

Computer Numerical Controls



***Manual Guide
for Lathe***

Operator's Manual

B-63344EN/02



- No part of this manual may be reproduced in any form.
- All specifications and designs are subject to change without notice.

In this manual we have tried as much as possible to describe all the various matters.

However, we cannot describe all the matters which must not be done, or which cannot be done, because there are so many possibilities.

Therefore, matters which are not especially described as possible in this manual should be regarded as "impossible".

SAFETY PRECAUTIONS

This manual includes safety precautions for protecting the user and preventing damage to the machine. Precautions are classified into Warnings and Cautions according to their bearing on safety. Also, supplementary information is described as Notes. Read the Warnings, Cautions, and Notes thoroughly before attempting to use the machine.

⚠ WARNING

Applied when there is a danger of the user being injured or when there is a damage of both the user being injured and the equipment being damaged if the approved procedure is not observed.

⚠ CAUTION

Applied when there is a danger of the equipment being damaged, if the approved procedure is not observed.

NOTE

The Note is used to indicate supplementary information other than Warning and Caution.

* Read this manual carefully, and store it in a safe place.

1.1 FOR SAFETY DURING OPERATION

To ensure safety while using a machine featuring the MANUAL GUIDE function that is made according to this programming manual, observe the following precautions:

WARNING

- 1 Confirm, on the screen, that the data has been entered correctly before proceeding to the next operation. Attempting operation with incorrect data may cause the tool to strike the work-piece or machine, possibly breaking the tool or machine or injuring the operator.
- 2 Before starting the machine using the tool compensation function, carefully determine the direction of compensation and the compensation value, and ensure that the tool will not strike the work-piece or machine. Otherwise the tool or machine may be damaged or the operator may injure.
- 3 Before playing back an operation after teaching it, check the tool paths on the confirmation screen to ensure that the tool will not strike the work-piece or machine. Otherwise, the tool or machine may be damaged or the operator may be injured.
- 4 To use constant surface speed control, set a value allowed for the work-piece and work-piece holding unit for the maximum spindle speed data item. If the set value is not appropriate, the work-piece or holding unit may fly due to centrifugal force, possibly breaking the machine or injuring the operator.
- 5 Set all necessary parameters and data items before starting MANUAL GUIDE operations. Note that if the cutting conditions are not suitable for the work-piece, the tool may be damaged or the operator may be injured.
- 6 After teaching a machining program created using MANUAL GUIDE functions, do not run the machine on that program immediately. Instead, confirm every step of the resultant program, and make sure that the tool path and machining operation are correct and that the tool will not strike the work-piece or machine. Before starting production machining, run the machine with no work-piece attached to the machine to make sure that the tool will not strike a work-piece or the machine. If the tool strikes the machine and/or work-piece, the tool and/or machine may be damaged, and even injuries the operator.

CAUTION

After pressing the power-on button, do not touch any keys on the keyboard until the initial screen appears. Some keys are used for maintenance or special operations such that pressing such a key may cause an unexpected operation.

TABLE OF CONTENTS

SAFETY PRECAUTIONS	s-1
I. GENERAL	
1 OVERVIEW	3
2 GUIDANCE HANDWHEEL	4
3 ALL-IN-ONE SCREEN	6
4 SYMBOLS USED	8
II. OPERATION	
1 OVERVIEW OF THE PROCEDURE.....	11
1.1 THE MANUAL GUIDE CONCEPT	12
1.2 FLOWCHART OF OPERATIONS.....	14
2 DESCRIPTION OF THE KEYBOARD	15
2.1 9.5"/10.4" LCD-MOUNTED TYPE CNC CONTROL UNIT	16
2.2 STAND-ALONE TYPE SMALL MDI UNIT	16
2.3 STAND-ALONE TYPE STANDARD MDI UNIT	17
3 DESCRIPTION OF COORDINATE.....	18
3.1 MACHINE COORDINATE SYSTEM	19
3.2 WORKPIECE COORDINATE SYSTEM	20
3.3 PROGRAM COORDINATE SYSTEM.....	22
4 GUIDANCE CUTTING OPERATIONS.....	23
4.1 SELECTING THE GUIDANCE CUTTING.....	24
4.2 INPUTTING PROCESS DATA	25
4.2.1 Main Process Data	25
4.3 TEACH-IN CUTTING MOTIONS	26
4.3.1 Figure Data Window	26
4.3.2 Operation of Teach-in Auxiliary Function Blocks	27
4.3.3 Operation of Teach-in a Rapid Traverse Motion Block	28
4.3.4 Operation of Teach-in a Simple Linear Cutting Motion Block	28
4.3.5 Operation of Guidance Cutting (Line)	29
4.3.6 Operation of Guidance Cutting (Circle)	32
4.3.7 Operation of Teach-in a Cutting Block	35

4.4	EDITING TAUGHT-IN BLOCKS	36
4.4.1	Figure Data Window	36
4.4.2	Operations for Figure Data Editing	37
4.5	CHECKING CUTTING MOTIONS ON A GRAPHIC WINDOW	38
4.5.1	Graphic Window.....	38
4.6	PLAYBACK MACHINING	39
4.6.1	One-shot Playback Machining.....	39
4.6.2	Whole Processes Playback Machining.....	40
4.7	ONE-SHOT MACHINING SIMULATION OF A INPUTTING PROCESS	41
5	SINGLE CUTTING OPERATIONS	42
5.1	SELECTING THE SINGLE CUTTING	43
5.2	INPUTTING PROCESS DATA	44
5.2.1	Main Process Data.....	44
5.3	ENTERING CUTTING MOTIONS.....	45
5.3.1	Figure Data Window	45
5.3.2	Operation of Teach-in Auxiliary Function Blocks	46
5.3.3	Operation of Teach-in a Positioning Block	46
5.3.4	Operation of Teach-in a Simple Linear Cutting Motion Block.....	46
5.3.5	Operation of Entering a Tool Path (Positioning/Line/Circle)	47
5.3.6	Displaying of Entered Tool Motion Blocks	49
5.4	EDITING TAUGHT-IN OR ENTERED BLOCKS.....	50
5.4.1	Figure Data Window	50
5.4.2	Operations for Figure Data Editing	51
5.5	CHECKING CUTTING MOTIONS ON A GRAPHIC WINDOW	52
5.6	PLAYBACK MACHINING	53
5.7	ONE-SHOT MACHINING SIMULATION OF A INPUTTING PROCESS	54
6	CYCLE CUTTING OPERATIONS	55
6.1	SELECTING THE CYCLE CUTTING	56
6.2	INPUTTING PROCESS DATA	57
6.2.1	Sample of Process Data	57
6.2.2	Supplemental Process Data	58
6.3	INPUTTING FIGURE DATA (OTHER THAN BAR MACHINING)	59
6.4	INPUTTING CONTOUR FIGURE DATA (BAR MACHINING)	60
6.5	EDITING CONTOUR FIGURE DATA (BAR MACHINING).....	62
6.5.1	Changing Inputted Contour Figure Data	62
6.5.2	Inserting a new Contour Figure Data	62

6.5.3	Deleting a needless Contour Figure Data	62
6.5.4	Inserting a New Contour Figure	62
6.5.5	Deleting a Contour Figure	63
6.5.6	Changing a Figure.....	63
6.6	RECALL OF FIGURE DATA FOR ROUGHING AND FINISHING	64
6.7	CHECKING CUTTING MOTIONS ON A GRAPHIC WINDOW	65
6.8	PLAYBACK MACHINING	66
6.9	ONE-SHOT MACHINING SIMULATION OF A INPUTTING PROCESS	67
7	EDITTING OF PLAYBACK MACHINING PROGRAMS	68
7.1	CHANGING PROGRAM NAME	69
7.2	EDITING THE CONTENTS OF MACHINING PROCESS	70
7.3	DELETING / COPYING A PROGRAM.....	71
7.3.1	Deleting a Program.....	71
7.3.2	Copying a Program.....	71
7.4	PROCESS EDITING.....	72
7.4.1	Moving a Process.....	72
7.4.2	Copying a Process	73
7.4.3	Deleting a Process	73
8	PLAYBACK MACHINING AND MACHINING SIMULATION.....	74
8.1	PLAYBACK MACHINING	75
8.2	MACHINING SIMULATION	76
8.2.1	Machining Simulation with Tool Path Drawing	76
8.2.2	Machining Simulation with Solid Model Animated Drawing.....	76
8.2.3	Machining Simulation with Animated Drawing and Tool Path.....	77
9	SETTING DATA	78
9.1	TOOL DATA	79
9.1.1	Tool File Window.....	79
9.1.2	Operation of Tool File Window	79
9.1.3	Detail of Tool File Data.....	80
9.2	MEASURING WORKPIECE COORDINATE SHIFT AMOUNT	81
9.3	TOOL FORM FOR ANIMATED DRAWING	84
9.3.1	General-Purpose Cutting Tools	84
9.3.2	Threading Tools.....	85
9.3.3	Grooving Tools.....	86
9.3.4	Center Drills	87
9.3.5	Drills 87	

9.3.6	Taps	87
9.3.7	Ramers	88
9.3.8	Boring Tools	88
9.3.9	Round Nose Cutting Tools	88
10	CONVERTING MACHINING PROGRAM INTO NC PROGRAM	89
10.1	OPERATIONS FOR CONVERSION.....	90
10.2	ALARMS DURING CONVERSION OF THE MACHINING PROGRAM INTO NC PROGRAM.....	91
11	OUTPUTTING / INPUTTING MACHINING PROGRAMS	92
11.1	OUTPUTTING MACHINING PROGRAMS	93
11.2	INPUTTING MACHINING PROGRAMS	94
III. TYPES OF CYCLE MOTIONS		
1	BAR MACHINING (ROUGHING).....	97
1.1	DETAIL OF PROCESS DATA	98
1.1.1	Process Data Window	98
1.1.2	Supplemental Process Data in a Pop-up Window	99
1.2	DETAIL OF FIGURE DATA	101
1.3	DETAIL OF CONTOUR CALCULATION	105
2	BAR MACHINING (FINISHING).....	115
2.1	DETAIL OF PROCESS DATA	116
2.1.1	Process Data Window.....	116
2.1.2	Supplemental Process Data in a Pop-up Window	117
2.2	DETAIL OF FIGURE DATA	119
2.3	NECKING FIGURE INPUTTING OF DIN509-E, DIN509-F, AND DIN76 ..	120
3	THREADING	122
3.1	DETAIL OF PROCESS DATA	123
3.1.1	Process Data Window.....	123
3.1.2	Supplemental Process Data in a Pop-up Window	128
3.2	DETAIL OF FIGURE DATA	129
4	GROOVING	132
4.1	DETAIL OF PROCESS DATA	133
4.1.1	Process Data Window.....	133
4.1.2	Supplemental Process Data in a Pop-up Window	134
4.2	DETAIL OF FIGURE DATA	135

5 TRAPEZOIDAL GROOVING (ROUGHING AND FINISHING).....	137
5.1 DETAIL OF PROCESS DATA	138
5.1.1 Process Data Window for Roughing	138
5.1.2 Process Data Window for Finishing.....	139
5.1.3 Supplemental Process Data in a Pop-up Window for Roughing.....	140
5.1.4 Supplemental Process Data in a Pop-up Window for Finishing	141
5.2 DETAIL OF FIGURE DATA	142
6 CENTER DRILLING / DRILLING / REAMING / BORING / TAPPING	144
6.1 DETAIL OF PROCESS DATA	146
6.1.1 Process Data Window.....	146
6.1.2 Supplemental Process Data in a Pop-up Window	150
7 -X AREA CUTTING FUNCTION.....	153
7.1 SELECTING OF -X AREA CUTTING	154
7.2 DETAIL OF -X AREA CUTTING	155

IV. SAMPLE OF PROGRAMMING

1 EXAMPLE OF CONTOUR FIGURE INPUTTING	159
--	------------

V. SUPPLEMENT

1 CALCULATING INPUT DATA.....	173
1.1 OVERVIEW	174
1.2 OPERATION.....	175
1.3 KEYS FOR ARITHMETIC OPERATIONS	176
2 USEFUL DISPLAY FUNCTIONS	177
2.1 BLANK FIGURE DATA DISPLAY IN THE PROGRAM LIST WINDOW	178
2.2 ALARM MESSAGE WINDOW.....	179
2.3 VARIOUS TYPES OF CURRENT POSITION DISPLAY AND COORDINATE SYSTEM PRESET	180
2.4 SOFT-KEY FOR ANIMATED DRAWING SCALING OPERATION.....	181
2.5 DIRECT INPUT OF THE JOG FEEDRATE	182
2.6 NC STATEMENT DISPLAY ON THE MACHINING SIMULATION SCREEN	183
3 USEFUL FUNCTIONS FOR MACHINING PROCESSES.....	184
3.1 INCREMENTAL COORDINATE INPUT	185
3.2 SUPPORT OF BACK TOOL POST LATHES	188
3.3 UNIDIRECTIONAL GROOVE CUTTING	190

3.4	AUTOMATIC DIVISION OF TAUGHT-IN BLOCKS IN GUIDANCE CUTTING	191
3.5	SPECIFICATION OF SEMIFINISHING FOR BAR MACHINING	192
3.6	SAFE OPERATION FOR PROGRAM SELECTION	193
3.7	REVERSE TAPPING	194
4	C-AXIS CUTTING A	202
4.1	C-AXIS END FACE CENTER DRILLING, C-AXIS END FACE DRILLING, C-AXIS END FACE REAMING, C-AXIS END FACE BORING, C-AXIS END FACE TAPPING	203
4.1.1	Selecting the Type of Machining	203
4.1.2	Detail of Process Data	204
4.1.3	Supplemental Process Data in a Pop-up Window	210
4.1.4	Detail of Figure Data	214
4.2	C-AXIS SIDE FACE CENTER DRILLING, C-AXIS DRILLING, C-AXIS REAMING, C-AXIS BORING, C-AXIS TAPPING	217
4.2.1	Selecting the Type of Machining	217
4.2.2	Detail of Process Data	218
4.2.3	Detail of Figure Data	220
4.3	C-AXIS END FACE GROOVING	223
4.3.1	Selecting the Type of Machining	223
4.3.2	Detail of Process Data	224
4.3.3	Supplemental Process Data in a Pop-up Window	227
4.3.4	Detail of Figure Data	229
4.4	C-AXIS SIDE FACE GROOVING	233
4.4.1	Selecting the Type of Machining	233
4.4.2	Detail of Process Data	233
4.4.3	Supplemental Process Data in a Pop-up Window	234
4.4.4	Detail of Figure Data	236
5	WASTE CUTTING CANCEL FUNCTION	240
5.1	INPUTTING A BLANK FIGURE	241
5.2	DETAILS OF CUTTING MOTIONS	244
6	RETHREADING	246
6.1	OVERVIEW	247
6.2	OPERATION	249

APPENDIX

A	PARAMETERS.....	253
A.1	PARAMETERS FOR DRILLING (1).....	254
A.2	PARAMETERS FOR MANUAL GUIDE PERIPHERAL FUNCTIONS	255
A.3	USER PARAMETERS	258
A.4	BIT TYPE PARAMETERS FOR MANUAL GUIDE COMMON USE	259
A.5	NUMERICAL PARAMETERS FOR MANUAL GUIDE COMMON USE	270
A.6	PARAMETER FOR BAR MACHINING	274
A.7	PARAMETER FOR GROOVING	278
A.8	PARAMETER FOR THREADING.....	280
A.9	PARAMETERS FOR DRILLING	284
A.10	PARAMETERS FOR OTHER MANUAL GUIDE FUNCTIONS.....	287
A.11	SETTING PARAMETERS IN THE NC.....	290
B	ALARMS	293
C	DYNAMIC GRAPHIC DISPLAY FOR NC PROGRAMS	296
C.1	OVERVIEW	297
C.2	OPERATION (MACHINING SIMULATION).....	298
C.3	OPERATION (SCALING).....	300
C.4	DYNAMIC GRAPHIC COMMANDS	301
D	ADDITIONAL INFORMATION ON EACH CUTTING MOTION.....	303
D.1	BAR MACHINING	304
D.2	NORMAL GROOVING	309
D.3	TRAPEZOIDAL GROOVING	311
D.4	THREADING.....	313

I. GENERAL

1

OVERVIEW

Overview of the manual

This manual describes the functions related to 1-path Lathe MANUAL GUIDE of Series 16i/18i/21i-TA/TB.

For other functions, refer to the operator's manual for the Series 16i/18i/21i-TA/TB.

The specifications and usage of the MANUAL GUIDE may vary according to the specifications of the operator's panel of a machine tool. Be sure to read the manual provided by the machine tool builder. The functions of the CNC machine tool system are determined not only by the CNC, but by the combination of the machine tool, the power magnetic circuit in the machine tool, the servo system, the CNC and the operator's panel.

It is impossible to cover all possible combinations of all functions, programming methods, and operations in a single manual.

This manual explains only the MANUAL GUIDE operations provided for the CNC. For individual CNC machine tools refer to applicable manuals from the machine tool builders. The manuals from machine tool builders take precedence over this manual.

This manual explains as many detailed functions as possible. However, it is not possible to describe all of the items which cannot be done or which the operator must not do. Therefore, please assume that functions other than those described in this manual cannot be performed.


Detailed information and special conditions are explained in notes. The readers may encounter new technical terms in the notes not previously defined or described. In this case, read this manual through first, then review the details.

2

GUIDANCE HANDWHEEL

Guidance Cutting and Guidance Handwheel

When a handwheel of a general-purpose lathe is rotated, the tool moves along only one axis. To carry out machining along a tapered or arc figure, an operator must rotate two handwheels simultaneously in synchronization. It is almost impossible to ensure accurate machining with this method.




Machining with a General Purpose Lathe

The Guidance Cutting eliminates the limitation of the general purpose lathe and enables sophisticated machining.

A guidance handwheel is provided so that an operator of the general purpose lathe can easily implement the function.

When the MANUAL GUIDE is used, just a few turns of the single guidance handle are required to carry out machining along a tapered or arc figure.



Rotating the Guidance Handwheel for Machining

After cutting a workpiece by using the above guidance cutting, this cutting motion can be taught into a machining program as an one block motion command, and these taught-in motion command can be used for playback machining.

Synchronous Feed and Guidance Handwheel


During running a machining program under automatic executing mode, an operator can control a tool motion by using guidance handwheel.

By selecting a synchronous feed mode on guidance handwheel, an operator can make a tool moved by the feedrate which is synchronized with handwheel rotating instead of inputted feedrate in the machining program.

3

ALL-IN-ONE SCREEN

In MANUAL GUIDE, basically, only one screen called All-in-one Screen is used for all the operations for it.



Title area :

The title of MANUAL GUIDE is displayed always.

CNC status area :

Following CNC status information are displayed always.

- Mode
- Alarm status
- Reset or Emergency stop status
- Actual time

Status indicator window :

Following CNC status information are displayed always.

- Actual machine position and Servo load meter
- Moving distance of actual and next block
- Feedrate and Guidance handwheel mode
- Spindle rotating speed and mode
- Actual program and process number
- Actual command by machining program

Graphic window:

Following graphical drawing are displayed as occasion demands.

- Taught-in tool path of guidance cutting and tracing cutting
- Animated drawing of machining simulation
- Tool path of machining simulation

Program window :

Following program information are displayed as occasion demands.

- Actual process name
- Process data of actual process
- Figure data of actual process

Pop-up window :

Following supplemental screens are displayed as occasion demands.

- Tool file
- Set-up guidance for work coordinate shift amount
- Program list
- Process list
- Supplemental program data

Key-in buffer :

Inputting numerical data and its comment are displayed as occasion demands.

Soft-keys :

Following soft-keys comment for indicating its contents are displayed as occasion demands.

- Machining type menu
- Data item menu
- Teach-in type menu
- Operating key
- Pop-up window menu

4

SYMBOLS USED

The following explains how keys and buttons are indicated in this manual.

- (1) Functions buttons are indicated in bold type :
Example) PRGRM, OFSET
- (2) Numeric keys to be entered from key-board are underlined :
Example) 12.345
- (3) The input key is indicated in bold type in the same way as the function buttons. Generally, the input key follows numeric key input :
Example) 12.345 **INPUT**
- (4) Soft-keys are enclosed in brackets [] :
Example) [LIST], [LINE]
- (5) The cursor keys are indicated by the following symbols :
Example) \uparrow , \downarrow , \leftarrow , \rightarrow
- (6) The page keys are indicated by the following symbols :
Example) \uparrow , \downarrow

II. OPERATION


1

OVERVIEW OF THE PROCEDURE

1.1 THE MANUAL GUIDE CONCEPT

By using MANUAL GUIDE, an operator can handle a newly equipped machine from simple cutting using a handwheel to complicated machining step by step. He will be able to carry out them without making a detour.

On MANUAL GUIDE, machining operations can be classified to 3 steps by an operator's programming skill.



Manually Cutting

As the 1st step after machine equipment, without any data inputting nor programming, by using normal handwheel for X/Z-axis, an operator can carry out a simple machining such as straight longitudinal or radial cutting, still more drilling.

Since this normal handwheel is available at anytime during idling status of MANUAL GUIDE, an operator carry out this handwheel cutting seeing a position display on an All-in-one screen.

This should be familiar to an operator has been using a manual lathe, mechanically driven lathe.

In addition to moving tool function, auxiliary function switches are prepared on a machine operator's panel.

Guidance / Single Cutting

As the 2nd skill up step, an operator can carry out a taper and circular cutting by using guidance handwheel.

There are 2 types for this cutting.

1) Guidance Cutting

By inputting a target line or circle figure data, an operator can carry out an approach cutting or along cutting by using a guidance handwheel.

Still more, by teaching these cutting motion blocks into CNC memory, an operator can carry out a playback machining repeatedly by using them, and at this time, he can control a tool motion by using a guidance handwheel in synchronous mode.

2) Single Cutting

By inputting a tool motion path of line or circle, an operator can carry out these cutting motion blocks, and he can control a tool motion by using a guidance handwheel in synchronous mode.

At the time of inputting a tool path data, simple figure calculating such as end coordinate calculating can be used.

In addition to the above cutting function, similar to the manually cutting method, auxiliary function switches prepared on a machine operator's panel can be used. Still more, these auxiliary function can be taught-in with the above cutting motions and used for playback machining.

Cycle Cutting

As the final skill up step, an operator can carry out a complicated machining by inputting necessary program data for cycle cutting.

The following types of cycle cutting are available


- 1) Bar machining (Outer, Inner, End face)
- 2) Grooving (Standard, Trapezoidal)
- 3) Threading (General, Metric, Unified, PT, PF)
- 4) Necking (DIN509-E, DIN509-F, DIN76)
- 5) Drilling (Center-drilling, Drilling, Reaming, Boring)
- 6) Tapping

Especially, in Bar machining, strong contour calculating functions are prepared for inputting a free contour form.

In these cycle cutting procedures, necessary auxiliary functions such as spindle rotation or tool changing are automatically outputted, so an operator can carry out a complicated machining by only pushing a cycle starting button.

1.2 FLOWCHART OF OPERATIONS


The following shows the general procedure from preparing to start making a machining program to executing a playback machining by using MANUAL GUIDE.




2

DESCRIPTION OF THE KEYBOARD


2.1 9.5"/10.4" LCD-MOUNTED TYPE CNC CONTROL UNIT



2.2 STAND-ALONE TYPE SMALL MDI UNIT




2.3 STAND-ALONE TYPE STANDARD MDI UNIT



3

DESCRIPTION OF COORDINATE

3.1 MACHINE COORDINATE SYSTEM



The above figure shows the state in which a tool post has returned to the reference position. The X and Z machine coordinates of the position of the tool post are 0. When the tool post is manually returned to a reference position, the X and Z machine coordinates of the machine reference position are automatically set to 0.

The directions of the X- and Z-axes are specified so that the tool post moves always from a workpiece or the spindle when the tool post moves in the positive X and Z directions.

This machine coordinate system is kept unchanged, regardless of whether the program reference position, explained later, is set on the end face of a workpiece.

3.2 WORKPIECE COORDINATE SYSTEM


The machine coordinate system previously mentioned is peculiar to a specific machine. It is determined uniquely regardless of the workpieces and tools used.

Another coordinate system is required for each tool to prevent programmed positions from changing between tools because of the difference in tool dimensions. This coordinate system must be set with respect to the dimensions of a specific tool. Such coordinate systems are called Workpiece Coordinate System.

A workpiece coordinate system is determined using the Tool Geometry Offset. For details of it, refer to the CNC Operator's Manual.


The origin of the workpiece coordinate system is set on the end face of workpiece always in MANUAL GUIDE.

In the following sample drawing, OFS_x and OFS_z means the distance with sign between 2 points, 1st is the position at the tool post is at the machine zero point, 2nd is the position at the imaginary nose is at the center of the end face of the workpiece (origin of the workpiece coordinate). These distance data are set into the geometry offset amount.



At the time of changing workpiece and its length is changed, instead of measuring the above geometry offset value for all tools, Workpiece Shift offset compensation is used for shifting the workpiece coordinate origin point.

In the following sample drawing, WSF_Z means the distance with sign between the end face of the old workpiece and the new one. This distance data is set into the Z-workpiece shift offset amount.



By using the Set-up Guidance, described later in Chapter 9, workpiece shift amount are automatically set.

3.3 PROGRAM COORDINATE SYSTEM

When a machining program is created by MANUAL GUIDE, the dimensions are specified similarly with workpiece coordinate system.

4

GUIDANCE CUTTING OPERATIONS

As described in Chapter I.2 GUIDANCE HANDWHEEL, an operator can carry out machining along a tapered or arc figure by using a guidance handwheel. And also, he can enter the motion block into CNC temporary memory, this entering operation is called “Teaching-in”. These entered, taught-in, motion blocks can be used repeatedly for cutting the same part during corresponding process is selected. In order to use these taught-in motion blocks for later occasion, they can be saved into CNC kept memory, called “Playback Machining Program”, and this operation is called “Save into Playback Machining Program”. By using this playback machining program, an operator can carry out same machining motions repeatedly later on.

4.1 SELECTING THE GUIDANCE CUTTING

By the following operations, an operator can select a Guidance Cutting mode.

- 1) Push **RESET** key on a LCD/MDI keyboard.
- 2) Push soft-key [GUIDNC].

NOTE

When the soft-key [GUIDNC] is not displayed on a screen, it will be displayed by pushing left-end softkey called Super Return.

There may be a case that menu keys for selecting machining type are prepared on a machine operator's panel, then refer to the manual prepared by machine tool builder.


4.2 INPUTTING PROCESS DATA

By selecting Guidance Cutting, the following Process Data items are displayed in a Program Window. As to supplemental process data, they will be displayed in a pop-up window, and it can be displayed by pushing soft-key [DETAIL].

4.2.1 Main Process Data

GUIDANCE CUTTING	
TOOL NUM =	
FEED/REV. =	
S-SPEED =	
TOOL KIND =	
TOOL DATA =	

TOOL NUM.	Number of tool used for guidance cutting
FEED/REV.	Feedrate at playback machining, and it can be changed to FEED/MIN. by pushing soft-key [FEED/MIN.]
S-SPEED	Cutting speed at playback machining, and it can be changed to REV/MIN. by pushing soft-key [REV/MIN.]
TOOL KIND	Tool kind used for guidance cutting. Choose from the following soft-key menu.
	[GENERAL-OUT] Tool used for outer machining
	[GENERAL-INN] Tool used for inner machining
	[GENERAL-FACE] Tool used for facing
	[GROOVE-OUT] Tool used for outer grooving
	[GROOVE-INN] Tool used for inner grooving
	[GROOVE-FACE] Tool used for face grooving
	[DRILL] Tool used for drilling
TOOL DATA	Tool nose data used for guidance cutting. Choose from the following soft-key menu when one of the GENERAL-OUT,INN or FACE is selected in TOOL KIND input field.



When one of the GROOVE-OUT,INN or FACE is selected in TOOL KIND, tool width must be inputted in TOOL DATA input field.
 When the DRILL is selected in TOOL KIND, tool diameter must be inputted in TOOL DATA.

4.3 TEACH-IN CUTTING MOTIONS

After inputting necessary process data, a cursor moves into Figure Data Window automatically, and then, an operator can begin guidance cutting and teach-in operation. This status is called ‘Teach-in mode’.


NOTE

The maximum block number can be inputted in teach-in mode of a guidance cutting process is 80.

4.3.1 Figure Data Window

As described above, at the time that a cursor is in a figure data window, an operator can carry out a guidance cutting using guidance handwheel, and teach-in these cutting motions into CNC for later playback machining.

In this figure data window, taught-in cutting motion blocks are displayed, and an operator can edit the contents of them.



During Teach-in mode, the following soft-keys are displayed and they are used for teach-in operations.



4.3.2 Operation of Teach-in Auxiliary Function Blocks

On a machine operator's panel, the following auxiliary function switches are prepared.

- CSS (Constant Surface Speed) mode ON
- CSS mode OFF
- FEED/Rev.
- FEED/Min.
- T-code
- Spindle CW
- Spindle CCW
- Spindle Stop
- Coolant ON
- Coolant OFF
- Return to Tool Change Position
- Return to Machine Reference Position

By pushing a necessary switch among these switches, corresponding auxiliary function is carried out.

During Teach-in mode, these carried out auxiliary functions can be taught-in into CNC for later playback machining.

After pushing one or continuously several ones, maximum 10 blocks, of the above auxiliary function switches, by pushing [TEACH AUX], an operator can teach-in these commands into CNC for later playback. When several auxiliary function switches are pushed continuously before pushing [TEACH AUX], all of these commands are taught in CNC at a time.

NOTE

The above taught-in command blocks can be used for playback machining, but since they are temporary program as it is, these will be eliminated at the time the next machining type is selected. So, in order to use these taught-in command blocks for playback machining at later on, an operator must save them as a playback machining program.


4.3.3 Operation of Teach-in a Rapid Traverse Motion Block

During Teach-in mode, an operator can move a tool by handwheel or JOG stick on a machine operator's panel.

After moving a tool toward a proper position, by pushing [TEACH RAPID], an operator can teach-in this tool motion into CNC as a rapid traverse block for later playback.

This taught-in block is displayed in a figure data window as following sample.

G00 X78.010 Z10.053 ;




4.3.4 Operation of Teach-in a Simple Linear Cutting Motion Block

During Teach-in mode, an operator can cut a workpiece in direction of only X-axis or Z-axis by using a normal handwheel on a machine operator's panel.

After moving a tool toward a proper position, by pushing [TEACH CUT], an operator can teach-in this tool motion into CNC as a linear cutting block for later playback.

This taught-in block is displayed in a figure data window as following sample.

G01 X78.010 Z10.053 F0.5 ;




4.3.5 Operation of Guidance Cutting (Line)

By using a guidance handwheel on a machine operator's panel, an operator can carry out the following 2 types of linear cutting in simultaneous X and Z-axis direction.

- **Approach Cutting** to an inputted Target Line
- **Along Cutting** to an inputted Target Line

In order to input a target line, the following data input window is displayed in a pop-up window, and it can be called by pushing a [LINE].



X1/Z1/X2/Z2 POS. Absolute coordinate of separated 2 points on a line.
ANGLE Angle of line from +Z-axis. A positive angle is clockwise direction from +Z-axis, and minus angle is counter clockwise direction. If this data is inputted, only 1 point coordinate data is necessary among the above 2 points.


After inputting necessary data in the above window, by pushing [INPUT END], an operator can begin guidance cutting.

NOTE

As to the above position data (X1,Z1) and (X2,Z2), instead of inputting numerical data through keyboard, an operator can input the actual tool position by pushing [READ POS.].

Besides inputting data for target line, the following distance data are displayed in a pop-up window. An operator can move the tool while checking the distance to the target line.

D Distance between the current tool position and the target line.
DX/DZ Distance between the current tool position and the target line along X or Z-axis.



NOTE

At guidance cutting, the Nose-R compensation is done automatically, and the nose radius value of inputted tool number in a process data window is used for it.


So, the above distance data display the distance between 2 imaginary nose point of the current tool position and the position of that a nose circle is touched to the target line.

(1) Approach Cutting

By switching the guidance handwheel mode on a machine operator's panel, an operator can select an Approaching Cutting mode.

In an approach cutting mode, a tool moves along a line perpendicular to the target line according as an operator rotates a guidance handwheel.

During approach cutting mode, the following guidance is displayed in a pop-up window.



In the guidance displayed in a pop-up window, pink and green arrows indicate the direction in which the tool is moved. The direction in which the handwheel is rotated determines the direction of approach. At the end of hollow arrow, the handwheel and the direction of its rotation are displayed.

The feedrate of the tool motion depends on the speed at which the guidance handwheel is rotated.

(2) Along Cutting

By switching the guidance handwheel mode on a machine operator's panel, an operator can select an Along Cutting mode.

In an along cutting mode, a tool moves along a line parallel to the target line according as an operator rotates a guidance handwheel.

During along cutting mode, similar to the former approach cutting mode, the guidance for handwheel rotation is displayed in a pop-up window.

In the guidance, blue arrows indicate the direction of along cutting. The direction in which the handwheel is rotated determines the direction of along cutting. At the end of solid arrow, the handwheel and the direction of its rotation are displayed.

The feedrate of the tool motion depends on the speed at which the guidance handwheel is rotated.

(3) Limit Setting

Normally, a limit is set such that a tool does not exceed the target line. When the target line is inputted, an opposite area of target line from the tool position is set to the limit area.

By pushing a [LMTOFF], this soft-key display is changed to [LMT ON] and limit becomes unavailable. In order to make this limit be valid, push [LMT ON].


During this limit is valid, a black line is displayed at the top of the approaching arrow in a guidance drawing.

4.3.6 Operation of Guidance Cutting (Circle)

By using a guidance handwheel on a machine operator's panel, an operator can carry out the following 2 types of circular cutting in simultaneous X and Z-axis direction.

- **Approach Cutting** to an inputted Target Circle
- **Along Cutting** to an inputted Target Circle

In order to input a target circle, the following data input window is displayed in a pop-up window, and it can be called by pushing a [CIRCLE].



CENTER X/Z

Absolute coordinate of circle center.

RADIUS

Radius of circle.

After inputting necessary data in the above window, by pushing [INPUT END], an operator can begin guidance cutting.


NOTE

As to the above circle center position data (X,Z), instead of inputting numerical data through keyboard, an operator can input the actual tool position by pushing [READ POS.].

Similar to the guidance cutting for line, besides inputting data for target circle, the following distance data are displayed in a pop-up window. An operator can move the tool while checking the distance to the target circle.

D

Distance between the current tool position and the target circle.



NOTE

Similar to line cutting, the Nose-R compensation is done automatically, and the nose radius value of inputted tool number in a process data window is used for it.

So, the above distance data display the distance between 2 imaginary nose point of the current tool position and the position of that a nose circle is touched to the target line.


After inputting necessary data in the above window, by pushing [INPUT END], an operator can begin guidance cutting. By switching the guidance handwheel mode on a machine operator's panel, an operator can select one of Approaching Cutting or Along Cutting.

(1) Approach Cutting

By switching the guidance handwheel mode on a machine operator's panel, an operator can select an Approaching Cutting mode.

In an approach cutting mode, a tool moves along a line connecting the center of the tool nose and the center of the target circle according as an operator rotates a guidance handwheel.

During approach cutting mode, the following guidance is displayed in a pop-up window.



In the guidance displayed in a pop-up window, pink and green arrows indicate the direction in which the tool is moved. The direction in which the handwheel is rotated determines the direction of approach. At the end of hollow arrow, the handwheel and the direction of its rotation are displayed.

The feedrate of the tool motion depends on the speed at which the guidance handwheel is rotated.

(2) Along Cutting


By switching the guidance handwheel mode on a machine operator's panel, an operator can select an Along Cutting mode.

In an along cutting mode, a tool moves along a circle having the same center as the target line according as an operator rotates a guidance handwheel.

During along cutting mode, similar to the former approach cutting mode, the guidance for handwheel rotation is displayed in a pop-up window.

In the guidance, blue arrows indicate the direction of along cutting. The direction in which the handwheel is rotated determines the direction of along cutting. At the end of solid arrow, the handwheel and the direction of its rotation are displayed.

The feedrate of the tool motion depends on the speed at which the guidance handwheel is rotated.



(3) Limit Setting

Similar to the former line guidance cutting, normally, a limit is set such that a tool does not exceed the target line.


When the target line is inputted, an opposite area of target line from the tool position is set to the limit area.

By pushing a [LMTOFF], this soft-key display is changed to [LMT ON] and limit becomes unavailable. In order to make this limit be valid, push [LMT ON].

During this limit is valid, a black line is displayed at the top of the approaching arrow in a guidance drawing.

⚠ CAUTION

Be careful tool nose and workpiece because it interferes, when the following figure is cut by guidance machining,



4.3.7 Operation of Teach-in a Cutting Block


As described in former description, during Teach-in mode, an operator can cut a workpiece by using a normal handwheel or guidance handwheel.

After cutting a workpiece toward a proper position, by pushing [TEACH CUT], an operator can teach-in this tool motion into CNC as a cutting block for later playback.

This taught-in block is displayed in a figure data window as following sample.


Sample of Linear Cutting)

G01 X78.010 Z10.053 F0.25 ;



Sample of Circular Cutting)

G02 X78.010 Z10.053 R20.0 F0.25 ;



4.4 EDITING TAUGHT-IN BLOCKS

Taught-in “Auxiliary Function Block”, “Rapid Traverse Block” and “Cutting Motion Block” can be displayed in a figure data window as described in 4.3. And an operator can edit these blocks too.


4.4.1 Figure Data Window

By using 4-directional cursor keys $\uparrow \downarrow \rightarrow \leftarrow$ on a LCD/MDI unit, a cursor in a figure data window can be moved for pointing the data word of taught-in blocks.

As described above, at the time that a cursor is in a figure data window, an operator can carry out a guidance cutting using guidance handwheel, and teach-in these cutting motions into CNC for later playback machining.

In this figure data window, taught-in cutting motion blocks are displayed, and an operator can edit the contents of them.

By pushing a cursor key \uparrow or \downarrow , the contents of figure data window are shifted up and down, and an operator can see the whole blocks.



4.4.2 Operations for Figure Data Editing

(1) Alteration of numeric value

After pointing the objective word (=Address + Numeric data) by cursor, input only new numeric data through numeric keys on LCD/MDI unit, and push INPUT key.

By these operations, only numeric value can be altered.

(2) Alteration of Address and numeric value

After pointing the objective word (=Address + Numeric data) by cursor, input new address and numeric data through address and numeric keys on LCD/MDI unit, and push INPUT key.

By these operations, address and numeric value can be altered.

(3) Insertion of a new word

After pointing the word after that a new word should be inserted, input new word (=Address + Numeric data) through address and numeric keys , and push INSERT.

By these operations, a new word can be inserted after the pointed word.

(4) Insertion of a new motion block

After pointing the character “;”, end of the motion block after that a new motion block should be inserted, input necessary word address data such as G-code, axis motion word (X____ Z____) etc. After inputting whole necessary word address data, lastly, push “;” and INSERT.

By these operations, a new motion block word can be inserted after the pointed word.

(5) Deletion of a word

After pointing the objective word (=Address + Numeric data), push DELETE.

Prompting message for confirmation of deleting will be displayed, so push DELETE again.

By these operations, this objective word can be deleted.

(6) Deletion of a motion block

After pointing some word (=Address + Numeric data) in the block which must be deleted, push “EOB” and **DELETE**. Prompting message for confirmation of deleting will be displayed, so push **DELETE** again.

By these operations, this objective motion block can be deleted.


4.5 CHECKING CUTTING MOTIONS ON A GRAPHIC WINDOW

Taught-in “Rapid Traverse Block” and “Cutting Motion Block” can be displayed graphically in a graphic window.

4.5.1 Graphic Window

In a graphic window, drawing of taught-in motion blocks are displayed in line form.

Cutting motion blocks are displayed by solid lines, and rapid traverse blocks are displayed by dotted line.



NOTE

The 1st block, since its starting point is not clear, is not displayed as a line drawing.

4.6 PLAYBACK MACHINING

Taught-in “Auxiliary Block”, “Rapid Traverse Block” and “Cutting Motion Block” can be executed in the form among of the following 2 types machining.

- One-shot playback machining
- Whole processes playback machining

4.6.1 One-shot Playback Machining

During a guidance cutting process is selected, in other word, its teach-in blocks are displayed in a figure data window, an operator can execute an actual machining by using taught-in blocks in its process, and it is called One-shot Playback Machining.

- Operations for one-shot playback machining
 - 1) By using cursor key $\uparrow \downarrow$, point the block from which playback machining is started. And as another method, pushing [HEAD] and pointing the cursor to the top of taught-in blocks, it can be started from the top of the process.
 - 2) By pushing [EXEC], playback machining of the taught-in blocks in its process can be started.

NOTE

Taught-in blocks by the operations described in this chapter are temporary one, and as it is, they will be canceled at the time next process is selected. If an operator wants to use these taught-in blocks for later playback machining, it is necessary to save them as a playback machining program.
As to the operations for this saving, refer to next chapter.

4.6.2 Whole Processes Playback Machining

In order to use taught-in blocks for whole processes playback machining, it is necessary to save them into CNC memory as a playback machining program.

- Operations for saving as a new playback program
 - 1) Push [SAVE], and a Program List is displayed in a pop-up window.

PROGRAM LIST			
Program	Program Name (Max 20ch.)	Processing time (Max 99minuites)	Lastly modified date and time
01: CIRCLE MACHINING 5M12S 10:LINE MACHINING		1997/05/12 10:12 4M32S	1997/06/10 11:21

Cursor

- 2) Input 2 digits number for program number, and push [NEW]. After then, a new program including current taught-in blocks is made.
- 3) Move a cursor onto the program name field, and Input program name through key-board, and push INPUT. The maximum character number of it is 20.

- Operations for adding to an old playback program
 - 1) Push [SAVE], and a Program List is displayed in a pop-up window.
 - 2) Select the program into which current taught-in blocks are added by positioning a cursor to its program number.
 - 3) Push [ADD], and after then, the current taught-in blocks are added the end of the selected playback program.

4.7 ONE-SHOT MACHINING SIMULATION OF A INPUTTING PROCESS

Taught-in “Auxiliary Block”, “Rapid Traverse Block” and “Cutting Motion Block”, can be checked by an one-shot playback machining simulation. And this machining simulation is done with tool path drawing only.

By pushing a [CHECK], it can be displayed by pushing a right-end soft-key [+], the following soft-keys are displayed.



[HEAD]	Return to the top of this process.
[RETURN]	End a check drawing and return to the programming screen.
[EXEC]	Start the continuous simulation drawing.
[SINGLE]	Cause a single block stop while continuous simulation is being executed. Or, starts single block simulation.

In order to return to the initial screen, push **RESET**, and then push [RETURN].

5

SINGLE CUTTING OPERATIONS

As described in Chapter I.2 GUIDANCE HANDWHEEL, an operator can enter cutting motions through key-board directly and control tool motions by using a guidance handwheel as a synchronous feed mode. And, these entered cutting motions are memorized into CNC temporary memory, and can be used repeatedly for cutting the same part during corresponding process is selected.

In order to use these entered cutting figures for later occasion, they can be saved into CNC kept memory, called “Playback Machining Program”, and this operation is called “Save into Playback Machining Program”. By using this playback machining program, an operator can carry out same machining motions repeatedly later on.

5.1 SELECTING THE SINGLE CUTTING

By the following operations, an operator can select a Single Cutting mode.

- 1) Push **RESET** key on a LCD/MDI keyboard.
- 2) Push soft-key [SINGLE].

NOTE

When the soft-key [SINGLE] is not displayed on a screen, it will be displayed by pushing left-end softkey called Super Return.

There may be a case that menu keys for selecting machining type are prepared on a machine operator's panel, then refer to the manual prepared by machine tool builder.

5.2 INPUTTING PROCESS DATA

By selecting Single Cutting, the following Process Data items are displayed in a Program Window.

5.2.1 Main Process Data

SINGLE CUTTING

TOOL NUM. =
FEED/REV. =
S-SPEED =
TOOL KIND =
TOOL DATA =

TOOL NUM	Number of tool used for single cutting
FEED/REV.	Feedrate at playback machining, and it can be changed to FEED/MIN. by pushing soft-key [FEED/MIN.].
S-SPEED	Cutting speed at playback machining, and it can be changed to REV/MIN. by pushing soft-key [REV/MIN.].
TOOL KIND	Tool kind used for guidance. Into details, refer to the Chapter 4.2.
TOOL DATA	Tool nose data for single cutting. Into details, refer to the Chapter 4.2.

5.3 ENTERING CUTTING MOTIONS

After inputting necessary process data, a cursor moves into Figure Data Window automatically, and then, an operator can enter the cutting motions directly through key-board, and carry out each cutting motion by using a guidance handwheel as a synchronous feed mode. And at this time, teaching of motion blocks done by using normal handwheel and auxiliary function blocks done by using switches on a machine operator's panel are possible too.

NOTE

The maximum block number can be entered in a single cutting process is 80.


5.3.1 Figure Data Window

As described above, at the time that a cursor is in a figure data window, an operator can carry out cutting of entered motion blocks by using a guidance handwheel.

These entered motion blocks are memorized into CNC temporary memory, and can be used for playback machining.

Besides, similar to the guidance cutting of former chapter, an operator can teach-in motion blocks by normal handwheel and auxiliary function. This status is called "Teach-in mode", similar to guidance cutting.

In this figure data window, entered and taught-in cutting motion blocks are displayed, and an operator can edit the contents of them.



During Teach-in mode, the following soft-keys are displayed and they are used for entering a new motion block and teach-in operations.



5.3.2 Operation of Teach-in Auxiliary Function Blocks

Similar to a guidance cutting process, the following auxiliary function switches on a machine operator's panel can be used. And, these auxiliary functions can be taught-in into CNC by [TEACH AUX].


- CSS (Constant Surface Speed) mode ON
- CSS mode OFF
- FEED/Rev.
- FEED/Min.
- T-code
- Spindle CW
- Spindle CCW
- Spindle Stop
- Coolant ON
- Coolant OFF
- Return to Tool Change Position
- Return to Machine Reference Position

5.3.3 Operation of Teach-in a Positioning Block

Similar to a guidance cutting process, tool positioning motions done by normal handwheel or JOG stick can be taught-in by [TEACH RAPID].

This taught-in block is displayed in a figure data window as following sample.

G00 X78.010 Z10.053 ;




5.3.4 Operation of Teach-in a Simple Linear Cutting Motion Block

Similar to a guidance cutting process, an operator can cut a workpiece in direction of only X-axis or Z-axis by using a normal handwheel, and these cutting motions can be taught-in by [TEACH CUT].

This taught-in block is displayed in a figure data window as following sample.

G01 X78.010 Z10.053 F0.5 ;




5.3.5 Operation of Entering a Tool Path (Positioning/Line/Circle)

After positioning a cursor to the end of taught-in blocks in a figure data window, an operator can input a tool path data with its end point calculating.

When the coordinate of the figure end point is unknown, it can be calculated and the figure can be entered.

Positioning Motion

By pushing a [POS.], the following figure inputting window is displayed in a pop-up window.




END POINT X/Z Absolute coordinate of end point

NOTE

As to the above position data (X, Z) , instead of inputting numerical data through key-board, an operator can input the actual tool position by pushing [READ POS.]

Linear Cutting Motion

By pushing a [LINE], the following figure inputting window is displayed in a pop-up window.



END POINT X/Z Absolute coordinate of end point
ANGLE Angle of line from +Z-axis. A positive angle is clockwise direction from +Z-axis, and minus angle is counter clockwise direction. If this angle data is inputted, end point either X or Z need not be entered, and not inputted data can be calculated.


FEEDRATE Feedrate of this cutting motion (data inputted in process data is set as a default value)

NOTE

As to the above position data (X, Z) , instead of inputting numerical data through key-board, an operator can input the actual tool position by pushing [READ POS.]

Circular Cutting Motion

By pushing a [CW] / [CCW], the following figure inputting window is displayed in a pop-up window.



END POINT X/Z	Absolute coordinate of end point
RADIUS	Radius of this circle
CENTER X/Z	Absolute coordinate of center point of this circle. If these center data (I/K) are inputted, end point either X or Z need not be entered, and not inputted data can be calculated. If end point (X/Z) and center point (I/K) are inputted, radius data need not be inputted.
FEEDRATE	Feedrate of this cutting motion (data inputted in process data is set as a default value)

NOTE


As to the above position data (X,Z), instead of inputting numerical data through key-board, an operator can input the actual tool position by pushing [READ POS.].

5.3.6 Displaying of Entered Tool Motion Blocks


As described in former description, an operator can input a figure data for each tool motion blocks.

After inputting necessary figure data for each tool motions blocks, by pushing **INSERT**, calculation of end points coordinate is done, and the result of it is displayed in a figure data window as following sample.


Sample of Positioning)



Sample of Linear Cutting)



Sample of Circular Cutting)




5.4 EDITING TAUGHT-IN OR ENTERED BLOCKS

Taught-in or entered “Auxiliary Function Block”, “Positioning Block” and “Cutting Motion Block” can be displayed in a figure data window as described in 5.3. And an operator can edit these blocks too.

5.4.1 Figure Data Window

By using 4-directional cursor keys $\uparrow \downarrow \rightarrow \leftarrow$ on a LCD/MDI unit, a cursor in a figure data window can be moved for pointing the data word of taught-in blocks.

By pushing a cursor key \uparrow or \downarrow , the contents of figure data window are shifted up and down, and an operator can see the whole blocks.



5.4.2 Operations for Figure Data Editing

(1) Alteration of numeric value

After pointing the objective word (=Address + Numeric data) by cursor, input only new numeric data through numeric keys on LCD/MDI unit, and push INPUT key.

By these operations, only numeric value can be altered.

(2) Alteration of Address and numeric value

After pointing the objective word (=Address + Numeric data) by cursor, input new address and numeric data through address and numeric keys on LCD/MDI unit, and push INPUT key.

By these operations, address and numeric value can be altered.

(3) Insertion of a new word

After pointing the word after that a new word is inserted, input new word (=Address + Numeric data) through address and numeric keys, and push INSERT.

By these operations, a new word can be inserted after the pointed word.

(4) Insertion of a new motion block

After pointing the character “;”, end of the motion block after that a new motion block should be inserted, select a figure type by pushing a corresponding soft-key menu. By this operation, a figure data inputting window, pop-up window, is displayed on a screen.

After inputting whole necessary figure data, push INSERT.

By these operations, a new motion block can be inserted.

(5) Deletion of a word

After pointing the objective word (=Address + Numeric data), push DELETE.

By these operations, this objective word can be deleted.

(6) Deletion of a motion block

After pointing some word (=Address + Numeric data) in the block which must be deleted, push “;” and DELETE.

By these operations, this objective motion block can be deleted.

NOTE

As to inputted data such as angle and center point, they are used for calculating end point, they cannot be changed after calculating.

5.5 CHECKING CUTTING MOTIONS ON A GRAPHIC WINDOW

Entered and taught-in tool motion block can be displayed graphically in a graphic window. It is similar to the case of Guidance Cutting. Into details, refer to the Chapter 4.

5.6 PLAYBACK MACHINING

Entered and taught-in tool motion blocks and auxiliary function blocks can be executed in the form among of the following 2 types machining.

- One-shot playback machining
- Whole processes playback machining

These are similar to the case of Guidance Cutting. Into details, refer to the Chapter 4.

NOTE

In single cutting motions, as described in this chapter, inputting motion blocks are the path of a tool, so Nose-R compensation is never be done.

5.7 ONE-SHOT MACHINING SIMULATION OF A INPUTTING PROCESS

Entered and taught-in motion blocks can be checked by an one-shot playback machining simulation. And this is similar to the case of Guidance Cutting. Into details, refer to the Chapter 4.

6

CYCLE CUTTING OPERATIONS

In cycle cutting, all of the motions, tool changing, approaching, auxiliary functions and cutting and so on, are automatically done.

Following cutting types are available.

- 1) Bar machining (Roughing)
- 2) Bar machining (Finishing)
- 3) Threading
- 4) Grooving (Standard)
- 5) Grooving (Trapezoidal Roughing)
- 6) Grooving (Trapezoidal Finishing)
- 7) Center drilling
- 8) Drilling
- 9) Reaming
- 10) Boring
- 11) Tapping

As to the details of each cycle cutting type, refer to Part III "Types of Cycle Motions". In this chapter, general operations for cycle cutting are described.

6.1 SELECTING THE CYCLE CUTTING

By the following operations, an operator can select a necessary cycle cutting type.

- 1) Push **RESET** key on a LCD/MDI keyboard.
- 2) Push soft-key [**CYCLE**].
- 3) Push soft-key for each cutting cycle type.



By pushing a [+], the 2nd menu as follows is displayed.



NOTE

There may be a case that some particular machining function are added by MTB, and at this time, menu for these functions are displayed in the above [*] soft-keys.

Into details, refer to the MTB's manual.

6.2 INPUTTING PROCESS DATA

By selecting each cycle cutting type, necessary process data items are displayed in a Program Window. As to supplemental process data, they will be displayed in a pop-up window, and it can be displayed by pushing soft-key [DETAIL].

6.2.1 Sample of Process Data

Example) Bar machining (Roughing)

BAR MACHINING

AREA	=	CUT ST Z	=
TOOL NUM.	=	FIN X	=
FEED/REV.	=	FIN Z	=
S-SPD/MIN	=	INFEED AM	=
S-DIRECT	=		
CUT ST X	=		

AREA

Select from [OUTER]/[INNER]/[FACE]/[OUTER REVERS] / [INNER/REVERS]/[FACE REVERS]

TOOL NUM.

Number of tool used for cycle cutting

FEED/REV.

Feedrate at playback machining, and it can be changed to FEED/MIN. by pushing soft-key [FEED/MIN.]

S-SPD/MIN

Cutting speed at playback machining, and it can be changed to REV/MIN. by pushing soft-key [REV/MIN.]

S-DIRECT.

Spindle rotating direction.

CUT ST X/Z

Coordinate of cutting start position. These are automatically set by inputting figure data.

FIN X/Z

X/Z direction amount of finishing.

INFEED AM

Infeed amount of the first cutting motion.

6.2.2 Supplemental Process Data

EDGE ANGL =	COOLANT =
NOSE ANGL =	SPDL GEAR=
RESE.AMNT =	
RELEASE =	
APPROACHX=	
APPROACHZ=	

By pushing a [DETAIL], a detail data window is displayed. These supplemental process data are automatically set always, so in ordinary case, an operator need not to call this detail data window excepting the case of checking these data. When more detailed control for machining motions is necessary, check and change these data if necessary.

EDGE ANGL	Angle of the cutting edge. At the case that it was set to the value over than 90 degrees, cutting edge compensation will be done automatically. Into details, refer to III.1 BAR MACHINING descriptions. Parameter No.9809 value is automatically set into this data at initially inputting this process.
NOSE ANGLE	Angle of the tool tip, its default value can be set by parameter. Parameter No.9810 value is automatically set into this data at initially inputting this process.
RESE.AMNT	Travel amount in X-axis(OUTER/INNER : diameter) or Z-axis(FACE : radius) for retraction after cutting.
RELEASE	Type of tool positioning after cutting. Default value is [STNDRD]. [STNDRD] The tool is retracted after cutting along the inputted figure. [RAPID] The tool is retracted immediately after cutting.
APROCH X/Z	X/Z coordinate of approaching intermediate point.
COOLANT	Coolant specification at playback. Choose from the following soft-key menu. Default value is [ON]. [ON] : (M8) [OFF] : (M9)
SPDL GEAR	Spindle gear at playback. Choose from the following soft-key menu. Default value is [AUTO]. [AUTO] [LOW] [MID1] [MID2] [HIGH]


6.3 INPUTTING FIGURE DATA (OTHER THAN BAR MACHINING)

After inputting necessary process data, a cursor moves into Figure Data Window, and then, an operator can enter figure data through key-board.

For figure data used in cycle cutting except for Bar machining, specify the necessary figure data such as start point or end point that are required for cycle cutting.

Use the numeric keys and the INPUT key to enter data.

Example) Figure data for Threading



START X/Z

X or Z coordinate of thread start point.

END X/Z

X or Z coordinate of thread end point.

6.4 INPUTTING CONTOUR FIGURE DATA (BAR MACHINING)

For the figure data used in Bar machining, specify the final contour figure.

When the coordinate of the figure end point is unknown, it can be calculated by inputting necessary data described on a blue print.

(1) Inputting Start Point

At the top of contour figure, enter Start Point figure data.
Figure data window

X	Z	;
---	---	---

START X/Z

Absolute coordinate of figure start point

(2) Selecting a figure type

A menu of figure type appears in soft-keys. Select a figure type by pushing the corresponding soft-key.

LINE	CW	CCW	ROUND	CHAMF	TANGNT				CALC.
------	----	-----	-------	-------	--------	--	--	--	-------

NOTE

As to Start Point figure data, different from other figure data such as line or circle whose data are inputted in a pop-up window, X and Z data are inputted in a figure data window directly.

(3) Inputting contour figure data

When a figure has been selected, a pop-up window for inputting contour figure data appears. Enter the data that is designated on the blue print.

Example) Contour figure data for Line

CONTOUR FORM (LINE)	
END POINT X	X=
END POINT Z	Z=
ANGLE	A=
OVERRIDE	P=


Soft-keys for figure data inputting pop-up window

				CAN				
--	--	--	--	-----	--	--	--	--

By pushing a [CAN], an operator can cancel the inputting of the current figure data, and can return to figure type selecting screen.

After inputting whole necessary contour figure data, by pushing a **INSERT**, a pop-up window for contour figure data is closed and inputted data are displayed in a figure data window as following example.

Example) Figure data window



NOTE

When **INSERT** has been pushed, necessary contour calculation is automatically done and end point coordinate of the corresponding figure is memorized internally and is displayed in a graphic window.

6.5 EDITING CONTOUR FIGURE DATA (BAR MACHINING)

After doing necessary editing operations following after each descriptions, by pushing a [CALC.], contour calculation for new contour figures will be done.

6.5.1 Changing Inputted Contour Figure Data

- (1) Move a cursor on the data to be changed in a figure data window.
- (2) At the time only numeric value to be changed, input only new numeric data, and push INPUT.
- (3) At the time both address and numeric value to be changed, input new address and numeric data, and push INPUT.

6.5.2 Inserting a new Contour Figure Data

If the inputted contour figure data were not enough for contour calculating, a warning message for it will be displayed and necessary data must be newly added.

- (1) Move a cursor on a contour figure data other than “ ; “ in a block that the data should be inserted newly in a figure data window.
- (2) Input a new “Address + Numeric data” and push INSERT.

NOTE

However, newly inserted contour figure data is limited to the one that is displayed in a pop-up window for contour figure data inputting.

If the other data is inputted, that inputting will be neglected.

6.5.3 Deleting a needless Contour Figure Data

If a needless contour figure data for calculating, it must be deleted.

- (1) Move a cursor on a contour figure data to be deleted.
- (2) Push a **DELETE**.
- (3) The message for confirming the operation.
To cancel the operation, push a **CAN**. To delete a data, push **DELETE** again.

6.5.4 Inserting a New Contour Figure

- (1) Move a cursor on the “ ; “ of the figure block to be followed by a new figure.
- (2) Select the figure type of a newly inserted figure.
- (3) A pop-up window for contour figure data inputting of the new figure is displayed.
- (4) Input necessary contour figure data.
- (5) Push **INSERT**.

6.5.5 Deleting a Contour Figure

- (1) Move a cursor on the “ ; “ or the left end address, figure type, of the figure block to be deleted.
- (2) Push **DELETE**.
- (3) The message for confirming the operation and the soft-keys similar to 6.5.3 are displayed. To cancel the operation, push **CAN**. To delete the figure, push **DELETE** again.

6.5.6 Changing a Figure

In order to change a figure type of the already inputted contour figure, after deleting the old figure block, insert a new figure block.

6.6 RECALL OF FIGURE DATA FOR ROUGHING AND FINISHING

On Bar machining process or Trapezoidal Grooving process, entered figure of Roughing or Finishing process can be recalled for next process.

When a cursor is positioned on a “Area” item, with keeping entered figure data, Roughing and Finishing can be changed as follows.

- Bar machining process
 - [BAR-F] Bar Roughing -> Bar Finishing
 - [BAR-R] Bar Finishing -> Bar Roughing

- Trapezoidal grooving
 - [GV-TRR] Trapezoidal Grooving Roughing -> Trapezoidal Grooving Finishing
 - [GV-TRF] Trapezoidal Grooving Finishing -> Trapezoidal Grooving Roughing

In the above case, in addition to the figure data, some data used for both roughing and finishing commonly are kept at the same time.

6.7 CHECKING CUTTING MOTIONS ON A GRAPHIC WINDOW

Contour figure (Bar machining) can be displayed graphically in a graphic window.

It is similar to the case of Guidance Cutting.

Into details, refer to the Chapter 4.

6.8 PLAYBACK MACHINING

Entered cycle motions can be executed in the form among of the following 2 types machining.

- One-shot playback machining
- Whole processes playback machining

These are similar to the case of Guidance Cutting. Into details, refer to the Chapter 4.

6.9 ONE-SHOT MACHINING SIMULATION OF A INPUTTING PROCESS

Entered cycle motion program can be checked by an one-shot playback machining simulation. And this is similar to the case of Guidance Cutting. Into details, refer to the Chapter 4.

7

EDITTING OF PLAYBACK MACHINING PROGRAMS

Besides editing inputted data or taught-in program at newly making a new machining process, it is possible to edit a playback machining program that was already saved.

7.1 CHANGING PROGRAM NAME

- 1) Push **RESET** key on a LCD/MDI keyboard.
- 2) Push [PROGRM] on an initial screen, then program list window appears.


PROGRAM LIST			
Program Number	Program Name (Max 20ch.)	Processing time (Max 99minutes)	Lastly modified date and time
0	:CIRCLE MACHINING	5M12S	1997/05/12 10:12
10	:LINE MACHINING	4M32S	1997/06/10 11:21

- 3) For changing a program name, move a cursor onto the program name field, and input program name through key-board, and push **INPUT**. The maximum character number of it is 20.

7.2 EDITING THE CONTENTS OF MACHINING PROCESS

By the following operations, an operator can select a program or process to be edited.

- 1) Push **RESET** key on a LCD/MDI keyboard.
- 2) Push [PROGRM] on an initial screen, then program list window appears.
- 3) Select a program to be edited by moving a cursor on a program list window, and push [EDIT], then process list window appears.



- 4) Select a process to be edited by moving a cursor on a process list window, and push [EDIT], then the process list is closed and selected program is displayed in a program window.
- 5) If necessary, modify the contents of machining process. As to the operations for each machining process, refer to the following corresponding explanations.

Guidance cutting 4.4 Editing Taught-in Blocks

Single cutting 5.4 Editing Taught-in Blocks
Cycle motions 6.3 Inputting Figure Data (Other than Bar
Machining)
 6.5 Editing Contour Figure Data (Bar
Machining)

- 6) Machining simulation by tool path drawing or one shot playback machining can be done, if necessary.
- 7) Push [SAVE] in order to replace the old process by the newly modified one. By pushing left end soft-key, this replacement is not done, and the newly modified process is canceled.
- 8) By pushing [SAVE] in the above case, a process list window appears again, and editing of other processes can be continued.
- 9) Push [RETURN], then a program list window is closed.

7.3 DELETING / COPYING A PROGRAM

On a program list window, deleting and copying of a program can be done.

7.3.1 Deleting a Program

- 1) Push **RESET** key on a LCD/MDI keyboard.
- 2) Push [PROGRM] on an initial screen, then program list window appears.
- 3) Select a program to be deleted by moving a cursor on a program list window, and push **DELETE**.
By this pushing, the message for confirming the operation is displayed.
To cancel the operation, push **CAN**. To delete a data, push **DELETE** again.

7.3.2 Copying a Program

- 1) Push **RESET** key on a LCD/MDI keyboard.
- 2) Push [PROGRM] on an initial screen, then program list window appears.
- 3) Select a program to be copied by moving a cursor on a program list window, and input a program number of newly made program, after then push [COPY].

7.4 PROCESS EDITING

7.4.1 Moving a Process

- 1) Push **RESET** key on a LCD/MDI keyboard.
- 2) Push [PROGRM] on an initial screen, then program list window appears.
- 3) Select a program to be edited by moving a cursor on a program list window, and push [EDIT], then process list window appears.
- 4) Move the cursor to the process immediately before the place where you want to move the process. Enter the number of the process to move with numeric keys and push [MOVE]. Then the process moves.
- 5) After moving a process, process number in a process list window will be renumbered automatically.

7.4.2 Copying a Process

- 1) Push **RESET** key on a LCD/MDI keyboard.
- 2) Push [PROGRM] on an initial screen, then program list window appears.
- 3) Select a program to be edited by moving a cursor on a program list window, and push [EDIT], then process list window appears.
- 4) Select a process to be copied by moving a cursor on a process list window, and push [COPY]. Then, this selected process is copied just after it.
- 5) After copying a process, process number in a process list window will be renumbered automatically.

7.4.3 Deleting a Process

- 1) Push **RESET** key on a LCD/MDI keyboard.
- 2) Push [PROGRM] on an initial screen, then program list window appears.
- 3) Select a program to be edited by moving a cursor on a program list window, and push [EDIT], then process list window appears.
- 4) Select a process to be deleted by moving a cursor on a process list window, and push **DELETE**.
By this pushing, the message for confirming the operation is displayed.
To cancel the operation, push **CAN**. To delete a data, push **DELETE** again.
- 5) After deleting a process, process number in a process list window will be renumbered automatically.

8

PLAYBACK MACHINING AND MACHINING SIMULATION

By using a playback machining program that was already saved, playback machining and machining simulation can be done.

8.1 PLAYBACK MACHINING

- 1) Push **RESET** key on a LCD/MDI keyboard.
- 2) Push [PROGRM] on an initial screen, then program list window appears.

PROGRAM LIST			
Program Number	Program Name (Max 20ch.)	Processing time (Max 99minutes)	Lastly modified date and time
0	:CIRCLE MACHINING 10:LINE MACHINING	5M12S 4M32S	1997/05/12 10:12 1997/06/10 11:21

- 3) Select the program for playback machining on a program list window by moving a cursor onto its program number field.
- 4) Push Playback Start button on a machine operator's panel or [EXEC.], and then the playback machining of the selected one will be started.


8.2 MACHINING SIMULATION

- 1) Push **RESET** key on a LCD/MDI keyboard.
- 2) Push [PROGRM] on an initial screen, then program list window appears.



8.2.1 Machining Simulation with Tool Path Drawing

Push [PATH] , then the following soft-keys are displayed.



[SPD UP]	Increase the machining simulation speed.
[SPD DW]	Reduce the machining simulation speed.
[PLOT]	Draw the machining figure entered in cycle cutting processes.
[HEAD]	Return to the top of this process, and initialize a workpiece.
[PROCES]	Start simulating the machining in units of processes. The output of M01 causes a single block stop. (To output M01 at the end of process, set a parameter No.9774#4(M1O) to 1)
[EXEC]	Start the continuous simulation drawing.
[SINGLE]	Cause a single block stop while continuous simulation is being executed. Or, starts single block simulation.

In order to return to the initial screen, push **RESET**, and then push left end soft-key, super return.

8.2.2 Machining Simulation with Solid Model Animated Drawing

Push [ANIMAT] , then the following soft-keys are displayed.



[SPD UP]	Increase the machining simulation speed.
[SPD DW]	Reduce the machining simulation speed.
[PLOT]	Draw the machining figure entered in cycle cutting processes over the workpiece figure.
[ROTATE]	Rotate the workpiece.
[CIRC]	Change the workpiece figure between full circle and 3/4 drawing.
[HEAD]	Return to the top of this process, and initialize a workpiece.
[PROCES]	Start simulating the machining in units of processes. The output of M01 causes a single block stop. (To output M01 at the end of process, set a parameter No.9774#4(M1O) to 1)
[EXEC]	Start the continuous simulation drawing.
[SINGLE]	Cause a single block stop while continuous simulation is being executed. Or, starts single block simulation.

8.2.3 Machining Simulation with Animated Drawing and Tool Path

Push [ANIMAT+PATH] , then the following soft-keys are displayed.



At this machining simulation mode, instead of tool path drawing, animated drawing for solid model cannot be done. So, soft-keys, [ROTATE] and [CIRC.] cannot be used.

As to other soft-keys, they are similar to 8.2.3.

In order to return to the initial screen, push **RESET**, and then push left end soft-key, super return.

9

SETTING DATA

Before creating a program in MANUAL GUIDE mode, data items such as Tool Data and Common Parameters must be set.

9.1 TOOL DATA

9.1.1 Tool File Window

By pushing a [TOOL], the tool file window is displayed.

TOOL NO.	TOOL FILE			GEOMETRY			WEAR			TIP
	X	Z	R	X	Z	R				
1	-10.000	-20.000	0.400	0.000	0.000	0.000	0.000	0.000	0.000	3
2	-11.000	-21.000	0.800	0.000	0.000	0.000	0.000	0.000	0.000	3
3	-12.000	-22.000	0.400	0.000	0.000	0.000	0.000	0.000	0.000	3
4	-20.000	-25.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0
5	-25.000	-26.000	0.200	0.000	0.000	0.000	0.000	0.000	0.000	0
6	-30.000	-27.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0
7	-35.000	-28.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0
8	-40.000	-30.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0
9	-35.000	-28.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0
10	-40.000	-30.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0
11	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0
12	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0
13	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0
14	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0
15	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0
16	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0

9.1.2 Operation of Tool File Window


[RETURN]	Close this tool file window.
Cursor keys	Move a cursor to vertically or horizontally.
INPUT, [INPUT]	Input a numeric data on a key-in buffer into a corresponding data and move a cursor to next data.
[+INPUT]	Input an added or subtracted (- inputted) value into a corresponding data and move a cursor to next data.

NOTE

As to the wear offset data, the following parameters are valid.
 Parameter No.5013: Maximum value of wear offset.
 Parameter No.5014: Maximum value of [+INPUT] data for wear offset.

9.1.3 Detail of Tool File Data

TOOL NO.	Commonly used for outputted T-code number and offset number.
GEOMETRY X/Z/R	X-axis, Z-axis and Nose-R geometry offset, and these are commonly used with ISO programming mode.
WEAR X/Z/R	X-axis, Z-axis and Nose-R wear offset, and these are commonly used with ISO programming mode.
TIP	Imaginary tool tip position, and it is commonly used with ISO programming mode.



9.2 MEASURING WORKPIECE COORDINATE SHIFT AMOUNT

By pushing a [PREST] in an initial screen, the setup guidance window for measuring workpiece coordinate shift amount appears.

⚠ WARNING

When measuring workpiece coordinate shift amount on the X-/Z-axis using this method, keep the spindle rotating, and push the tool against the end surface or periphery of the workpiece and cut it with a feedrate as low as possible, using such as handwheel. Also, be sure to keep the safety door of the machining station closed.

Refer to the applicable manual supplied by the respective machine tool builders for detailed operations. If you do not know how to use this measurement function, do not use it.


Use of this measurement method without a working knowledge of the operating procedure may bring about the death of, or a serious injury to, the user. Before starting the machine using the tool compensation function, carefully determine the direction of compensation and the compensation value, and ensure that the tool will not strike the workpiece or machine. Otherwise the tool or machine may be damaged or the operator may injured.

(1) Manual reference position return

First, manually return to the reference position. When reference position return has been performed previously, this is unnecessary.

(2) Workpiece shift amount preset window

In an initial screen, by pushing a [PRESET], a workpiece shift preset window as follows is displayed.



(3) Tool index operation

Move a cursor on a “Tool number”, input a tool number to be used for presetting workpiece shift amount, and push **INPUT**.

After then, on a machine operator’s panel, push a tool selecting button. By this operation, a turret rotates and selected tool is assigned for measuring workpiece shift amount.

At this time, push CSS OFF switch on machine operator’s panel and after then make a spindle rotate by pushing a spindle rotating button. This rotating speed can be changed by common parameter displayed in an initial screen.

(4) Measuring Z-axis workpiece shift amount

Move a tool and make touch it to the end face of a workpiece by rotating handwheel slowly. Then, push [Z-FACE] for teaching the end surface coordinate.

(5) Measuring X-axis workpiece shift amount

After releasing a tool from a workpiece, move tool and make the outer surface of a workpiece. At this time, in order to do measuring of next step precisely, cut a workpiece a little. After then, push [X-OUTR] for teaching the outer surface coordinate.

(6) Measuring diameter of cut workpiece and inputting

By using a measure such as calipers, measure a diameter amount of cut part by the above operations. Of course, before then, the spindle must be stopped by pushing a spindle stop switch.

Move a cursor on a “Diameter MX” part, input a measured diameter amount, and push **INPUT**.

By these operations, workpiece shift amount of X-axis is calculated and is displayed at a lower part of this window.

(7) Inputting end surface shift amount

In ordinary case, after moving a cursor on a “Shift Amount MZ” part, input “0” value and push **INPUT**. By some reason, if some shifting of end surface is needed, input the shifting amount value and push **INPUT**.

By these operations, workpiece shift amount of Z-axis direction is calculated and is displayed at a lower part of this window.

By pushing a [RETURN], this window can be closed.

NOTE

Operations for reading actual X and Z workpiece coordinate by pushing [Z-FACE] or [X-OUTR] can be done only one time. The reason for it is as follows.

Once measured a workpiece coordinate shift amount, workpiece coordinate value is changed according to the measured amount, so if the reading of workpiece coordinate value more than one time, the correct value will never be calculated correctly.




In order to avoid to measure workpiece coordinate more than one time, soft-key [Z-FACE] and [X-OUTER] will be disappear after operations for measuring.

By closing this measuring window or inputting a tool number again, measuring can be done again.



9.3 TOOL FORM FOR ANIMATED DRAWING

The tool form for animated drawing is automatically specified as follows.




9.3.1 General-Purpose Cutting Tools




9.3.2 Threading Tools




9.3.3 Grooving Tools




9.3.4 Center Drills




9.3.5 Drills




9.3.6 Taps




9.3.7 Reamers



9.3.8 Boring Tools



9.3.9 Round Nose Cutting Tools



10

CONVERTING MACHINING PROGRAM INTO NC PROGRAM

A machining program saved in the manual guide mode can be converted into an NC program with G-code, M-code and so on.

NOTE

- 1 This function is available when an optional function “Background editing” is added and the parameter No.9760#6(NCO) is set to 1.
- 2 While the program is being converted, no other operation such as background editing, manual movement or data setting can be performed.
- 3 When this function is available, editing B is validated. Two or more address (for example, X100. Z100.) can be edited at a time.
- 4 The program number of the converted NC program is always set to the number of the original program in manual guide format.

10.1 OPERATIONS FOR CONVERSION

- 1) Push **RESET** key on a LCD/MDI keyboard.
- 2) Push [PROGRM] on an initial screen, then program list window appears.
- 3) Select a program to be edited by moving a cursor on a program list window, and push [CNV NC], then the following soft-keys appears.



- 4) By pushing [EXEC], conversion to the NC program is started and the animated drawing is executed at the same time.
During the conversion, the “EDITING” message blinks at the bottom of screen, and it disappears when the operation ends.
During conversion, avoid changing the screen to another screen or performing other operations.

10.2 ALARMS DURING CONVERSION OF THE MACHINING PROGRAM INTO NC PROGRAM

While the machining program is being converted into the NC program, the machining program is running for check drawing. A P/S alarm may occur because of the contents of the machining program.

For the P/S alarms, see appendix II. which describes the alarms that may occur when the machining program is running. Then correct the machining program.

If the P/S alarm occurs during the conversion, the converted part of the machining program has already been stored in the tape memory area. To restart the conversion of the machining program, correct the erroneous part, delete the converted part, and perform conversion from the beginning.

The following alarms may occur while the conversion.

Alarm No.		Description
070	Cause	Insufficient tape memory area
	Action	<p>Take the following action depending on the condition:</p> <ol style="list-style-type: none"> 1) If another NC program is already registered and the remaining memory is insufficient for the program being currently converted. -> Save the registered NC program in the external memory unit via the reader/puncher interface, delete the program, and resume conversion. 2) If the entire reserved area is insufficient for the program being currently converted. -> The NC program area can be increased by setting parameters. However, this causes the manual guide program area to be reduced and all data items to be cleared temporarily.
072	Cause	The number of registered programs (it depends on an optional setting) exceeded.
	Action	Save some of the registered NC programs into the external memory unit via the reader/puncher interface, delete the programs, and resume conversion from the beginning.
073	Cause	An attempt was made to specify the same program number as that of a registered program.
	Action	Delete the registered NC program having the same number and resume conversion from the beginning.

11

OUTPUTTING / INPUTTING MACHINING PROGRAMS

A manual guide format program can be outputted to an external memory unit via the reader / puncher interface, and it can be inputted similarly.

NOTE

These outputting and inputting can be done under only EDIT mode, but depending on a machine or MTB, there is a case that the mode is changed to EDIT mode automatically at these operations. Into details, refer to the machine operating manual made by MTB.

11.1 OUTPUTTING MACHINING PROGRAMS

- 1) Push **RESET** key on a LCD/MDI keyboard.
- 2) Push [PROGRM] on an initial screen, then program list window appears.
- 3) By pushing a right end soft-key [+], the following soft-keys appears.



- 4) To output all machining program of manual guide format, push a [ALL-PN].
- 5) To output only one program, select a program to be outputted by moving a cursor on a program list window, and push a [PUNCH].
- 6) When the output of the machining program starts, the “OUTPUT” message blinks at the bottom of the screen. It continues to flash until the operation ends.

NOTE

If the output equipment is the FANUC Cassette, a new file is created immediately after the registered file.

11.2 INPUTTING MACHINING PROGRAMS

- 1) Push **RESET** key on a LCD/MDI keyboard.
- 2) Push [PROGRM] on an initial screen, then program list window appears.
- 3) By pushing a right end soft-key [+], the following soft-keys appears.




- 4) Using numeric keys, enter the number of the file containing the machining program to be read and push a [READ]. Reading of the machining program is started.
- 5) If the input equipment is other than the FANUC Handy File or its equivalent one, input 1 as a file number always.
- 6) When reading of the machining program starts, the “INPUT” message blinks at the bottom of the screen. It continues to flash until the operation ends.

III. TYPES OF CYCLE MOTIONS

1

BAR MACHINING (ROUGHING)




1.1 DETAIL OF PROCESS DATA

1.1.1 Process Data Window

BAR MACHINING (ROUGH)			
AREA	=	CUT ST Z	=
TOOL NUM.	=	FIN X	=
FEED/REV.	=	FIN Z	=
S-SPD/MIN	=	INFEED AM	=
S-DIRECT	=		
CUT ST X	=		

AREA Select from [OUTER]/[INNER]/[FACE]/[OUTER REVERS] / [INNER/REVERS]/[FACE REVERS]



TOOL NO.	Number of tool used for roughing bar machining
FEED/REV.	Cutting feedrate, and it can be changed to FEED/MIN. by pushing soft-key [FEED/MIN.].
S-SPD/MIN	Cutting speed, and it can be changed to REV/MIN. by pushing soft-key [REV/MIN.].
S-DIRECT	Spindle rotating direction. Select from [NORMAL] and [REVERS].
CUT ST X/Z	Coordinate of cutting start position. These are automatically set by inputting figure data.
FIN X	X direction amount of finishing.
FIN Z	Z direction amount of finishing.
INFEED AM	Infeed amount of the first cutting motion.


1.1.2 Supplemental Process Data in a Pop-up Window

EDGE ANGL =	COOLANT =
NOSE ANGL =	SPDL GEAR=
RESE.AMNT =	
RELEASE =	
APROCHX =	
APROCHZ =	

These supplemental process data are automatically set always, so in ordinary case, an operator need not to call this pop-up window excepting the case of checking these data.


EDGE ANGL

Angle of the cutting edge. In case of that it was set to the value less than 90 degrees, cutting edge compensation will be done automatically. Parameter No.9809 value is automatically set into this data at initially inputting this process.




NOSE ANGLE

Angle of the tool tip, its default value can be set by parameter. In the case of that pocket figure was inputted as contour figure, cutting back compensation will be done automatically. Parameter No.9810 value is automatically set into this data at initially inputting this process.



RESE.AMNT


Travel amount in X-axis(OUTER/INNER : diameter) or Z-axis(FACE : radius) for retraction after cutting.

**RELEASE**

Type of tool positioning after cutting. Default value is [STNDRD].

[STNDRD] The tool is retracted after cutting along the inputted figure.

[RAPID] The tool is retracted immediately after cutting.

**APROCH X**

X coordinate of approaching intermediate point.

APROCH Z

Z coordinate of approaching intermediate point.

COOLANT

Coolant specification at playback. Choose from the following soft-key menu. Default value is [ON].

[ON]

[OFF]

SPDL GEAR

Spindle gear at playback. Choose from the following soft-key menu. Default value is [AUTO].

[AUTO]

[LOW]

[MID1]

[MID2]

[HIGH]

1.2 DETAIL OF FIGURE DATA

In Bar machining, up to 30 figures can be specified for one process.

(1) Inputting Start Point

At the top of contour figure, Start Point figure data is placed always.
Figure data window)

X	Z	;
---	---	---

START X/Z

Absolute coordinate of figure start point

NOTE

As to Start Point figure data, different from other figure data such as line or circle whose data are inputted in a pop-up window, X and Z data are inputted in a figure data window directly.

(2) Selecting a figure type

A menu of figure type appears in soft-keys. Select a figure type by pushing the corresponding soft-key.

LINE	ARC ↖	ARC ↙	ROUND	CHAMF	TANGNT				CALC.
------	----------	----------	-------	-------	--------	--	--	--	-------

When a figure has been selected, a pop-up window for inputting contour figure data appears. Enter the data that is designated on the blue print.


(3) LINE

CONTOUR FORM (LINE)	
END POINT X	X=
END POINT Z	Z=
ANGLE	A=
OVERRIDE	P=

- | | |
|----------------------|---|
| END POINT X/Z | Absolute coordinate of figure end point |
| ANGLE | Angle of line from +Z-axis. A positive angle is clockwise direction from +Z-axis, and minus angle is counter clockwise direction. |
| OVERRIDE | This data is not used in roughing. |

(4) ARC (CW/CCW)

CONTOUR FORM (ARC CW)	
END POINT X	X=
END POINT Z	Z=
RADIUS	R=
CENTER X	I=
CENTER Z	K=
OVERRIDE	P=




END POINT X/Z Absolute coordinate of figure end point
RADIUS Radius of arc
CENTER X/Z Absolute coordinate of arc center
OVERRIDE This data is not used in roughing.

NOTE

No major arc can be entered. For bar machining, even a semicircle or major arc cannot be entered if that semicircle or minor arc extends over three or more quadrants.

(5) ROUND


CONTOUR FORM (ROUND)	
RADIUS	R=
OVERRIDE	P=



RADIUS Radius of Corner-R
OVERRIDE This data is not used in roughing.

(6) CHAMFER

CONTOUR FORM (CHAMF)	
CHAMFER	C=
OVERRIDE	P=



CHAMFER Chamfer amount
OVERRIDE This data is not used in roughing.

(7) TANGNT

Pushing [TANGNT] specifies that the next figure form a tangent to the previous figure (either figure must be a arc). For next figure, arc or line must be entered.

When, [TANGNT] is selected, "TANGNT" is displayed on a screen.

(8) CALC.

When a new contour figure is added at the end of a series of previously inputted figures, contour calculating is automatically done after pushing **INSERT**.


On the other hand, when some figures are changed after inputted and contour calculated, during data changing, there may be a case that some contradiction between changing figures.

By this reason, contour calculation at figure editing is done only at [CALC.] is pushed by an operator.


NOTE

In case of specifying contour figures, there are the following limitations according to the selected type of machining area.

- In case that machining area is Outer, Outer Reverse, Inner or Inner Reverse, contour figures must be monotonous change along the Z-axis.




- In case that machining area is Face or Face Reverse, contour figures must be monotonous change along the X-axis.




- As the following examples, in case of machining a face area in Bar machining, contour figures must be specified by 2 figures as follows.


Example 1)



Example 2)



Example 3)



(*) In these examples, it is not allowed to specify only a Line 1. It is necessary to specify Line 1 and Line 2.

1.3 DETAIL OF CONTOUR CALCULATION

A figure block, a part of a contour, with its end point not determined is said to be in the pending state. A pending figure block is drawn by dotted line.


In the pop-up window for inputting contour figure data, more data input items than required are provided. These data items are used to calculate the cross point with the immediately preceding pending figure block, and also calculate the end point. The pending state is then released.

NOTE

10 successive figure blocks can be specified as pending blocks.


(1) CHAMF / ROUND immediately after a start point

Immediately after CHAMF or ROUND, only LINE or ARC can be inputted.




(2) CHAMF / ROUND at the end of a contour

At the end of a contour, CHAMF or ROUND can be inputted. In this case, input a dummy figure block as a pending block. In this dummy block, input only angle data, with its end point pending.




(3) LINE


- (a) When the preceding figure block is not pending
- Only X is inputted
-> This line is determined as a vertical line.
 - Only Z is inputted
-> This line is determined as a horizontal line.
 - A and either X or Z are inputted
-> The end point which is not inputted is calculated.



- (b) When the preceding figure block specifying an arc is not pending, and TANGNT is specified.
- Either X or Z is inputted
-> The angle A is calculated automatically, and an end point is determined. If neither X nor Z is inputted, this line will be pending.



- (c) When the preceding figure block is pending, and TANGNT is not specified.
- Both X and Z, and A are inputted
-> The cross point between the preceding figure block is calculated.



When the preceding figure is an arc, the cross point selection request window is displayed. Input number data 1 or 2, then push **INSERT**.


- (d) When the preceding figure block is pending arc, and TANGNT is specified.

It is assumed that the radius and the center point coordinate (I,K) of arc have already inputted.

- (i) Only A is inputted

-> The tangential point selection request window is displayed. Input number data 1 or 2, then push **INSERT**


This line will be pending.



- (ii) Both X and Z are inputted

-> The tangential point selection request window is displayed. Input number data 1 or 2, then push **INSERT**


The end point of this line will be determined.



- (iii) A and either X or Z are inputted


-> The tangential point selection request window is displayed. Input number data 1 or 2, then push **INSERT**

The end point of this line will be determined.




If the positional relationship between the tangential point and the line is such that an inputted A conflicts with the inputted X or Z, a warning message is displayed to indicate that invalid data has been inputted.

- (iv) A and both X and Z are inputted
 -> The end point of the arc and line will be determined.
 The tangential point selection request window is not displayed.



(4) ARC


- (a) When the preceding figure block is not pending, and TANGNT is not specified
- I and K are inputted
 -> This arc will be pending.
 - X, Z and R are inputted, or
 - X, Z, I and K are inputted
 -> A minor arc will be determined.



NOTE

In the distance (radius) between the start point and center differs from the one between the end point and center, the figure displayed in a graphic window will differ from the actual form, and machining will not be performed correctly.


- (iv) Only R is inputted
 -> By specifying TANGNT and inputting a line with A = 180 degree and X coordinate as an immediately after figure, this arc can be determined.
 However, there are two possible tangential points, so one of them must be selected by inputting number data 1 or 2.



- (b) When the preceding figure block is not pending, and TANGNT is specified

- (i) X and Z are inputted


-> The radius is automatically calculated and this arc will be determined.



- (c) When the preceding figure block is pending (for which the start point has been determined), and TANGNT is not specified


- (i) R, I and K are inputted

-> The cross point selection request window is displayed. Input number data 1 or 2, then push INSERT. This arc will be pending.



- (ii) X, Z, I and K are inputted


-> The cross point selection request window is displayed. Input number data 1 or 2, then push INSERT. This arc will be determined.



- (d) When the preceding figure block is pending (for which the start point has been determined), and TANGNT is specified


(i) R, I and K are inputted

-> The tangential point is calculated, and this arc will be pending.



(ii) X, Z, I and K are inputted


-> The tangential point is calculated, and this arc will be determined.



(iii) R and X, Z are inputted

-> The tangential selection request window is displayed.

Input number data 1 or 2, but in this case, select a tangential point to define a minor arc.




- (e) When the preceding figure block "arc" is pending (for which the start point has been determined and only the R is to be inputted), and TANGNT is specified

In this case, the directions of two arcs must be the same.


- (i) R, X and Z are inputted


-> The tangential selection request window is displayed. Input number data 1 or 2, but in this case, select a tangential point to define a minor arc. This arc will be determined.



- (ii) R, I and K are inputted

-> A tangential point is calculated. This arc will be pending.



(5) Line tangential to two arcs

By inputting 3 successive figure as follows, Line (2) tangential to 2 arcs can be specified as the above drawing. The end points of (1) and (2) will be determined, and (3) will be pending.

Among the above 4 lines possibility, depending on the directions of 2 arcs, the line that makes a smooth connection to the arcs will be automatically selected.

1st figure ARC(1) :


I and K are inputted. (A start point is determined. This arc is pending.)

2nd figure LINE(2) :

No data.

3rd figure ARC(3) :

R, I and K are inputted.

(6) Arc that contacts to both crossing lines and arcs

By inputting 3 successive figure as follows, Arc (2) tangential to 2 lines or arcs can be specified as the above drawing. The end points of (1) and (2) will be determined, and (3) will be pending.

1st figure LINE(1) or ARC(1) :

Line that is pending (for which the start point has been determined), or

Arc that is pending (for which the start point has been determined)

2nd figure ARC(2) :


Only R is inputted.

3rd figure LINE(3) or ARC(3) :

Line with A, X and Z, or

Arc with R, I and K

(7) Arc that contacts to uncrossing line and arc



By inputting 3 successive figure as follows, Arc (2) tangential to line and arc , these 2 figures (1) and (3) do not cross, can be specified as the above drawing. The end points of (1) and (2) will be determined, and (3) will be pending.

Among the above 2 arcs possibility, the arc that makes a smooth connection to the line (1) and arc (3) will be automatically selected.

1st figure LINE(1) :

Line that is pending (for which the start point has been determined)


2nd figure ARC(2) :

Only R is inputted.

3rd figure ARC(3) :

Arc with R, I and K

(8) Arc that contacts to uncrossing 2 arcs



By inputting 3 successive figure as follows, Arc (2) tangential to 2 arcs , these 2 figures (1) and (3) do not cross, can be specified as the above drawing. The end points of (1) and (2) will be determined, and (3) will be pending.

Among 8 arcs possibility, depending on the directions of 2 arcs, the line that makes a smooth connection to the arcs will be automatically selected.

1st figure ARC(1) :

Arc with I and K, and it is pending (for which the start point has been determined)

2nd figure ARC(2) :


No data.

3rd figure ARC(3) :

Arc with R, I and K

2

BAR MACHINING (FINISHING)




2.1 DETAIL OF PROCESS DATA

2.1.1 Process Data Window

BAR MACHINING (FINISH)	
AREA	= CUT ST Z =
TOOL NUM.	=
FEED/REV.	=
S-SPD/MIN	=
S-DIRECT.	=
CUT ST X	=

AREA

Select from [OUTER]/[INNER]/[FACE]/[OUTER REVERS] / [INNER/REVERS]/[FACE REVERS]


TOOL NUM

Number of tool used for finishing bar machining
Cutting feedrate, and it can be changed to FEED/MIN. by pushing soft-key [FEED/MIN.]

FEED/REV.

Cutting speed, and it can be changed to REV/MIN. by pushing soft-key [REV/MIN.]

Cutting speed, and it can be changed to REV/MIN. by pushing soft-key [REV/MIN.]

S-SPD/MIN

Spindle rotating direction. Select from [NORMAL] and [REVERS].

S-DIRECT

X coordinate of cutting start position.

CUT POS X

Z coordinate of cutting start position.

CUT POS Z


2.1.2 Supplemental Process Data in a Pop-up Window

EDGE ANGL =	SP.GEAR=
NOSE ANGL =	
RESE AMNT =	
APPROACHX =	
APPROACHZ =	
COOLANT =	

These supplemental process data are automatically set always, so in ordinary case, an operator need not to call this pop-up window excepting the case of checking these data.


EDGE ANGL

Angle of the cutting edge, normally it is set automatically to 90 degrees. In the case of that it was set to the value less than 90 degrees, cutting edge compensation will be done automatically. Parameter No.9033 value is automatically set into this data at initially inputting this process.




NOSE ANGLE

Angle of the tool tip, its default value can be set by parameter. In the case of that pocket figure was inputted as contour figure, cutting back compensation will be done automatically. Parameter No.9034 value is automatically set into this data at initially inputting this process.



RESE.AMNT Travel amount in X-axis(OUTER/INNER : diameter) or Z-axis(FACE : radius) for retraction after cutting.



APROCH X	X coordinate of approaching intermediate point.
APROCH Z	Z coordinate of approaching intermediate point.
COOLANT	Coolant specification at playback. Choose from the following soft-key menu. Default value can be set by parameter. [ON] (M8) [OFF] (M9)
SPDL GEAR	Spindle gear at playback. Choose from the following soft-key menu. [AUTO] default [LOW] [MEDIUM 1] [MEDIUM 2] [HIGH]

2.2 DETAIL OF FIGURE DATA


In Bar machining (Finishing), up to 30 figures can be specified for one process, but there are cases that one arc may be counted as 2 figures.

As to contour figure data, they are similar to Bar machining (Roughing), so refer to Chapter 1. But only “OVERRIDE” and “DIRECTION” data are added as follows.

(1) LINE / ARC / CHAMFER / ROUND

Example of LINE)

CONTOUR FORM (LINE)	
END POINT X	X=.....
END POINT Z	Z=.....
ANGLE	A=.....
OVERRIDE	P=.....



END POINT X/Z	Similar to Bar machining (Roughing)
ANGLE	Similar to Bar machining (Roughing)
OVERRIDE	This datum is used for only Bar Finishing, an operator can set a feedrate used for finishing this figure only by selecting an override from 10% - 150% by 10% unit. And 100% means that the feedrate inputted in a process data window. By pushing [+10%] or [-10%], this data can be changed.

2.3 NECKING FIGURE INPUTTING OF DIN509-E, DIN509-F, AND DIN76

(1) Selecting a necking figure menu

During inputting figures for bar machining, the following menu of figure type appears in soft-keys.




By pushing a right end soft-key, menus for necking figure are displayed.



(2) DIN509-E

By pushing a [DIN509], grinding necking of DIN509-E type can be selected.



WIDTH Width of necking figure DIN509-E


DEPTH Depth of necking figure.

RADIUS Corner-R radius of necking figure.

By pushing a **INSERT** after inputting the above data according to the DIN509-E standard, this necking figure is converted to the group of necessary figures, lines and corner-R, and these generated figures are displayed in a figure window.

(3) DIN76

By pushing a [DIN76], threading necking of DIN76 type can be selected.




WIDTH Width of necking figure DIN76

DEPTH Depth of necking figure.

By pushing a **INSERT** after inputting the above data according to the DIN76 standard, this necking figure is converted to the group of necessary figures, lines and corner-R, and these generated figures are displayed in a figure window.

(4) DIN509-F

By pushing a [DIN509], necking for grinding of DIN509-E type can be selected.



WIDTH Width of necking figure DIN509-F

DEPTH Depth of necking figure.


RADIUS Corner-R radius of necking figure.

By pushing a **INSERT** after inputting the above data according to the DIN509-F standard, this necking figure is converted to the group of necessary figures, lines and corner-R, and these generated figures are displayed in a figure window.

NOTE

- 1 When inputting this necking figure, the end point coordinate (X, Z) of the figure just prior to it must be decided already. If it remains the pending status, warning message is displayed when inserting this necking figure.
- 2 After inputting a necking figure and being converted to several lines and corner-R figures, only figure data of them can be modified.

3 THREADING



3.1 DETAIL OF PROCESS DATA

3.1.1 Process Data Window


(1) GENERAL THREAD

TYPE = [GENERAL]

THREADING	
AREA	= CHAMFERNG
TOOL NUM.	= CUT AMUNT
S -SPD/MIN	= TYPE
S -DIRECT.	= METHOD
CUT ST X	= ANGLE
CUT ST Z	= LEAD

AREA

Select from [OUTER]/[INNER]



TOOL NUM

Number of tool used for threading

S-SPD/MIN

Cutting speed, and it can be changed to REV/MIN. by pushing soft-key [REV/MIN.]

S-DIRECT

Spindle rotating direction. Select from [NORMAL] and [REVERS].

CHAMFERNG

Select whether to perform chamfering by [ON] / [OFF]

[ON] : M- code for chamfer on (parameter No.9836) is outputted.

For the chamfering length, parameter No.5130 is used.

[OFF] : M- code for chamfer off (parameter No.9837) is outputted.

Depth of cut for the first pass.

CUT AMUNT

By pushing [CUT TIMES], the number of cuts can be selected.

[CUT AMUNT] : The number of cuts is determined from the depth of cut and the cutting method.

[CUT TIMES] : When the number of cuts is entered, threading is performed according to this value. This number of cuts includes the spark-out motions.

NOTE

- The maximum number of cuts is 999.
When zigzag cutting is selected, input an even number of cuts, excluding the numbers of spark-out motions. If an odd number is inputted, one extra cutting is done.

NOTE


- 2 Depending on the minimum depth of cut (parameter No.9833), inputted number may be greater than actually needed. In such a case, the actual number is reduced to a value below the inputted number.
Further more, inputted number may differ slightly from the actual number because of a degree of error in the calculation.

METHOD

Select from [SINGLE-AMNT], [BOTH-AMNT], [STRGHT-AMNT], [SINGLE-DPTH], [BOTH-DPTH] and [STRGHT-DPTH].

[SINGLE-AMNT]

Single edge cutting, constant cutting amount.




H = Thread height D = Depth of cut

u = Finishing amount

[BOTH-AMNT]

Zigzag cutting, constant cutting amount



$$d_{n-2} = D \sqrt{n-2}$$


$$d_{n-1} = (D\sqrt{n-2} + \sqrt{n})/2$$

$$d_n = D \sqrt{n}$$


NOTE

If the depth of cut becomes smaller than the minimum depth of cut (parameter No. 9833), the depth of cut is fixed to the minimum depth of cut.


[STRGHT-AMNT] Straight cutting, constant cutting amount.




[SINGLE-DPTH] Single edge cutting, constant cutting depth.



[BOTH-DPTH] Zigzag cutting, constant cutting depth.



[STRGHT-DPTH] Straight cutting, constant cutting amount.



ANGLE

Tool tip angle used for only GENERAL thread.
Parameter No.9835 value is automatically set. If it is 0, 60 is set.

LEAD

Thread lead. The least input increment is 0.0001mm or 0.000001inch.

(2) METRIC THREAD

TYPE = [METRIC]

THREADING	
AREA	= CHAMFERNG =
TOOL NUM	= CUT AMUNT =
S-SPD/MIN	= TYPE =METRIC
S-DIRECT	= METHOD =
CUT ST X	= LEAD =
CUT ST Z	=

Metric thread is performed according to the metric standard. Only straight threads can be made. All the data excepting “ANGLE” are same with the general thread. A thread angle of 60degrees is used for it.

(3) UNIFIED THREAD

TYPE = [UNIFIED]

THREADING	
AREA	= CHAMFERNG =
TOOL NUM	= CUT AMUNT =
S-SPD/MIN	= TYPE =UNIFI
S-DIRECT	= METHOD =
CUT ST X	= NUM/INCH =
CUT ST Z	=

Unified thread is performed according to the unified thread standard. Only straight threads can be made. All the data excepting “THRD/INCH” (replaced with “LEAD”) are same with the general thread. A thread angle of 60degrees is used for it.

NUM/INCH Number of thread per inch. The least input increment is 0.1.

(4) PT THREAD

TYPE = [PIPE-T]

THREADING	
AREA	= CHAMFERNG =
TOOL NUM	= CUT AMUNT =
S-SPD/MIN	= TYPE =PIPE-T
S-DIRECT	= METHOD =
CUT ST X	= NUM/INCH =
CUT ST Z	=

PT thread is performed according to the pipe-taper thread standard. Only tapered threads with a slant angle of 1.7899 degrees can be made. All the data are same with the unified type thread. A thread angle of 55degrees is used for it.

When an external tapered (male) thread figure, the end face of the workpiece represents the minimum diameter section. With an internal tapered (female) thread figure, the end face of the workpiece represents the maximum diameter section.

(5) PF THREAD

TYPE = [PIPE-F]

THREADING		
AREA	=	CHAMFERNG
TOOL NUM	=	CUT AMUNT
S-SPD/MIN	=	TYPE
S-DIRECT	=	METHOD
CUT ST X	=	NUM/INCH
CUT ST Z	=	

PF thread is performed according to the PF thread standard. Only straight threads can be made. All the data are same with the PT type thread. A thread angle of 55degrees is used for it.

NOTE


All the thread of metric and unified are shaped differently depending on whether they are external threads or internal threads, however, the above functions regard figure data as being identical.

3.1.2 Supplemental Process Data in a Pop-up Window

MLTI	=	APPROARCHX=
HIGHT	=	APPROARCHZ=
SPARK OUT	=	COOLANT =
FINISHING	=	SP.GEAR =
CLEAR X	=	
CLEAR Z	=	

These supplemental process data are commonly used for the above 5 types of threads, and automatically set always, so in ordinary case, an operator need not to call this pop-up window excepting the case of checking these data.

MULTI. Number of thread at multiple thread screw. Initial value is 1.



HIGHT

Thread height. It is automatically calculated from the parameter below when the LEAD(THRД/INCH) is inputted.

- 1.General thread : Parameter No.9832
- 2.Metri/unified thread : Parameter No.9838
- 3.PT/PF thread : Parameter No.9839

SPARK OUT

Number of finishing operations to be done. Initial value is 1.

FINISHING

Finishing amount. It is automatically preset by the value of parameter No.9834.

CLEAR X

Clearance along the X-axis in threading. It is automatically preset by the value of parameter No.9830.

CLEAR Z

Clearance along the Z-axis in threading, and it means the distance required for the spindle to reach a stable speed. It is automatically preset by the value of parameter No.9831.

APPROACH X X coordinate of approaching intermediate point.

APPROACH Z Z coordinate of approaching intermediate point.

COOLANT Coolant specification at playback. Choose from the following soft-key menu. Default value is [ON].

[ON] (M8)

[OFF] (M9)

SPDL GEAR

Spindle gear at playback. Choose from the following soft-key menu. Default value is [AUTO].

[AUTO]

[LOW]

[MID1]

[MID2]


[HIGH]

3.2 DETAIL OF FIGURE DATA

(1) GENERAL THREAD

START X	=
START Z	=
END X	=
END Z	=


START X / Z X and Z Coordinate of a threading start point.
END X / Z X and Z Coordinate of a threading end point.



(2) METRIC THREAD

THRED-DIA	=
START Z	=
END Z	=

THRED-DIA Thread diameter(D).
START Z Z Coordinate of a threading start point(ZS).
END Z Z Coordinate of a threading end point(ZE).



(3) UNIFIED THREAD


THRED-DIA	=
START Z	=
END Z	=

THRED-DIA**START Z****END Z**

Thread diameter(D).

Coordinate of a threading start point(ZS).

Coordinate of a threading end point(ZE).


**(4) PT THREAD**

START X	=
START Z	=
END Z	=

START X / Z**END Z**

X and Z Coordinate of a threading start point(ZS).

Z Coordinate of a threading end point(ZE).



(5) PF THREAD

THRED-DIA	=
START Z	=
END Z	=

THREAD-DIA


Thread diameter(D).

START Z


Coordinate of a threading start point(ZS).

END Z

Coordinate of a threading end point(ZE).



4 GROOVING




4.1 DETAIL OF PROCESS DATA

4.1.1 Process Data Window

GROOVING	
AREA	CUT ST Z =
TOOL NUM.	TOOL WIDT =
FEED/REV	STEP AMNT =
S-SPD/MIN	DWELL =
S-DIRECT.	
CUT ST X	

AREA

Select from [OUTER]/[INNER]/[FACE]



TOOL NUM

Number of tool used for grooving

FEED/REV.

Cutting feedrate, and it can be changed to FEED/MIN. by pushing soft-key [FEED/MIN.].

S-SPD/MIN

Cutting speed, and it can be changed to REV/MIN. by pushing soft-key [REV/MIN.].

S-DIRECT

Spindle rotating direction. Select from [NORMAL] and [REVERS].

CUT ST X

X coordinate of an point before groove part machining is started.

CUT ST Z

Z coordinate of an point before groove part machining is started.

TOOL WIDTH

Width of grooving tool at cutting edge.

STEP AMNT

Depth of each cutting motion.

DWELL

Dwell at the bottom of a groove in roughing.

In normal grooving, semi-finish machining is carried out. But, by setting the parameter 9772<REN> to 1, it is not carried out. About the details of this parameter, see Appendix A "Parameters."

4.1.2 Supplemental Process Data in a Pop-up Window

APPROARCHX =
APPROARCHZ =
COOLANT =
SP.GEAR =

These supplemental process data are automatically set always, so in ordinary case, an operator need not to call this pop-up window excepting the case of checking these data.


APPROACH X	X coordinate of approaching intermediate point.
APPROACH Z	Z coordinate of approaching intermediate point.
COOLANT	Coolant specification at playback. Choose from the following soft-key menu. Default value is [ON].
	[ON] (M8)
	[OFF] (M9)
SPDL GEAR	Spindle gear at playback. Choose from the following soft-key menu. Default value is [AUTO].
	[AUTO]
	[LOW]
	[MID1]
	[MID2]
	[HIGH]

4.2 DETAIL OF FIGURE DATA


GRV.WIDTH =
GRV.DEPTH =
PITCH =
GRV NUM =
GRV ST X =
GRV ST Z =
GRV END X =
CHAMFER =

GRV.WIDTH	Width of a groove to be machined.
GRV.DEPTH	Depth (radius value) of a groove to be machined. By pushing a [GRV.DIA], absolute X(Z in FACE) coordinate of the groove bottom can be specified.
GRV ST X / Z	X or Z coordinate of a point where grooving starts.
GRV END X	X coordinate of the end point of a groove. This data is necessary only at the depth of a groove is different. If no value is inputted into this data item, depth of start point end point becomes equal. At end face grooving, "GRV END Z" is displayed and Z coordinate must be inputted.
CHAMFER	Chamfer amount of a groove.


(1) OUTER



(2) INNER




(3) FACE


**PITCH**

Distance between grooves when grooves of the same figure are machined at regular intervals.

- 1) PITCH < 0




- 2) PITCH > 0

**NUMBER**

Number of grooves when more than one groove are to be machined at regular intervals. 1 is set as the default value.

5


TRAPEZOIDAL GROOVING (ROUGHING AND FINISHING)



5.1 DETAIL OF PROCESS DATA


5.1.1 Process Data Window for Roughing

GROOV TRAPEZOID ROUGH			
AREA	=	STEP AMNT	=
TOOL NUM.	=	DWELL	=
FEED/REV	=	FINISH X	=
S-SPD/MIN	=	FINISH Z	=
S -DIRECT.	=	PITCH	=
TOOL WIDT	=	GRV NUM	=




TOOL NUM	Number of tool used for grooving
FEED/REV.	Cutting feedrate, and it can be changed to FEED/MIN. by pushing soft-key [FEED/MIN.].
S-SPD/MIN	Cutting speed, and it can be changed to REV/MIN. by pushing soft-key [REV/MIN.].
TOOL WIDTH	Width of grooving tool at cutting edge.
STEP AMNT	Depth of each cutting motion.
DWELL	Dwell at the bottom of a groove in roughing.
FINISH X	X direction amount of finishing.
FINISH Z	Z direction amount of finishing.
PITCH	Distance between grooves when grooves of the same figure are machined at regular intervals.

1) PITCH < 0



2) PITCH > 0



NUMBER	Number of grooves when more than One groove are to be machined at regular intervals.
---------------	--

5.1.2 Process Data Window for Finishing

GROOV TRAPEZOID FINISH			
AREA	=	CUT ST Z	=
TOOL NUM.	=	TOOL WIDT	=
FEED/REV	=	PITCH	=
S-SPD/MIN	=	GRV NUM	=
S -DIRECT.	=		
CUT ST X	=		

CUT ST X

X coordinate of an point before groove part machining is started. In roughing process, this data item is displayed in a detailed data window.

CUT ST Z

Z coordinate of an point before groove part machining is started. In roughing process, this data item is displayed in a detailed data window.

As to the data item other than the above, they are similar to roughing.

5.1.3 Supplemental Process Data in a Pop-up Window for Roughing

CUT ST X =
CUT ST Z =
APPROARCHX=
APPROARCHZ=
COOLANT =
SP.GEAR =

These supplemental process data are automatically set always, so in ordinary case, an operator need not to call this pop-up window excepting the case of checking these data.

CUT ST X	X coordinate of a point before groove part machining is started.
CUT ST Z	Z coordinate of a point before groove part machining is started.
APPROACH X	X coordinate of approaching intermediate point.
APPROACH Z	Z coordinate of approaching intermediate point.
COOLANT	Coolant specification at playback. Choose from the following soft-key menu. Default value is [ON].
	[ON] (M8)
	[OFF] (M9)
SPDL GEAR	Spindle gear at playback. Choose from the following soft-key menu. Default value is [AUTO].
	[AUTO]
	[LOW]
	[MID1]
	[MID2]
	[HIGH]

5.1.4 Supplemental Process Data in a Pop-up Window for Finishing

APPROARCHX=
APPROARCHZ=
COOLANT =
SP.GEAR =

Excepting that cutting start point data are moved to the process window, other data item are similar to roughing.

5.2 DETAIL OF FIGURE DATA

START X	=	POINT 3 X	=
START Z	=	POINT 3 Z	=
POINT 1 X	=	CORNER R	=
POINT 1 Z	=	POINT 4 X	=
CORNER R	=	POINT 4 Z	=
POINT 2 X	=	CORNER R	=
POINT 2 Z	=	END X	=
CORNER R	=	END Z	=

START X / Z Coordinate of a point where grooving starts.

POINT 1 to 4 X / Z X and Z coordinates of the corners of a trapezoidal groove shown below.

NOTE


The bottom figure of a trapezoidal groove must be parallel to Z-axis (OUTER and INNER groove) or X-axis (FACE groove). In other word, when OUTER or INNER groove is specified, the X coordinate of point 2 and 3 must be same, and when FACE groove is specified, the Z coordinate of them must be same.

CORNER R 1 to 4 Corner-R radius of each point 1 to 4. These data items can be changed to chamfering figure by pushing a [CHAMF].


CHAMFER 1 to 4 Chamfer amount for each point 1 to 4.

END X / Z X and Z coordinates of the end point of a trapezoidal groove shown below.


(1) OUTER



(2) INNER




(3) FACE




6

CENTER DRILLING / DRILLING / REAMING / BORING / TAPPING


(1) CENTER DRILLING




(2) DRILLING




(3) REAMING



(4) BORING



(5) TAPPING



6.1 DETAIL OF PROCESS DATA

6.1.1 Process Data Window

(1) CENTER DRILLING

CENTER DRILLING			
TOOL NUM	=	HOLE DIA	=
FEED/MIN	=	START Z	=
REV/MIN	=	DEPTH	=
S-DIRECT	=	DWELL	=
CUT ST X	=		
CUT ST Z	=		

TOOL NUM	Number of tool used for center drilling
FEED/MIN	Feed amount in center drilling, and it can be changed to FEED/REV by pushing a [FEED/REV].
REV/MIN	Spindle rotating speed.
S-DIRECT	Spindle rotating direction. Select from [NORMAL] and [REVERS].
CUT ST X	X-coordinate of a point where machining starts
CUT ST Z	Z-coordinate of a point where machining starts
HOLE DIA	Hole diameter or tool nominal diameter. This datum is used for only animated drawing.
START Z	Absolute Z-coordinate of hole start point
DEPTH	Depth of hole. By pushing [END Z], absolute Z-coordinate of hole end point can be selected.
DWELL	Dwell time at hole end point


(2) DRILLING

DRILLING			
TOOL NUM	=	HOLE DIA	=
FEED/MIN	=	START Z	=
REV/MIN	=	DEPTH	=
S-DIRECT	=	CUT DEPTH	=
CUT ST X	=	DWELL	=
CUT ST Z	=	PATTERN	=


TOOL NUM	Number of tool used for drilling
FEED/MIN	Feed amount in drilling, and it can be changed to FEED/REV by pushing a [FEED/REV].
REV/MIN	Spindle rotating speed.
S-DIRECT	Spindle rotating direction. Select from [NORMAL] and [REVERS].
CUT ST X	X-coordinate of a point where machining starts
CUT ST Z	Z-coordinate of a point where machining starts
HOLE DIA	Hole diameter or tool nominal diameter. This datum is used for only animated drawing.

START Z	Absolute Z-coordinate of hole start point
DEPTH	Depth of hole.
	By pushing [END Z], absolute Z-coordinate of hole end point can be selected.
CUT-DPTH	Depth of first cut in peck drilling [DEEP HO;E] or high-speed peck drilling [RAPID DEEP] (parameter 9853 : DRILCF)
DWELL	Dwell time at hole end point
PATTERN	Drilling type Select from [DRILL], [DEEP HOLE] and [RAPID DEEP].


1.[DRILL]



2.[DEEP HOLE]



3.[RAPID DEEP]




NOTE

The above return amount can be set in a detail data window.

(3) REAMING

REAMING	
TOOL NUM	= HOLE DIA =
FEED/MIN	= START Z =
REV/MIN	= DEPTH =
S-DIRECT	= CHAMF-LNG =
CUT ST X	= DWELL =
CUT ST Z	=


TOOL NO	Number of tool used for reaming
FEED/MIN	Feed amount in reaming, and it can be changed to FEED/REV by pushing a [FEED/REV].
REV/MIN	Spindle rotating speed.
S-DIRECT	Spindle rotating direction. Select from [NORMAL] and [REVERS].
HOLE DIA	Hole diameter or tool nominal diameter. This datum is used for only animated drawing.
START Z	Absolute Z-coordinate of hole start point
DEPTH	Depth of hole. By pushing [END Z], absolute Z-coordinate of hole end point can be selected.
CHAMF-LNG	Cutting-lip length of a reamer at cutting start (parameter 9054 : RIMKLN)
	
DWELL	Dwell time at hole end point
CUT ST X	X-coordinate of a point where machining starts
CUT ST Z	Z-coordinate of a point where machining starts

(4) BORING

BORING	
TOOL NUM	= HOLE DIA =
FEED/MIN	= START Z =
REV/MIN	= DEPTH =
S-DIRECT	= SHIFT =
CUT ST X	= DWELL =
CUT ST Z	=

TOOL NUM	Number of tool used for boring
FEED/MIN	Feed amount in boring, and it can be changed to FEED/REV by pushing a [FEED/REV].
REV/MIN	Spindle rotating speed.
S-DIRECT	Spindle rotating direction. Select from [NORMAL] and [REVERS].
HOLE DIA	Hole diameter of boring cutting

START Z	Absolute Z-coordinate of hole start point
DEPTH	Depth of hole.
	By pushing [END Z], absolute Z-coordinate of hole end point can be selected.
DWELL	Dwell time at hole end point
SHIFT	Shift amount for relief motion in boring (parameter 9858 : BRSHFT)



CUT ST X	X-coordinate of a point where machining starts
CUT ST Z	Z-coordinate of a point where machining starts

(5) TAPPING

TAPPING	
TOOL NO.	= HOLE DIA =
FEED/MIN	= START Z =
REV/MIN	= DEPTH =
S-DIRECT	= PITCH =
CUT ST X	= DWELL =
CUT ST Z	= TAP TYPE =

TOOL NUM	Number of tool used for tapping
FEED/MIN	Feed amount in tapping, and it can be changed to FEED/REV by pushing a [FEED/REV]. This datum is automatically calculated when a pitch datum mentioned later is inputted.
REV/MIN	Spindle rotating speed.
S-DIRECT	Spindle rotating direction. Select from [NORMAL] and [REVERS].
HOLE DIA	Hole diameter or tool nominal diameter. This datum is used for only animated drawing.
START Z	Absolute Z-coordinate of hole start point
DEPTH	Depth of hole. By pushing [END Z], absolute Z-coordinate of hole end point can be selected.
PITCH	Pitch of a tapping tool
DWELL	Dwell time at hole end point
TAP TYPE	Kind of tapping motion, rigid tapping or conventional tapping. Select from [RIGID] or [NORMAL].
CUT ST X	X-coordinate of a point where machining starts
CUT ST Z	Z-coordinate of a point where machining starts

6.1.2 Supplemental Process Data in a Pop-up Window

These supplemental process data are automatically set always, so in ordinary case, an operator need not to call this pop-up window excepting the case of checking these data.

(1) CENTER DRILLING

APROCH X =
APROCH Z =
COOLANT =
SPDL GEAR =

APPROACH X	X coordinate of approaching intermediate point.
APPROACH Z	Z coordinate of approaching intermediate point.
COOLANT	Coolant specification at playback. Choose from the following soft-key menu. Default value is [ON].
	[ON] (M8)
	[OFF] (M9)
SPDL GEAR	Spindle gear at playback. Choose from the following soft-key menu. Default value is [AUTO].
	[AUTO]
	[LOW]
	[MID1]
	[MID2]
	[HIGH]

(2) DRILLING [DRILL]

ST FEED =
ST CLEAR =
APROCH X =
APROCH Z =
COOLANT =
SPDL GEAR =

ST FEED	Cutting feedrate override at the start of cutting (parameter 9050 : STFECF) The cutting feedrate is calculated as follows. Feedrate = (FEED/MIN or FEED/REV) X (STFECF) / 100
ST CLEAR	Clearance (distance between the tool tip and tool shoulder) at the start of cutting. The tool cuts the workpiece by the above feedrate from a point distanced from the cutting start point by an amount equal to this clearance. This clearance is calculated as follows. Clearance = (HOLE DIA) / (2 X Tan (nose angle/2)) Nose angle = parameter 9083 : DRLANGL
APPROCH X	Similar to center drilling
APPROCH Z	Similar to center drilling.
COOLANT	Similar to center drilling.
SPDL GEAR	Similar to center drilling

(3) DRILLING [DEEP HOLE] / [RAPID DEEP]

DPTH DCRS =	APROCH Z =
RET AMNT =	COOLANT =
MIN DEPTH =	SPDL GEAR =
ST FEED =	
ST CLEAR =	
APPROCH X =	

DPTH DCRS	Decrement of the depth of cut for peck or high-speed peck drilling. The depth of cut is reduced by this for each cut. (parameter 9850 : DRLDEC)
RET AMNT	Amount of retraction for peck or high-speed peck drilling. (parameter 9851 : DRLRET)
MIN DEPTH	Minimum depth of cut. (parameter 9852 : DRLMIN)
ST FEED	Similar to drilling [DRILL].
ST CLEAR	Similar to drilling [DRILL].
APPROCH X	Similar to drilling [DRILL].
APPROCH Z	Similar to drilling [DRILL].
COOLANT	Similar to drilling [DRILL].
SPDL GEAR	Similar to drilling [DRILL].

(4) REAMING

RET SPEED =	
ST FEED =	
APPROCH X =	
APPROCH Z =	
COOLANT =	
SPDL GEAR =	

RET SPEED	Feedrate for retraction to the cutting start point upon the completion of reaming motion. This feedrate is calculated as follows. (parameter 9860 : RMBROV) Feedrate = (FEED/MIN or FEED/REV) X (RTRN FD) / 100
ST FEED	Similar to drilling [DRILL]
APPROCH X	Similar to center drilling.
APPROCH Z	Similar to center drilling.
COOLANT	Similar to center drilling.
SPDL GEAR	Similar to center drilling.

(5) BORING

APROCH X =
APROCH Z =
COOLANT =
SPDL GEAR =

APPROCH X Similar to center drilling.
APPROCH Z Similar to center drilling.
COOLANT Similar to center drilling.
SPDL GEAR Similar to center drilling.

(6) TAPPING


APROCH X =
APROCH Z =
COOLANT =
SPDL GEAR =

APPROCH X Similar to center drilling.
APPROCH Z Similar to center drilling.
COOLANT Similar to center drilling.
SPDL GEAR Similar to center drilling.


7

-X AREA CUTTING FUNCTION

In the cycle motions of MANUAL GUIDE, as shown in the following sample drawing, an operator enter cutting figures in the +X area, and its actual cutting motions are performed in the +X area too.



On the other hand, on the machine which has opposite double tool posts, there is a case that -X area cutting must be done as follows.



When the optional function “-X Area Cutting Function” is available, it is possible to select the cutting in $+X$ area or $-X$ area in the cycle motions excepting hole machining processes. Whether this optional function is available or not is depending on the machine construction, so please refer to the manual from the machine tool builder.

7.1 SELECTING OF -X AREA CUTTING

When the “-X Area Cutting Function” is available, in the detail data window of cycle motions excepting hole machining, as shown in the following, a data item “X AREA” is displayed, and it is used for selecting -X area cutting.

Example) Detail data window of Bar machining (Roughing)

EDGE ANGL =	APPROACHZ =
NOSE ANGL =	COOLANT =
RESE.AMNT =	SPDL GEAR =
RELEASE =	
X AREA =	
APPROACHX =	

X AREA Select from [+X] / [-X]. Default value is [+X].

In case of selecting the -X area cutting, an operator must enter a cutting figure of cycle motions in the +X area, and it is quite similar to the +X area cutting.

On case of performing the -X area cutting, an operator must select a tool suitable for its cutting motions in the -X area. This tool must have an opposite figure to the normal +X area cutting tool. Its tool data such as Wear/Geometry offset value and imaginary tool tip position must be set corresponding to an actual tool. For example, when the imaginary tool tip position is set to 3 on a normal +X area cutting tool, 2 must be set in its data for the -X area cutting tool.

NOTE

-X area cutting cannot be selected in a Guidance Cutting, Single Cutting and hole machining process.

7.2 DETAIL OF -X AREA CUTTING

When the -X area cutting is selected, the following transformation are done against the normal +X area cutting motions, and the result motions are performed.

(1) X-axis motion command

The signs of all motion commands of X-axis are reversed.

(2) G-codes

G-codes performed in cutting motions are reversed as follows.

G02 -> G03
G03 -> G02
G41 -> G42
G42 -> G41

(3) Machining simulation

According to the -X area cutting motions, a tool used for animated drawing is displayed in opposite form. And, drawing for cutting a workpiece which is accompanied with tool motion is performed in the -X area.

NOTE

When this optional function “-X Area Cutting Function” is available, animated drawing with a solid model cannot be used. As the soft-key menu for machining simulation, only [PATH] and [ANIMAT+PATH] are displayed, and [ANIMAT] is never displayed.

IV. SAMPLE OF PROGRAMMING

1

EXAMPLE OF CONTOUR FIGURE INPUTTING

⚠ WARNING


The following example of entering contour data is intend only to illustrate what automatic calculation of cross points is like when contour data is entered. The contour data given in the example may not be able to used in actual machining. If the machine is forced to run according to a program like the one shown above, the tool may bump against the workpiece, and the machine may be forced to perform unnatural machining, possibly causing damage to the tool and/or machine, and even injuries.

NOTE

The following examples show the input procedure for contours, assuming that the process data for bar machining has already been inputted.


1.EXAMPLE OF CONTOUR FIGURE INPUTTING SAMPLE OF PROGRAMMING B-63344EN/02

Sample 1




```
32      INPUT      (Start Point X)
0      INPUT      (Start Point Z)
[CIRCLE CW]
100     INPUT      (Radius)
INSERT
[TANGNT]
[CIRCLE CCW]
5      INPUT      (Radius)
52      INPUT      (Center X)
-29     INPUT      (Center Z)
INSERT
2      INPUT      (Cross Point Number)
INSERT
[TANGNT]
[LINE]
70      INPUT      (End Point X)
90      INPUT      (Angle)
INSERT
[LINE]
-70     INPUT      (End Point Z)
INSERT
[LINE]
80      INPUT      (End Point X)
INSERT
```

Sample 2




```
20      INPUT          (Start Point X)
0       INPUT          (Start Point Z)
[LINE]
-15     INPUT          (End Point Z)
INSERT
[CIRCLE CCW]
40      INPUT          (Radius)
100    INPUT          (Center X)
-15     INPUT          (Center Z)
INSERT
[TANGNT]
[CIRCLE CW]
14      INPUT          (Radius)
INSERT
[TANGNT]
[LINE]
70      INPUT          (End Point X)
-70    INPUT          (End Point Z)
180    INPUT          (Angle)
INSERT
2       INPUT          (Cross Point Number)
INSERT
[LINE]
80      INPUT          (End Point X)
INSERT
```

Sample 3




30	INPUT	(Start Point X)
0	INPUT	(Start Point Z)
[LINE]		
160	INPUT	(Angle)
INSERT		
[TANGNT]		
[CIRCLE CCW]		
70	INPUT	(End Point X)
-40	INPUT	(End Point Z)
10	INPUT	(Radius)
INSERT		
1	INPUT	(Cross Point Number)
INSERT		
[LINE]		
-50	INPUT	(End Point Z)
INSERT		
[LINE]		
80	INPUT	(End Point X)
INSERT		

Sample 4



30	INPUT	(Start Point X)
0	INPUT	(Start Point Z)
[CIRCLE CW]		
10	INPUT	(Radius)
INSERT		
[TANGNT]		
[LINE]		
70	INPUT	(End Point X)
-40	INPUT	(End Point Z)
160	INPUT	(Angle)
INSERT		
2	INPUT	(Cross Point Number)
INSERT		
[LINE]		
-50	INPUT	(End Point Z)
INSERT		
[LINE]		
80	INPUT	(End Point X)
INSERT		

Sample 5




```

0      INPUT          (Start Point X)
0      INPUT          (Start Point Z)
[CIRCLE CW]
7      INPUT          (Radius)
0      INPUT          (Center X)
-7     INPUT          (Center Z)
INSERT
[TANGNT]
[CIRCLE CCW]
110    INPUT          (Radius)
INSERT
[TANGNT]
[CIRCLE CCW]
10     INPUT          (Radius)
74     INPUT          (Center X)
-40    INPUT          (Center Z)
INSERT
1      INPUT          (Cross Point Number)
INSERT
[LINE]
70     INPUT          (End Point X)
-70    INPUT          (End Point Z)
180    INPUT          (Angle)
INSERT
2      INPUT          (Cross Point Number)
INSERT
[LINE]
80     INPUT          (End Point X)


```

Sample 6



```
0      INPUT          (Start Point X)
0      INPUT          (Start Point Z)
[CIRCLE CW]
25     INPUT          (Radius)
0      INPUT          (Center X)
-25    INPUT          (Center Z)
INSERT
[TANGNT]
[CIRCLE CCW]
35     INPUT          (Radius)
INSERT
[TANGNT]
[CIRCLE CW]
35     INPUT          (Radius)
80     INPUT          (Center X)
-120   INPUT          (Center Z)
INSERT
1      INPUT          (Cross Point Number)
INSERT
[TANGNT]
[LINE]
150   INPUT          (End Point X)
-150   INPUT          (End Point Z)
180   INPUT          (Angle)
INSERT
[LINE]
160   INPUT          (End Point X)
```

Sample 7



```


20      INPUT          (Start Point X)
0       INPUT          (Start Point Z)
[LINE]
165     INPUT          (Angle)
INSERT
[TANGNT]
[CIRCLE CCW]
40      INPUT          (End Point X)
-20     INPUT          (End Point Z)
10      INPUT          (Radius)
INSERT
1       INPUT          (Cross Point Number)
INSERT
[LINE]
-40     INPUT          (End Point Z)
INSERT
[CIRCLE CW]
8       INPUT          (Radius)
INSERT
[TANGNT]
[LINE]
60      INPUT          (End Point X)
-60     INPUT          (End Point Z)
170     INPUT          (Angle)
INSERT
2       INPUT          (Cross Point Number)
INSERT
[LINE]
-65     INPUT          (End Point Z)
INSERT

```

B-63344EN/02 SAMPLE OF PROGRAMMING 1.EXAMPLE OF CONTOUR FIGURE INPUTTING

```
[LINE]  
70      INPUT          (End Point X)  
INSERT  
[LINE]  
-80     INPUT          (End Point Z)  
INSERT  
[LINE]  
80      INPUT          (End Point X)  
INSERT
```

Sample 8



10	INPUT	(Start Point X)
0	INPUT	(Start Point Z)
[CHAMF]		
1	INPUT	(Chamfer)
INSERT		
[LINE]		
-5	INPUT	(End Point Z)
INSERT		
[CIRCLE CCW]		
10	INPUT	(Radius)
30	INPUT	(Center X)
-5	INPUT	(Center Z)
INSERT		
[TANGNT]		
[LINE]		
135	INPUT	(Angle)
INSERT		
2	INPUT	(Cross Point Number)
INSERT		
[TANGNT]		
[CIRCLE CW]		
8	INPUT	(Radius)
INSERT		
[TANGNT]		
[LINE]		
30	INPUT	(End Point X)
-30	INPUT	(End Point Z)

B-63344EN/02 SAMPLE OF PROGRAMMING 1.EXAMPLE OF CONTOUR FIGURE INPUTTING

170	INPUT	(Angle)
INSERT		
[CIRCLE CW]		
10	INPUT	(Radius)
INSERT		
[TANGNT]		
[LINE]		
40	INPUT	(End Point X)
-50	INPUT	(End Point Z)
180	INPUT	(Angle)
INSERT		
2	INPUT	(Cross Point Number)
INSERT		
[ROUND]		
10	INPUT	(Radius)
INSERT		
[LINE]		
70	INPUT	(End Point X)
110	INPUT	(Angle)
INSERT		
[LINE]		
-60	INPUT	(End Point Z)
INSERT		
[CIRCLE CW]		
20	INPUT	(Radius)
70	INPUT	(Center X)
-80	INPUT	(Center Z)
INSERT		
[TANGNT]		
[CIRCLE CW]		
10	INPUT	(Radius)
INSERT		
[TANGNT]		
[LINE]		
100	INPUT	(End Point X)
-75	INPUT	(End Point Z)
180	INPUT	(Angle)
INSERT		
1	INPUT	(Cross Point Number)
INSERT		
[LINE]		
110	INPUT	(End Point X)
INSERT		

V. SUPPLEMENT

1

CALCULATING INPUT DATA

1.1 OVERVIEW

Data can be input for each numeric data item on the MANUAL GUIDE screen with calculator-type arithmetic operations.

One of four dyadic fundamental operations (addition, subtraction, multiplication, and division) can be performed as an operation at a time. The result of an operation can be used as the first term of the next operation to perform as many operations as required for one numeric data input item.

The inputtable numeric data depends on the data format of the target numeric data item. If data smaller than the least input increment is input, processing such as round off is not performed and the data is ignored.

1.2 OPERATION

Use the following key operations for the arithmetic operations :

- | | | |
|--------------------|---|------------------|
| (1) Addition | : | 100.+200.[INPUT] |
| (2) Subtraction | : | 100.-200.[INPUT] |
| (3) Multiplication | : | 100.*20.[INPUT] |
| (4) Division | : | 100./10.[INPUT] |

The displayed result of an operation is not directly entered in the numeric data item. The operator must check the displayed result of an operation, then press [INPUT] to enter the result in the input data item.

Example)

210. - 65.3 + 1.25

Key input operation and displayed results of pressing the INPUT key for the above operation

- Key operation

2	1	0	.	-	6	5	.	3	INPUT	+	1	.	2	5	INPUT	INPUT
---	---	---	---	---	---	---	---	---	--------------	---	---	---	---	---	--------------	--------------

- Key-in buffer display

210.-65.3	START X
-----------	---------

(INPUT key)

144.7	START X
-------	---------

- (Key operation for the second operation)

144.7+1.25	START X
------------	---------


- (INPUT key)

145.95	START X
--------	---------

- (INPUT key)

The operation result (149.95) is input to the START X data item.

1.3 KEYS FOR ARITHMETIC OPERATIONS



2

USEFUL DISPLAY FUNCTIONS

2.1 BLANK FIGURE DATA DISPLAY IN THE PROGRAM LIST WINDOW

Blank figure data items can also be displayed in the program list window displayed by pressing soft-key [PRGRM], by parameter setting.

PROGRAM LIST				BLANK SIZE
PROGRAM (NUM.) USED/FREE				12/13
MEMORY (BLOCK) USED/FREE				112/255
01 : CIRCLE MACHINING	5M12S	1998/10/06	10:12	LENGTH 32.000
02 : LINEAR MACHINING	4M15S	1998/10/05	11:15	OUTER DIA 25.000
03 : DRILLING	2M10S	1998/10/01	10:20	INNER DIA 0.000
04 : OUTER ROUGH	6M15S	1998/10/02	11:15	REMOVAL 2.000
05 : GROOVING	3M22S	1998/10/06	10:12	
10 : TAPPING	1M35S	1998/10/07	11:15	
11 : THREADING	3M12S	1998/10/06	10:12	
15 : TEST-1	7M45S	1998/10/05	11:15	
18 : TEST-2	9M52S	1998/10/05	10:12	
20 : INNER MACHINING	6M35S	1998/10/05	11:15	

Blank figure data can be set for each machining program.


When the cursor moves to the next program, the blank figure data for the new program is also displayed. Pressing soft-key [WORK] moves the cursor to the blank figure data field to allow the operator to input required data. Pressing soft-key [PRGRM] moves the cursor back to the program list.

NOTE

- 1 To display the above blank figure data in the program list window, set bit 2 (BSZ) of parameter No. 9761 to 1.
- 2 To perform simultaneous bar machining and end facing with a value set for REMOVAL, be sure to specify a vertical line drawn from the start point (X0, Z0) as the first figure.

2.2 ALARM MESSAGE WINDOW

An alarm message window is displayed when soft-key [ALARM] is pressed on the MANUAL GUIDE screen or an alarm is issued during actual machining or animated drawing.



NOTE

To enable the above function of displaying the alarm message window, set bit 4 (AWD) of parameter No. 9761 to 1.

If an alarm is issued, the nature of the alarm can be checked on the MANUAL GUIDE screen and the alarm screen need not be displayed when this window is used.

2.3 VARIOUS TYPES OF CURRENT POSITION DISPLAY AND COORDINATE SYSTEM PRESET

Pressing soft-key [POS] can step the current position data displayed in the status indicator window from the absolute coordinates to the relative coordinates and machine coordinates.

When the relative coordinates are displayed, the X, Z, or C coordinate can be preset by the following operation:

Press the rightmost soft-key [+]. R [PRESET] is displayed.

Press address key X, Z, or C.

Use numeric keys to input a value to be preset.

Press [PRESET].

NOTE

To enable the current position display switch function and relative coordinate preset function above, set bit 1 (POS) of parameter No. 9846.

2.4 SOFT-KEY FOR ANIMATED DRAWING SCALING OPERATION

Soft-key [ZOOM] used for animated drawing scaling operation can be displayed on the first page containing various soft-keys for animated drawing, by parameter setting.

[<][SPD UP] [SPD DW] [PLOT] [ROTATE] [CIRC] [ZOOM]
[HEAD] [PROCES] [EXEC] [SINGLE][+]

Pressing [ZOOM] displays the following soft-keys to allow the operator to scale a drawing up. Pressing [DESIDE] executes scaleup operation, then the previous soft-keys are displayed again.

[<][SPD UP][SPD DW][PLOT][EXEC][]
[NORMAL][SCL UP][SCL DW][CANCEL][DECIDE][+]

NOTE

To display the above soft-key for scaling operation,
set bit 3 (ZOM) of parameter No. 9764 to 1.

2.5 DIRECT INPUT OF THE JOG FEEDRATE

Data item "JOG FED X/Z" can be displayed on the basic menu screen and guidance/single cutting screen to directly input the jog feedrate, by parameter setting.

The input data is temporarily stored as common parameter No. 9097 and is converted according to the increment system and data format, then is written as parameter No. 1423 for the jog feedrate.

When data is input directly as common parameter No. 9097, the corresponding data is written as parameter No. 1423 for the jog feedrate when the basic menu screen is displayed.

The valid data format and increment system are as follows:

When the parameter No.1402#4(JRV) is set to 0.

1mm/min. (at mm input)
0.1inch/min. (at inch input)

When the parameter No.1402#4(JRV) is set to 1.

0.01mm/rev. (at mm input)
0.001inch/rev. (at inch input)

NOTE

To enable the above jog feedrate input function, set bit 0 (JOG) of parameter No. 9846 to 1.

⚠ WARNING

- 1 After jog feedrate data is input, the feedrates related to all jog feed operations on the CNC are changed to the new input feedrate.
For this reason, the jog feedrate indicated on the machine operator's panel or in the machine operator's manual becomes unreliable. If you want to prevent this situation, be sure to disable this direct jog feedrate input function.
If you do not have enough skill and knowledge for machine operation, never perform this direct jog feedrate input operation. Otherwise the tool may strike the workpiece or machine, possibly breaking the tool or machine or injuring you.
- 2 If the input jog feedrate is very fast, the tool may strike the workpiece or machine, possibly breaking the tool or machine or injuring the operator.
For this reason, be sure to confirm, on the screen, that the input data is correct before moving the tool. Moreover, before actual move operation, move the tool by a very short distance at a time gradually with sufficient care and confirm that the tool moves at the correct feedrate.
If you do not have enough skill and knowledge for machine operation, never perform this direct jog feedrate input operation.

2.6 NC STATEMENT DISPLAY ON THE MACHINING SIMULATION SCREEN

The specified NC statements can be displayed on the machining simulation screen by parameter setting. This allows the operator to check the NC statements specified during conversion of NC statements or execution of a program.

NOTE

To enable the above NC statement display function, set bit 2 (NCD) of parameter No. 9847 to 1.

3


USEFUL FUNCTIONS FOR MACHINING PROCESSES


3.1 INCREMENTAL COORDINATE INPUT

Incremental values can be input for the following data in each machining below by parameter setting:

- Single Cutting
 - Coordinates of the end point in each block
 - Coordinates of the center of an arc
- Bar machining (Roughing, Finishing)
 - Coordinates of the end point of each figure
 - Coordinates of the center of an arc
- Threading
 - Coordinates of the end point of a thread
- Standard grooving
 - X coordinate (outer or inner surface) or Z coordinate (end face) of the end point of a groove
- Trapezoidal grooving (Roughing, Finishing)
 - Coordinates of each point other than the start point of a trapezoidal groove

Each incremental coordinate indicates the distance from the start point to the end point of a line or arc. Each incremental coordinate of the center of an arc indicates the distance from the start point of the arc.





Pressing soft-key [ABS/IN] can switch between absolute input (standard specification of the MANUAL GUIDE) and incremental input. The selected input format (absolute or incremental) is displayed on the title bar of the figure data window.

NOTE

Absolute input and incremental input cannot be specified together in one machining process. If absolute input is switched to incremental input or vice versa in one process, the format of all figure data in the process is changed to the newly selected input format with the input numeric values. In this case, because the figure data cannot be used as is, delete all input figures, then input them again.

The address of each coordinate in each block input in the incremental format in a single cutting process is indicated with "U" (X-axis) or "W" (Z-axis).

When coordinates are input in the incremental format in a bar machining process, the figure code of each figure is displayed in reverse video as shown in the example below:


< X30.0 Z -20. P100;

NOTE

To enable incremental input, set bit 4 (INC) of parameter No. 9764 to 1.

3.2 SUPPORT OF BACK TOOL POST LATHES

The MANUAL GUIDE supports a flatbed manual lathe, of which tool post is located between the workpiece and operator, in principle. By using the "back tool post lathe support function" (option function), the MANUAL GUIDE can also be used for a slant-bed lathe, of which tool post is located beyond the workpiece viewed from the operator.



NOTE

When this option function is installed, set the following parameters because the upward direction on the screen indicates the positive X direction in the coordinate system for the lathe:
Bit 5 (SRV) of parameter No. 9761 = 0 (The soft-key icon points up.)
Parameter No. 6510 = 14 (The upward direction on the screen indicates the positive X direction in the coordinate system of animated drawing.)

When this option is installed, all guidance drawings on the MANUAL GUIDE screen and input figures in the graphic window are displayed top side down to match the direction of the X-axis of the actual machine.

NOTE

For a lathe for which the MANUAL GUIDE is installed together with this option function, manual cutting such as guidance or single cutting may not be needed.

In this case, the following parameter can be set so that the related soft-keys for cutting are not displayed on the menus:

Bit 2 (NGS) of parameter No. 9762 = 1 (Soft-keys [GUIDNC] and [SINGLE] are not displayed.)

3.3 UNIDIRECTIONAL GROOVE CUTTING


In ordinary grooving, for both normal and trapezoidal grooves, the center of a groove is first cut with the tool, then the tool is moved right and left to cut the groove.

Unidirectional cutting can also be selected by parameter setting. In this case, an end face side of the workpiece to be grooved is first cut with the tool, then the tool is moved toward the chuck to cut the groove.

This cutting method can be used for suppressing vibrations which may be caused by the tool during heavy cutting.

NOTE

To use this unidirectional groove cutting, set bit 5 (G1W) of parameter No. 9764 to 1.



3.4 AUTOMATIC DIVISION OF TAUGHT-IN BLOCKS IN GUIDANCE CUTTING

In guidance cutting, a cutting motion whose end point is the tool position when a teach-in soft-key ([CUT]/[RAPID]) is pressed is stored as a motion block.

Each motion can also be stored as a block according to the following conditions by parameter setting:

- Switching between approach cutting and along cutting
- Direction of cutting in the handle or jog feed mode
- Axis along which the tool moves in the handle or jog feed mode

When soft-key [CUT] is pressed, all cutting motions stored as separate blocks are taught as cutting feed (G01, G02, or G03).

When soft-key [RAPID] is pressed, they are taught as rapid traverse (G00).

Up to 30 blocks of motions can be stored until the teach-in soft-key is pressed.

When this function is enabled, if the tool is moved simultaneously along two axes in the handle or jog feed mode, large blocks are stored at a time. Always move the tool along only one axis.

NOTE

- 1 To use automatic division of taught-in cutting motions, set bit 1 (TCA) of parameter No. 9762 to 1.
- 2 For auxiliary function teach-in, up to eight blocks of motions can continuously be stored, regardless of whether the above parameter is set.
- 3 The same block may be taught as multiple continuous blocks by handwheel operation. In this case, delete unnecessary blocks.

3.5 SPECIFICATION OF SEMIFINISHING FOR BAR MACHINING

Semifinishing only can be executed for bar machining by parameter setting.

The "ROUGH/SEMI" data item is displayed in the detail data window for bar machining (roughing) to allow the operator to select a cutting motion from the soft-key menu.

- [ROUGH] → Executes only roughing.
- [R+SEMI] → Executes roughing and semifinishing.
- [SEMI] → Executes only semifinishing.

NOTE

To use this semifinishing specification function, set bit 6 (SEM) of parameter No. 9761 to 1.

3.6 SAFE OPERATION FOR PROGRAM SELECTION

To prevent machining operation with a program erroneously selected by an operator error, only the specified program can be used for machining operation.

Move the cursor to a program to be used for machining in the program list window, then press soft-key [SELPR].

When soft-key [SELPR] is pressed, the screen changes to the machining simulation screen determined by the setting of bit 3 (SGR) of parameter No. 9847. When the Playback Start button on the operator's panel is pressed, playback machining starts.

If the Playback Start button is pressed without pressing soft-key [SELPR] after another program is selected in the program list window using the cursor, an alarm is issued and playback machining cannot be started.

NOTE

To enable the above function, set bit 7 (SPR) of parameter No. 9847 to 1.

3.7 REVERSE TAPPING

Reverse tapping can be performed by parameter setting. When this function is enabled, the M code indicating forward or reverse rotation is issued before tapping.

NOTE

The above function is enabled by setting bits 5 (MTM) and 4 (TTM) of parameter No. 9846. For details of the parameter setting, see Appendix A, "PARAMETERS." When bit 6 (G32) of parameter No. 9779 is set to 1, this function is disabled for tapping by turning.

When this function is enabled, the motion of each machining pattern is as follows.

(1) Forward tapping by turning :

When the parameter No.9779#6(G32) is set to 0.

```
:
(M8/M9);
G50 S_ ;
:
M(Forward spindle rotation tapping pre-command P9292); . . . (A)*
G97G99G40S_ T_ M(Forward spindle rotation command P9295);
G80;
(Movement to the cutting start point)
G99G84Z_ R0.F_ P_ ;
G80;
:
* Block (A) is output when a value is set for parameter No. 9292.
```

(2) Reverse tapping by turning :

When the parameter No.9779#6(G32) is set to 0.

```
:
(M8/M9);
G50 S_ ;
:
M(Reverse spindle rotation tapping pre-command P9293); . . . (A)*
G97G99G40S_ T_ M(Forward spindle rotation command P9295);
G80;
(Movement to the cutting start point)
G99G84Z_ R0.F_ P_ ;
G80;
:
```

NOTE

- 1 When bit 4 (TTM) of parameter No. 9846 is set to 0 or when the bit is set to 0 and parameter No. 9293 is not set, reverse rotation may be specified as the direction of rotation for tapping (in process data). In this case, P/S alarm, "3008 A WRONG TOOL SELECTED," is issued.
- 2 In reverse tapping, the reverse spindle rotation command is also issued at the bottom of the hole in the same way as in forward tapping. To prevent this command from being issued, the M code for the reverse spindle rotation tapping pre-command is output before a tapping command (G84 or G88) is issued to issue the reverse rotation command at the bottom of the hole. For this reason, set a signal to reverse the spindle rotation commands following this M code in the PMC ladder to make the system reverse the spindle rotation commands according to the signal. Make the PMC ladder cancel the signal at the time such as at the falling edge of the TAP signal (bit 5 (TAP) of F0001). Use the M code for the forward spindle rotation tapping pre-command as required.

(3) Forward rigid tapping by turning :**When the parameter No.9779#6(G32) is set to 0.**

;
 (M8/M9);
 G50 S_ ;
 G99G40T_ ;
 G80;
 (Movement to the cutting start point)

M(Spindle stop command P9294); (B1)
 or . . . (B)*

M(Forward spindle rotation tapping pre-commandP9292);
 . . . (B2)

S_ M(Rigid tapping mode command P5210);
 G99G84Z_ R0.F_ P_ ;
 G80;

;
 *(For block (B),

- Block (B1) is output when bit 4 (TTM) of parameter No. 9846 is set to 0.
- Block (B2) is output when bit 4 (TTM) of parameter No. 9846 is set to 1 and a value is set for parameter No. 9292. When no value is set for parameter No. 9292, no command is output.

(4) Reverse rigid tapping by turning :**When the parameter No.9779#6(G32) is set to 0.**

```

:
(M8/M9);
G50 S_ ;
G99G40T_ ;
G80;
(Movement to the cutting start point)
M(Reverse spindle rotation tapping pre-command P9293);
S_ M(Rigid tapping mode command P5210);
G99G84Z_ R0.F_ P_ ;
G80;
:

```

NOTE

When bit 4 (TTM) of parameter No. 9846 is set to 0 or when the bit is set to 0 and parameter No. 9293 is not set, reverse rotation may be specified as the direction of rotation for tapping. In this case, P/S alarm, "3008 A WRONG TOOL SELECTED," is issued.

(5) C-axis forward tapping by milling, even spacing

```

:
M(Milling axis stop command P9876);
(M8/M9);
M(Milling forward tapping pre-command P9088); . . . (C)*
G97G98G40S_ T_ M(Forward milling axis rotation command P9877)
G80;
(Movement to the cutting start point)
G98(G84/G88)_ ;
(Second figure specification)
:
(nth figure specification)
:

```

G80M(Milling axis stop command P9876);

* Block (C) is output when bit 5 (MTM) of parameter No. 9846 is set to 1 and a value is set for parameter No. 9088.

(6) C-axis reverse tapping by milling, even spacing

```

        :
        M(Milling axis stop command P9876);
        (M8/M9);
        M(Milling reverse tapping pre-command P9089);
        G97G98G40S_ T_ M(Forward milling axis rotation command P9877)
        G80;
        (Movement to the cutting start point)
        G98(G84/G88)_ ;
        (Second figure specification)
        :
        (nth figure specification)
        :
        G80M(Milling axis stop command P9876);
        :
    
```

NOTE

When bit 4 (TTM) of parameter No. 9846 is set to 0 or when the bit is set to 0 and parameter No. 9089 is not set, reverse rotation may be specified as the direction of rotation for tapping. In this case, P/S alarm, "3008 A WRONG TOOL SELECTED," is issued.

(7) C-axis forward tapping by milling, uneven spacing

```

        :
        M(Milling axis stop command P9876);
        (M8/M9);
        M(Milling forward tapping pre-command P9088); . . . (D)*
        G97G98G40S_ T_ M(Forward milling axis rotation command P9877)
        G80;
        (Movement to the cutting start point)
        G98(G84/G88)_ ;
        G80M(Milling axis stop command P9876);
        (Second figure specification)
        M(Milling forward tapping pre-command P9088); . . . (D)*
        M(Milling forward command P9877);
        G98(G84/G88)_ ;
        G80M(Milling axis stop command P9876);
        :
        (nth figure specification)
        M(Milling forward tapping pre-command P9088); . . . (D)*
        M(Milling forward command P9877);
        G98(G84/G88)_ ;
        G80M(Milling axis stop command P9876);
        :
*
```

* Block (D) is output when bit 5 (MTM) of parameter No. 9846 is set to 1 and a value is set for parameter No. 9088.

(8) C-axis reverse tapping by milling, uneven spacing

M(Milling axis stop command P9876);
(M8/M9);
M(Milling reverse tapping pre-command P9089);
G97G98G40S_ T_ M(Forward milling axis rotation command P9877)
G80;
(Movement to the cutting start point)
G98(G84/G88)_ ;
G80M(Milling axis stop command P9876);
(Second figure specification)
M(Milling reverse tapping pre-command P9089);
M(Milling forward command P9877);
G98(G84/G88)_ ;
G80M(Milling axis stop command P9876);
:
(nth figure specification)
M(Milling reverse tapping pre-command P9089);
M(Milling forward command P9877);
G98(G84/G88)_ ;
G80M(Milling axis stop command P9876);
:

NOTE

When bit 4 (TTM) of parameter No. 9846 is set to 0 or when the bit is set to 0 and parameter No. 9089 is not set, reverse rotation may be specified as the direction of rotation for tapping. In this case, P/S alarm, "3008 A WRONG TOOL SELECTED," is issued.

(9) C-axis forward tapping by rigid tapping, even spacing

```

:
:
:
M(Milling axis stop command P9876);
(M8/M9);
G97G98G40T_ ;
G80;
(Movement to the cutting start point)

```

M(Milling axis stop command P9876); (E1)
or . . . (E)*

M(Milling forward tapping pre-command P9088); . . . (E2)
--

```

S_M(Rigid tapping mode command P5210);
G98(G84/G88)_ ;
(Second figure specification)
:
```

```
(nth figure specification)
:
```

```
G80M(Milling axis stop command P9876);
:
```

* For block (E),

- Block (E1) is output when bit 5 (MTM) of parameter No. 9846 is set to 0.
- Block (E2) is output when bit 5 (MTM) of parameter No. 9846 is set to 1 and a value is set for parameter No. 9088. When no value is set for parameter No. 9088, no command is output.

(10) C-axis reverse tapping by rigid tapping, even spacing

```

:
M(Milling axis stop command P9876);
(M8/M9);
G97G98G40T_ ;
G80;
(Movement to the cutting start point)
M(Milling reverse tapping pre-command P9089);
S_M(Rigid tapping mode command P5210);
G98(G84/G88)_ ;
(Second figure specification)
:
```

```
(nth figure specification)
:
```

```
G80M(Milling axis stop command P9876);
:
```

NOTE

When bit 4 (TTM) of parameter No. 9846 is set to 0 or when the bit is set to 0 and parameter No. 9089 is not set, reverse rotation may be specified as the direction of rotation for tapping. In this case, P/S alarm, "3008 A WRONG TOOL SELECTED," is issued.

(11) C-axis forward tapping by rigid tapping, uneven spacing

:
M(Milling axis stop command P9876);

(M8/M9);

G97G98G40T_ ;

G80;

(Movement to the cutting start point)

M(Milling axis stop command P9876); (F1)
or . . . (F)*

M(Milling forward tapping pre-command P9088); . . . (F2)

S_ M(Rigid tapping mode command P5210);

G98(G84/G88)_ ;

G80M(Milling axis stop command P9876);

(Second figure specification)

M(Milling forward tapping pre-command P9088); . . . (G)*

S_ M(Rigid tapping mode command P5210);

G98(G84/G88)_ ;

G80M(Milling axis stop command P9876);

:
(nth figure specification)

M(Milling forward tapping pre-command P9088); . . . (G)*

S_ M(Rigid tapping mode command P5210);

G98(G84/G88)_ ;

G80M(Milling axis stop command P9876);

:

* For block (F),

- Block (F1) is output when bit 5 (MTM) of parameter No. 9846 is set to 0.
- Block (F2) is output when bit 5 (MTM) of parameter No. 9846 is set to 1 and a value is set for parameter No. 9088. When no value is set for parameter No. 9088, no command is output.

* For block (G),

Block (G) is output when bit 5 (MTM) of parameter No. 9846 is set to 1 and a value is set for parameter No. 9088. When no value is set for parameter No. 9088, no command is output.

(12) C-axis reverse tapping by rigid tapping, uneven spacing

```

:
M(Milling axis stop command P9876);
(M8/M9);
G97G98G40T_ ;
G80;
(Movement to the cutting start point)
M(Milling reverse tapping pre-command P9089);
S_M(Rigid tapping mode command P5210);
G98(G84/G88)_ ;
G80M(Milling axis stop command P9876);
(Second figure specification)
M(Milling reverse tapping pre-command P9089);
S_M(Rigid tapping mode command P5210);
G98(G84/G88)_ ;
G80M(Milling axis stop command P9876);
:
(nth figure specification)
M(Milling reverse tapping pre-command P9089);
S_M(Rigid tapping mode command P5210);
G98(G84/G88)_ ;
G80M(Milling axis stop command P9876);
:

```

NOTE

When bit 4 (TTM) of parameter No. 9846 is set to 0 or when the bit is set to 0 and parameter No. 9089 is not set, reverse rotation may be specified as the direction of rotation for tapping. In this case, P/S alarm, "3008 A WRONG TOOL SELECTED," is issued.


If the reverse spindle rotation tapping pre-command is used to reverse the specified direction of spindle rotation, the icon indicating the spindle rotation status points opposite to the actual direction of spindle rotation. For this reason, to make the icon points the correct direction, set the parameter for "using an external signal to display the spindle rotation status (bit 7 (SPE) of parameter No. 9845)" to 1. Also set forward and reverse spindle rotation signals for external signal R987 as follows. The MANUAL GUIDE checks these signals and display the icon indicating the spindle rotation status.
 Bit 0 of R987 = 1: Set to 1 when M03 (forward rotation) is specified.
 Bit 1 of R987 = 1: Set to 1 when M04 (reverse rotation) is specified.
 When both signals are set to 0, the spindle is assumed to stop.

4

C-AXIS CUTTING A

4.1

C-AXIS END FACE CENTER DRILLING, C-AXIS END FACE DRILLING, C-AXIS END FACE REAMING, C-AXIS END FACE BORING, C-AXIS END FACE TAPPING



In C-axis end face drilling, center drilling, drilling, reaming, boring, and tapping can be used in the same way as for drilling by turning.

NOTE

To use C-axis boring, set bit 1 (CBR) of parameter No. 9765 to 1.

4.1.1 Selecting the Type of Machining

Perform the following operation to select each type of machining.

C-axis center drilling :

 Press soft-key [C-CDRL], then press [FACE].

C-axis drilling :

 Press soft-key [C-DRIL], then press [FACE].

C-axis reaming :

 Press soft-key [C-REAM], then press [FACE].

C-axis boring :

 Press soft-key [C-BORE], then press [FACE].

C-axis tapping :

 Press soft-key [C-TAP], then press [FACE].

4.1.2 Detail of Process Data

(1) C-axis center drilling

CYCLE CUTTING * C-AXIS CENTER DRILL*	
AREA	= CUT ST Z =
TOOL NUM	= HOLE DIA =
FEED/MIN	= DWELL =
REV/MIN	= HOLE POS =
S-DIRECT	=
CUT ST X	=

TOOL NUM

Number of tool used for center drilling

FEED/MIN

Feed amount in center drilling

REV/MIN

Spindle rotating speed

NOTE

In C-axis drilling, only FEED/MIN is available while FEED/MIN or REV/MIN can be selected for drilling by turning.

S-DIRECT


Spindle rotating direction. Select from [NORMAL] and [REVERS].

CUT ST X

X coordinate of the retract position for drilling multiple holes

CUT ST Z

Z coordinate of the retract position for drilling multiple holes



HOLE DIA

Nominal diameter of the tool. Used only in animated drawing.


DWELL

Dwell time at hole end point


HOLE POS

Hole position pattern. Select from [EQ INT] and [NE INT].

1. [EQ INT]



2. [NE INT]

**(2) C-axis drilling**

CYCLE CUTTING ***C-AXIS DRILL***			
AREA	=	CUT ST Z	=
TOOL NUM	=	HOLE DIA	=
FEED/MIN	=	CUT-DPTH	=
REV/MIN	=	DWELL	=
S-DIRECT	=	HOLE POS	=
CUT ST X	=	PATTERN	=

TOOL NUM

Number of tool used for drilling

FEED/MIN

Feed amount in drilling

REV/MIN

Spindle rotating speed

S-DIRECT

Spindle rotating direction. Select from [NORMAL] and [REVERS].

CUT ST X

X coordinate of the retract position for drilling multiple holes

CUT ST Z

Z coordinate of the retract position for drilling multiple holes

HOLE DIA

Nominal diameter of the tool. Used only in animated drawing.

CUT-DPTH

Depth of the first cut in peck drilling or high-speed peck drilling. Automatically determined according to the hole diameter and value of parameter No. 9853 (DRILCF).

DWELL

Dwell time at hole end point


HOLE POS

Hole position pattern. Select from [EQ INT] and [NE INT].


PATTERN

Select from [DRILL], [DEEP HOLE], and [RAPID DEEP].


1. [DRILL]



2. [DEEP HOLE]



3. [RAPID DEEP]

**NOTE**

The return amount shown in the above figure is displayed in the detail data window.

(3) C-axis reaming

CYCLE CUTTING ***C-AXIS REAMING***	
AREA =	CUT ST Z =
TOOL NUM =	HOLE DIA =
FEED/MIN =	CHAMF-LNG =
REV/MIN =	DWELL =
S-DIRECT =	HOLE POS =
CUT ST X =	

TOOL NUM

Number of tool used for reaming

FEED/MIN

Feed amount in reaming

REV/MIN

Spindle rotating speed

S-DIRECT

Spindle rotating direction. Select from [NORMAL] and [REVERS].

CUT ST X

X coordinate of the retract position for drilling multiple holes

CUT ST Z


Z coordinate of the retract position for drilling multiple holes

HOLE DIA

Nominal diameter of the tool. Used only in animated drawing.

CHAMF-LNG

Cutting-lip length of a reamer at the start of cutting.
Automatically determined according to the value of parameter
No. 9054 (RIMKLN).

**DWELL**

Dwell time at hole end point

HOLE POS

Hole position pattern. Select from [EQ INT] and [NE INT].

(4) C-axis boring

CYCLE CUTTING ***C-AXIS BORING***	
AREA =	CUT ST Z =
TOOL NUM =	HOLE DIA =
FEED/MIN =	SHIFT =
REV/MIN =	DWELL =
S-DIRECT =	HOLE POS =
CUT ST X =	

TOOL NUM

Number of tool used for boring

FEED/MIN

Feed amount in boring

REV/MIN

Spindle rotating speed

S-DIRECT

Spindle rotating direction. Select from [NORMAL] and [REVERS].

CUT ST X

X coordinate of the retract position for drilling multiple holes

CUT ST Z


Z coordinate of the retract position for drilling multiple holes

HOLE DIA

Nominal diameter of the tool. Used only in animated drawing.

SHIFT

Shift amount for relief motion in boring. Automatically determined according to the value of parameter No. 9858 (BRSHFT).



DWELL

Dwell time at hole end point

HOLE POS

Hole position pattern. Select from [EQ INT] and [NE INT].

(5) C-axis tapping

CYCLE CUTTING ***C-AXIS TAPPING***			
AREA	=	CUT ST Z	=
TOOL NUM	=	HOLE DIA	=
FEED/MIN	=	PITCH	=
REV/MIN	=	DWELL	=
S-DIRECT	=	HOLE POS	=
CUT ST X	=	TAP TYPE	=

TOOL NUM

Number of tool used for tapping

FEED/MIN

Feed amount in tapping. Automatically determined according to the pitch and speed.

REV/MIN

Spindle rotating speed

S-DIRECT

Spindle rotating direction. Select from [NORMAL] and [REVERS].

CUT ST X

X coordinate of the retract position for drilling multiple holes

CUT ST Z

Z coordinate of the retract position for drilling multiple holes

HOLE DIA

Nominal diameter of the tool. Used only in animated drawing.

PITCH

Pitch of a tapping tool

DWELL

Dwell time at hole end point

HOLE POS

Hole position pattern. Select from [EQ INT] and [NE INT].

TAP TYPE

Kind of tapping motion, rigid tapping or conventional tapping.

Select from [RIGID] or [NORMAL].

4.1.3 Supplemental Process Data in a Pop-up Window

(1) C-axis center drilling

A PROCH X =
A PROCH Z =
COOLANT =
SPDL GEAR =

APPROACH X

X coordinate of approaching intermediate point.

APPROACH Z

Z coordinate of approaching intermediate point.

COOLANT

COOLANT command at playback. Choose from the following soft-key menu. Default value is [ON].

- [ON] : (M8)
- [OFF] : (M9)

SPDL GEAR

Select the milling gear. Directly input an M code (only when required).

(2) C-axis drilling [DRILL]

ST FEED =
ST CLEAR =
A PROCH X =
A PROCH Z =
COOLANT =
SPDL GEAR =

ST FEED

Cutting feedrate override at the start of cutting (parameter 9050 : STFECF) The cutting feedrate is calculated as follows.

$$\text{ST FEED} = (\text{Feedrate}) \times (\text{STFECF}) / 100$$

ST CLEAR

Clearance (distance between the tool tip and tool shoulder) at the start of cutting. The tool cuts the workpiece by the above feedrate from a point distanced from the cutting start point by an amount equal to this clearance. This clearance is calculated as follows.

$$\text{Clearance} = (\text{HOLE DIA}) / (2 \times \tan(\text{nose angle}/2))$$

Nose angle = parameter 9083 : DRLANGL

A PROCH X

Similar to center drilling

A PROCH Z

Similar to center drilling

COOLANT

Similar to center drilling

SPDL GEAR
Similar to center drilling

(3) C-axis drilling [DEEP HOLE] / [RAPID DEEP]

DPTH DCRS =	APPROCH Z =
RET AMNT =	COOLANT =
MIN DEPTH =	SPDL GEAR =
ST FEED =	
ST CLEAR =	
APPROCH X =	

DPTH DCRS

Decrement of the depth of cut for peck or high-speed peck drilling. The depth of cut is reduced by this for each cut. (parameter 9850 : DRLDEC)

RET AMNT

Amount of retraction for peck or high-speed peck drilling. (parameter 9851 : DRLRET)

MIN DEPTH

Minimum depth of cut. (parameter 9852 : DRLMIN)

ST FEED

Similar to drilling [DRILL].

ST CLEAR

Similar to drilling [DRILL].

APPROCH X

Similar to center drilling

APPROCH Z

Similar to center drilling

COOLANT

Similar to center drilling

SPDL GEAR

Similar to center drilling

(4) C-axis reaming

RET SPEED =
ST FEED =
APPROCH X =
APPROCH Z =
COOLANT =
SPDL GEAR =

RET SPEED

Feedrate for retraction to the cutting start point upon the completion of reaming motion. This feedrate is calculated as follows. (parameter 9860 : RMBROV)

$$\text{RET SPEED} = (\text{Feed per minute}) \times (\text{RMBROV}) / 10$$

ST FEED

Similar to drilling [DRILL].

ST FEED

Similar to drilling [DRILL].

APPROCH X

Similar to center drilling

APPROCH Z

Similar to center drilling

COOLANT

Similar to center drilling

SPDL GEAR

Similar to center drilling

(5) C-axis boring

ORIENT M =
SFT DIRCT =
APPROCH X =
APPROCH Z =
COOLANT =
SPDL GEAR =

ORIENT M


M code for milling spindle orientation. Automatically determined according to the value of parameter No. 9056 (CBRORM).

SFT DIRCT


Shift direction of retraction after boring. Automatically determined according to the setting of bit 2 (BSH) of parameter No. 9765. (Positive direction when this parameter is set to 0; negative direction when it is set to 1)

To change the direction, select a desired direction by pressing soft-key [+SHIFT] or [-SHIFT].

1. [+SHIFT]



2. [-SHIFT]



APPROCH X

Similar to center drilling

APPROCH Z

Similar to center drilling

COOLANT

Similar to center drilling

SPDL GEAR

Similar to center drilling

(6) C-axis tapping

APPROCH X =
APPROCH Z =
COOLANT =
SPDL GEAR =

APPROCH X

Similar to center drilling

APPROCH Z

Similar to center drilling

COOLANT

Similar to center drilling

SPDL GEAR

Similar to center drilling

4.1.4 Detail of Figure Data

(1) "Evenly spaced" figure data

START X

X coordinate of the hole position (common)

START Z


Z coordinate of the hole start point (common)

START C

C coordinate of the position of the first hole

NOTE

A cutting motion in drilling is started the amount of drilling clearance (parameter No. 9855 (GRDLCL)) before the start point.



DEPTH D

Depth of hole (common)

ANGLE A

Angle indicating the hole position spacing

The positive or negative direction can be specified.


H.NUM N

Total number of holes


LST.ANG Q

C coordinate of the position of the last hole


- When no data is input for ANGLE(A), H.NUM(N), and LST.ANG(Q)



2. When no data is input for ANGLE(A), a value of 2 or more is input for H.NUM(N), and data is input for LST.ANG(Q)



3. When data is input for ANGLE(A), a value of 2 or more is input for H.NUM(N), and no data is input for LST.ANG(Q)



(2) "Unevenly spaced" figure data

Up to four end face holes can be specified at any positions with any depths.

POINT n X

X coordinate of the position of the nth hole

POINT n Z

Z coordinate of the start point of the nth hole

POINT n C


C coordinate of the position of the nth hole

DEPTH n D

Depth of the nth hole (Specify this value for each hole.)

NOTE


A cutting motion in drilling is started the amount of drilling clearance (parameter No. 9855 (GRDLCL)) before the start point.



NOTE

For a hole for which not all the above figure data items are input, no cutting is executed.

4.2 C-AXIS SIDE FACE CENTER DRILLING, C-AXIS DRILLING, C-AXIS REAMING, C-AXIS BORING, C-AXIS TAPPING



4.2.1 Selecting the Type of Machining

Perform the following operation to select each type of machining.
C-axis center drilling :

Press soft-key [C-CDRL], then press [SIDE].

C-axis drilling :

Press soft-key [C-DRIL], then press [SIDE].

C-axis reaming :

Press soft-key [C-REAM], then press [SIDE].

C-axis boring :

Press soft-key [C-BORE], then press [SIDE].

C-axis tapping :

Press soft-key [C-TAP], then press [SIDE].

4.2.2 Detail of Process Data


(1) C-axis center drilling, C-axis drilling, C-axis reaming, C-axis boring, and C-axis tapping

CUT ST X

X coordinate of the retract position for drilling multiple holes

CUT ST Z

Z coordinate of the retract position for drilling multiple holes




All data displayed in process data and detail data windows other than the coordinates of the cutting start point above and data for boring below is the same as for C-axis end face drilling.

SFT-DRCT


Shift direction of retraction after boring. Automatically determined according to the setting of bit 2 (BSH) of parameter No. 9765. (Positive direction when this parameter is set to 0; negative direction when it is set to 1)

To change the direction, select a desired direction by pressing soft-key [+SHIFT] or [-SHIFT].

1. [+SHIFT]



2. [-SHIFT]



4.2.3 Detail of Figure Data

(1) "Evenly spaced" figure data

START X

X coordinate of the hole position (common)

START Z


Z coordinate of the hole start point (common)

START C

C coordinate of the position of the first hole

NOTE

A cutting motion in drilling is started the amount of drilling clearance (parameter No. 9855 (GRDLCL)) before the start point.



DEPTH D

Depth of hole (radius: common)

ANGLE A

Angle indicating the hole position spacing

The positive or negative direction can be specified.


H.NUM N

Total number of holes


LST.ANG Q

C coordinate of the position of the last hole


- When no data is input for ANGLE(A), H.NUM(N), and LST.ANG(Q)



2. When no data is input for ANGLE(A), a value of 2 or more is input for H.NUM(N), and data is input for LST.ANG(Q)



3. When data is input for ANGLE(A), a value of 2 or more is input for H.NUM(N), and no data is input for LST.ANG(Q)



(2) "Unevenly spaced" figure data

Up to four side face holes can be specified at any positions with any depths.

POINT n X

X coordinate of the position of the nth hole

POINT n Z

Z coordinate of the start point of the nth hole

POINT n C


C coordinate of the position of the nth hole

DEPTH n D


Depth of the nth hole (Specify this value for each hole.)

NOTE

A cutting motion in drilling is started the amount of drilling clearance (parameter No. 9855 (GRDLCL)) before the start point.



4.3 C-AXIS END FACE GROOVING



4.3.1 Selecting the Type of Machining

Perform the following operation to select each type of machining.

C-AXIS GROOVING :

Press soft-key [C-GROV], then press [FACE].

C-AXIS GROOVING/CHAMF :

Press soft-key [C-GCHF], then press [FACE].

4.3.2 Detail of Process Data

(1) C-axis grooving

CYCLE CUTTING ***C-AXIS GROOVING***	
AREA	CUT ST Z =
TOOL NUM.	MIL DIA =
FEED X,C	SHAPE =
FEED Z	=
REV/MIN	=
CUT ST X	=

AREA

Select a desired cutting area from the following soft-key menu:

[FACE] = End face of the workpiece

[SIDE] = Outer surface of the workpiece

The following soft-keys are displayed in addition to the above menu items. You can switch between C-axis grooving and C-axis groove chamfering using the specified figure data.

[C-GROV] = Chamfering → Grooving

[C-GCHF] = Grooving → Chamfering

TOOL NUM.

Tool number of the grooving tool (end face milling tool)

FEED X,C

Feedrate used for cutting the workpiece with moving the end face end milling tool sideward (along the X-axis or about the C-axis) (mm/min or inch/min)

FEED Z

Feedrate used for cutting the workpiece with moving the end face end milling tool axis-direction (along the Z-axis) (mm/min or inch/min)

REV/MIN


Milling spindle speed

CUT ST X

X coordinate of the retract position for cutting multiple grooves

CUT ST Z

Z coordinate of the retract position for cutting multiple grooves




MIL DIA

Nominal diameter of the groove width or tool. This data is used only in animated drawing.


SHAPE

C-axis end face grooving type. Select a desired type from soft-keys [REGULR] and [IRREGL].

1. [REGULR]



2. [IRREGL]

**(2) C-axis groove chamfering**

CYCLE CUTTING	*	C-AXIS	
GROOVING/CHAMF*			
AREA	=	MIL DIA	=
TOOL NUM.	=	CHAMFER	=
FEED/MIN	=	SHAPE	=
REV/MIN	=		
CUT ST X	=		
CUT ST Z	=		

TOOL NUM.

Number of tool used for groove chamfering

FEED/MIN

Feedrate in chamfering (mm/min or inch/min)

REV/MIN

Milling spindle speed

CUT ST X

X coordinate of the retract position for cutting multiple grooves

CUT ST Z


Z coordinate of the retract position for cutting multiple grooves

MIL DIA

Width of the groove cut before chamfering

CHAMFER

Amount of chamfer after grooving



SGAPE

C-axis end face grooving type. Select a desired type from soft-keys [REGULR] and [IRREGL].

4.3.3 Supplemental Process Data in a Pop-up Window

(1) C-axis grooving

APPROCH X =
APPROCH Z =
COOLANT =
SPDL GEAR =

APPROCH X

X coordinate of approaching intermediate point.

APPROCH Z

Z coordinate of approaching intermediate point.

COOLANT

COOLANT command at playback. Choose from the following menu. The default value is "ON".

[ON] : (M8)

[OFF] : (M9)

SPDL GEAR

Select the milling gear. Directly input an M code (only when required).

(2) C-axis groove chamfering


SMALL DIA =
NOSE ANGL =
APPROCH X =
APPROCH Z =
COOLANT =
SPDL GEAR =

SMALL DIA

Small diameter of the chamfering tool

NOSE ANGL

Angle of the nose of the chamfering tool



NOTE

Cutter compensation data in the tool file is used as the radius of the chamfering tool.

APPROCH X

Similar to grooving

APPROCH Z

Similar to grooving

COOLANT

Similar to grooving

SPDL GEAR

Similar to grooving

4.3.4 Detail of Figure Data

(1) "Regular" groove figure data

START X

X coordinate of a groove (common)

START Z


Z coordinate of the groove start point (common)

START C

C coordinate of the first groove

NOTE

A cutting motion in grooving is started the amount of grooving clearance (parameter No. 9855 (GRDCL)) before the start point.




DEPTH D

Depth of a groove (common)


GV-LNG LA

Length of a groove (Center angle: common)




ANGLE A


Angle between the start points of two grooves (center angle)




G.NUM N
Total number of grooves
LST.ANG Q
C coordinate of the start point of the last groove




- When no data is input for ANGLE(A), H.NUM(N), and LST.ANG(Q)



2. When no data is input for ANGLE(A), a value of 2 or more is input for H.NUM(N), and data is input for LST.ANG(Q)



3. When data is input for ANGLE(A), a value of 2 or more is input for H.NUM(N), and no data is input for LST.ANG(Q)



(2) "Irregular" figure data

Up to two C-axis end face grooves can be specified at any positions with any depths.

ST.POS n X

X coordinate of the start point of the nth groove

ST.POS n Z


Z coordinate of the start point of the nth groove

ST.POS n C

C coordinate of the start point of the nth groove

NOTE

A cutting motion in grooving is started the amount of grooving clearance (parameter No. 9855 (GRDCL)) before the start point.



E.P n X/Z


X coordinate of the end point of the nth groove

E.P n C


C coordinate of the end point of the nth groove

DEPTH n D

Depth of the nth groove (Specify this value for each groove.)



4.4 C-AXIS SIDE FACE GROOVING



4.4.1 Selecting the Type of Machining

Perform the following operation to select each type of machining.
C-axis grooving :

Press soft-key [C-GROV], then press [SIDE].

C-axis groove chamfering:

Press soft-key [C-GCHF], then press [SIDE].

4.4.2 Detail of Process Data

(1) C-axis grooving and C-axis groove chamfering

FEED Z,C

Feedrate used for cutting the workpiece with moving the side face end milling tool sideward (along the Z-axis or about the C-axis) (mm/min or inch/min)

FEED X


Feedrate used for cutting the workpiece with moving the side face end milling tool axis-direction (along the X-axis) (mm/min or inch/min)

CUT ST X

X coordinate of the retract position for cutting multiple grooves

CUT ST Z

Z coordinate of the retract position for cutting multiple grooves



All process data for C-axis side face grooving other than the above is the same as for C-axis end face grooving.

4.4.3 Supplemental Process Data in a Pop-up Window

(1) C-axis grooving

APPROCH X =
APPROCH Z =
COOLANT =
SPDL GEAR =

APPROCH X

X coordinate of approaching intermediate point.

APPROCH Z

X coordinate of approaching intermediate point.

COOLANT

COOLANT command at playback. Choose from the following menu. The default value is "ON".

[ON] : (M8)

[OFF] : (M9)

SPDL GEAR

Select the milling gear. Directly input an M code (only when required).

(2) C-axis groove chamfering


SMALL DIA =
NOSE ANGL =
APPROCH X =
APPROCH Z =
COOLANT =
SPDL GEAR =

SMALL DIA

Small diameter of the chamfering tool

NOSE ANGL

Angle of the nose of the chamfering tool



NOTE

Cutter compensation data in the tool file is used as the radius of the chamfering tool.

APPROCH X

Similar to grooving

APPROCH Z

Similar to grooving

COOLANT

Similar to grooving

SPDL GEAR

Similar to grooving

4.4.4 Detail of Figure Data

(1) "Regular" groove figure data

START X

X coordinate of the groove start point (common)

START Z


Z coordinate of the groove start point (common)

START C

C coordinate of the first groove

NOTE

A cutting motion in grooving is started the amount of grooving clearance (parameter No. 9855 (GRDCL)) before the start point.




DEPTH D

Depth of a groove (radius: common)


GV-LNG LA

Length along the Z-axis of a groove (common)

1. Groove length = +




2. Groove length = -



ANGLE A

Angle between two grooves




G.NUM N


Total number of grooves

LST.ANG Q


C coordinate of the last groove



- When no data is input for ANGLE(A), H.NUM(N), and LST.ANG(Q)



- When no data is input for ANGLE(A), a value of 2 or more is input for H.NUM(N), and data is input for LST.ANG(Q)
- When data is input for ANGLE(A), a value of 2 or more is input for H.NUM(N), and no data is input for LST.ANG(Q)



(2) "Irregular" figure data

Up to two C-axis end face grooves can be specified at any positions with any depths.

ST.POS n X

X coordinate of the start point of the nth groove

ST.POS n Z


Z coordinate of the start point of the nth groove

ST.POS n C

C coordinate of the start point of the nth groove

NOTE

A cutting motion in grooving is started the amount of grooving clearance (parameter No. 9855 (GRDCL)) before the start point.



E.P n X/Z


Z coordinate of the end point of the nth groove

E.P n C

C coordinate of the end point of the nth groove

DEPTH n D

Depth of the nth groove (Specify this value for each groove.)



5

WASTE CUTTING CANCEL FUNCTION

In bar machining (outer, inner, and end face forward machining), optimum cutting motions can be made by automatically eliminating waste motions according to the blank figure specified in advance. This function is enabled by setting bit 7 (ACC) of parameter No. 9777 and bit 2 (BSZ) of parameter No. 9761 to 1.

5.1 INPUTTING A BLANK FIGURE

After creating a program for bar machining (roughing), perform the following operations to specify a desired blank figure.

The program create and edit screen cannot be used to specify a blank figure. Use the program list window shown below to specify and cancel a blank figure.

- (1) Select the program list window.

PROGRAM LIST	BLANK SIZE
	LENGTH 112.500
01: CIRCLE MACHINING	OUTER DIA 110.000
02: LINE MACHINING	INNER DIA 0.000
03: BAR MACHINING	REMOVAL 0.000
04: GROOVING	WORK
05: DRILLING	BAR

- (2) Press soft-key [WORK] and position the cursor to the "WORK" item. The following soft-keys are displayed.

[PRGRM] [BAR] [ROUGH] . . . [] [] []

[PRGRM]: Moves the cursor back to the program list display section.


[BAR]: Specifies a bar as the blank figure.

[ROUGH]: Specifies a formed material as the blank figure.

When the "WORK" item in the blank window is left blank, the blank figure is assumed to be a bar. The "OUTER DIA," "INNER DIA," and "LENGTH" items in the blank size window are determined according to blank figure data when soft-key [FIGEND] is pressed.

- (3) Press soft-key [ROUGH]. The following window for inputting the figure of a formed material is displayed.

SPECIFYING ROUGH SHAPE	
OUTER	
X1	Z1
X2	Z2
X3	Z3
X4	Z4
X5	Z5
:	:
:	:
X11	Z11
X12	Z12



[DLTALL] [FIGEND] [] [RETURN] [] []

(The above is an example of a window displayed for a back tool post lathe.)

[FIGEND]:

Saves the input blank figure data into the program and closes this window. (The input blank figure data is saved into the program only when soft-key [FIGEND] is pressed.)

[DLTALL]:

Deletes all data displayed in the window. (Only the data keyed in and stored in the key-in buffer is deleted, and the data saved into the program is not deleted.)

[RETURN]:

Closes the window for inputting the blank figure.

Only blank figures as shown in the following examples can be specified. These blank figures are made only with vertical and horizontal lines and have the shape of a staircase whose coordinate monotonously increases (for outer machining) or decreases (for inner machining) in the direction from the end face of each blank to the chuck. The coordinates of up to 12 corner points of a blank figure can be specified for each of outer and inner machining. Select outer or inner machining using page keys [\uparrow] and [\downarrow].

NOTE

When specifying the figure of a formed material for which only inner machining is to be performed, always specify the outer figure.


When only outer machining is to be performed, the inner figure need not be specified.

- Examples of blank figures that can be specified
Outer machining




SUPPLEMENT 5. WASTE CUTTING CANCEL FUNCTION


Inner machining




End face machining




- Examples of blank figures that cannot be specified



The coordinate does not monotonously increase or decrease.




No slanted line can be specified.



The contour extends off the blank.

5.2 DETAILS OF CUTTING MOTIONS

When the parameter for enabling the waste cutting cancel function is set and a formed material is specified as the blank figure, the bar machining process is executed with automatically eliminating the cutting motion for each area in which there is no blank as shown in the figure below.



START X/Z

Also determined as described in the explanation of parameters Nos. 9784 and 9785 for a formed material.

APPROACH X/Z

Also determined as described in the explanation of parameters Nos. 9782 and 9783 for a formed material.

NOTE


Pressing soft-key [CALC.] in the figure data window at program editing recalculates the cutting start point and approaching points using the input blank size of the formed material.

Clearance

The cutting start position following retraction is determined according to the value of parameter No. 9784 (outer/inner machining) or No. 9785 (end face machining).

NOTE

These parameters are also used for automatically determining the cutting start point.

SUPPLEMENT5.WASTE CUTTING CANCEL FUNCTION

6 RETHREADING

Rethreading is a function of cutting a worn-out or partially broken thread again. A thread is cut again by inputting thread cutting data and teaching the position of the thread. This function requires the function of controlling the spindle orientation to synchronize the tool feed with the mounted thread.

6.1 OVERVIEW

Applicable threads

- Following thread types
General, metric, unified, piping PT, and PF
- Straight and tapered threads
- Single and multiple threads
- Normal (right-hand) thread and reverse (left-hand) thread

Spindle orientation

Perform spindle orientation before teaching the thread position.

Input data

Input data required for rethreading in the process data window for ordinary threading. Specify "REPAIR" as the "METHOD" input item to perform rethreading.

Rethreading requires the following data items like ordinary threading:

Process data: TYPE, METHOD, ANGLE, and LEAD

Figure data: START X, START Z, END X, and END Z

For details of each item, see the corresponding chapter in this operator's manual.

Teaching the thread position


Teach the thread position to synchronize the tool feed with the mounted thread. Touch the tool on the bottom of an appropriate thread and press soft-key [SYNC P] to teach the thread position. The taught position is used to provide timing to start feeding the tool at the cutting start point.

Tool motions

The tool moves for rethreading as shown in the figure below:

- a) Moves from the current tool position to the approaching point.
- b) Moves from the approaching point to the cutting start point.
- c) Performs threading.

For details of each point, see the corresponding chapter of this operator's manual.



Synchronization

To synchronize the tool feed with the mounted thread, the tool is made wait for the start of tool feed at point A shown in the figure below by the number of spindle rotations that is obtained by the following equation:

$$Q = Q_s + Q_z - Q_e - Q_p \text{ (degree)}$$


Qs: Spindle angular displacement for providing timing to start feeding the tool at point A and synchronize the tool feed with the phase of the thread

$$Qs = 360(\text{Lead}-r)/\text{Lead}$$

Lead , r : Remainder of L/Lead

L : Distance between the taught thread position and point A

Qz : Angle indicating the difference between the spindle one-rotation signal detection position and spindle orientation stop position. Qz differs depending on the machine. Set Qz for parameter No. 9844.



Qe : Spindle angular displacement equivalent to the amount of the position error of the servo axis (Z)

$$Qe = \Delta E_z \times 360 / \text{Lead}$$

ΔE_z : Amount of the servo position error at the threading feedrate

Qp : Spindle angular displacement equivalent to the amount of accumulation during acceleration

This value can be changed by setting a new value for the "SHIFT" figure data input item when required.

$$Qp = \text{Shift amount} \times 360 / \text{Lead}$$

Shift angle Q above is calculated with the user macro (O1041). If the tool feed cannot be synchronized with the phase of the thread, the machine tool builder can change the expression according to the machine.

6.2 OPERATION

(1) Input process data.

When rethreading is selected, the default values are automatically set for the input items below as follows:

CUT AMUNT/CUT TIMES :

CUT TIMES is selected and 1 is set.

MULTI. : 1 is set.

For a multiple thread, input the number of threads. For multiple cuts, input the number of cuts or the depth of cut.

(2) When the cursor is positioned at the "METHOD" input item in the process data window, press soft-key [REPAIR].

[S-AMNT] [B-AMNT] [] [REPAIR]

When rethreading is performed according to the value input for "CUT AMUNT/CUT TIMES", " BOTH AMOUNT " is automatically selected for "METHOD".


(3) Manually input the lead of the thread.

(4) When the cursor is positioned in the figure data window and rethreading is specified, soft-keys [ORIENT] and [CAN OR] are displayed.

Press soft-key [ORIENT] to perform spindle orientation. At this time, the M code for orientation set for parameter No. 4960 is output.

(5) Teach the figure of the thread or directly input numeric values to specify the figure.

After inputting process data, the operator should directly input the values for START X, START Z, END X, and END Z for the thread figure or teach the thread figure as follows to specify the figure:



- Move the tool to the thread start point.

- Position the cursor to the "START X" input item.

- Press soft-key [RD POS].

[RD POS] [SYNC P] [] [] . . . [] []

At that time, the current workpiece coordinate X is set for the "START X" input item.

- Set other figure data in the same way.

- (6) Teach the thread position to synchronize the tool feed with the thread.

Before this operation, at least START X and START Y must be set for the figure.

- Touch the tool on the bottom of the thread to be rethreaded.
 - Press soft-key [SYNC P].

At this time, angular displacement Q for synchronization with the thread described above is calculated and the calculation result and taught position are displayed as follows:

*

*

```
SHIFT =           ←Calculation result Q  
TYPE =  
METHOD = REPAIR  
ANGL =  
LEAD =
```

START X =
START Z =
END X =
END Z =
SHIFT OFS = ←Amount of accumulation during acceleration Qp
SYNC POS = ←Taught thread position

If threading is executed before soft-key [SYNC P] is pressed, macro alarm, "3001 CHECK PROCESS DATA." is issued.

- (7) Manually remove the tool from the thread and move it to a safe position at which cutting can be started. Then, press soft-key [CAN OR] to cancel spindle orientation.

When soft-key [CAN OR] is pressed, the M code for canceling orientation set for parameter No. 4961 is output. If the tool is not at the distance specified for parameter No. 9843 from the thread, the warning message, "MOVE TOOL AWAY FROM THREAD," is displayed.

- (8) Press soft-key [EXEC] or the [START] button on the machine operator's panel to execute rethreading.

When rethreading is selected, process data "CUT TIMES" is automatically set to 1. For this reason, rethreading is performed only once in ordinary cases. The operator can change the value set for "CUT TIMES/CUT AMUNT", however. When the value is changed, rethreading is executed according to the specified value.

To use this function, the parameter 9848 bit 7 (TRP) must be set to 1.

APPENDIX

A PARAMETERS

⚠ WARNING

Be sure to use the parameters set by the machine tool builder.

If you change the setting of a parameter, the machining program may not work correctly.

If the machining program does not work correctly, the tool may bump against the workpiece, and the machine may be forced to perform unnatural machining, possibly causing damage to the tool and/or machine, and even injuries.

A.1 PARAMETERS FOR DRILLING (1)

NOTE

In addition to the parameter listed below, parameter Nos.9850 to 9862 are provided for drilling.

9050**STFECF**

STFECF Cutting feedrate override at the start of cutting in drilling.
Valid data range : 0 to 255 Units : 1%

9054**RIMKLN**

RIMKLN Cutting-lip length to be set automatically at the start point of cutting in reaming (chamfer length on the program screen).
Valid data range : 0 to 99,999,999
Units : 0.001mm
 0.0001inch

9056**CBRORM**

CBRORM M code for spindle orientation in C-axis boring
Valid data range : 0 to 999

A.2 PARAMETERS FOR MANUAL GUIDE PERIPHERAL FUNCTIONS

9080**ANMTWO**

ANMTWO Shank width of an outer general tool for animated drawing only.
 Valid data range : 0 to 99,999,999
 Units : 0.001mm
 0.0001inch

9081**ANMTWI**

ANMTWI Shank width of an inner general tool for animated drawing only.
 Valid data range : 0 to 99,999,999
 Units : 0.001mm
 0.0001inch

9082**ANMTWF**

ANMTWF Shank width of a face general tool for animated drawing only.
 Valid data range : 0 to 99,999,999
 Units : 0.001mm
 0.0001inch

9083**ANMTAN**

ANMTAN Nose angle of a drilling tool for animated drawing only.
 Valid data range : 0 to 180
 Units : 1 degree

9090**SPDLMX**

SPDLMX Maximum spindle speed used for constant surface speed control.
 G50 S(SPDLMX) ; is outputted at the top of each program in
 MANUAL GUIDE format program. And also, this is used for the
 default value for an external CSN (CSS mode command) switch on a
 machine operator's panel.
 Valid data range : 0 to 65535
 Units : 1

9091**INITTCD**

Default value of a tool number used for an external T-code switch on
 a machine operator's panel. This value is applied when no data is
 inputted in a guidance or single cutting process, or on an initial
 screen.
 Valid data range : 1 to 99
 Units : 1

9092	INISMIN
------	---------

INISMIN Default value of a spindle speed used for an external CSN(CSS mode command) switch on a machine operator's panel. This value is applied when no data is inputted in a guidance or single cutting process, or on an initial screen.
 Valid data range : 0 to 65535
 Units : 1

9093	INISRPM
------	---------

INISRPM Default value of a spindle speed used for an external CSF(CSS mode cancel command) switch on a machine operator's panel. This value is applied when no data is inputted in a guidance or single cutting process, or on an initial screen.
 Valid data range : 0 to 65535
 Units : 1

9640	#7	#6	#5	#4	#3	#2	#1	#0
				PR5	PR4	PR3	PR2	PR1

PRn 1 : Enables custom process n (= 1 to 5).
 0 : Disables custom process n (= 1 to 5).

9641	#7	#6	#5	#4	#3	#2	#1	#0
					EFV	SM5	NT0	RF2

RF2 1 : It is available to change the parameter 1241 for setting the second reference position in Manual Guide Screen.
 0 : Disables to change the parameter 1241 in Manual Guide Screen.

NT0 1 : After finish machining, output to with the command of moving a tool to the approach point before returning to the tool change position.
 0 : After finish machining, output to as one block command.

SM5 1 : In tapping, output M05 as one block command after the command of G32.
 0 : In tapping, output M05 with the command of G32 as one block command.

EFV1 1 : Enables feedrate override and cutting amount override in case of the end face cutting with outer bar machining.
 0 : Disables the above function.
 <Related parameters : No. 9643, 9644>

9642	#7	#6	#5	#4	#3	#2	#1	#0
								SLM

SLM 1 : Spindle load meter displays the spindle load data which is read from PMC data R991.
 PMC data R991 has to be 8 bit data with binary format.
 0 : Spindle load meter displays the CNC's spindle load data.

9643	FACFOV
------	---------------

FACFOV Feedrate override for the end face cutting with executing outer bar machining.
 Valid data range : 0 to 255 (when 0 is set, it means 100%).)
 Units : %
 <Related parameter : No. 9641 bit3 (EFV)>

9644	CUTAOV
------	---------------

CUTAOV Cutting amount override for the end face cutting with executing outer bar machining
 Valid data range : 0 to 255 (when 0 is set, it means 100%).)
 Units : %
 <Related parameter : No. 9641 bit3 (EFV)>

9645	PRGFMC
------	---------------

PRGFMC M-code which is output at the program top as the following example.
 O0002 (BAR/THREAD) ;
 G80 ;
 G40 ;
 M45 ; ← In case of P9645=45
 G30 L10 W0 ;
 Valid data range : 0 to 32767
 Units : 1

A.3 USER PARAMETERS

9646	Bit type parameter
------	--------------------

to

9655	Bit type parameter
------	--------------------

9656	Word type parameter
------	---------------------

to

9685	Word type parameter
------	---------------------

NOTE

For details of parameter Nos.9646 to 9685, refer to
the manual supplied by the machine tool builder.

A.4**BIT TYPE PARAMETERS FOR MANUAL GUIDE COMMON USE**

9760	#7 NPL	#6 NCO	#5 G30	#4 APZ	#3 MGE	#2	#1	#0
------	-----------	-----------	-----------	-----------	-----------	----	----	----

- MGE 1 : The following block is output at the end of last cutting process.
G97 M05;
M09;
0 : The above function is disabled.
- APZ 1 : Approaching point Z for bar machining, threading, and grooving is calculated using the cutting start point as follows:
 $Z=[\text{START } Z] + \text{Parameter } [\text{OTSFPZ}] \text{ or } [\text{INSFPZ}]$
[OTSFPZ] : Parameter 9781
[INSFPZ] : Parameter 9783
0 : The above function is disabled. For how the approaching point is calculated, see the explanation of parameter No. 9783.
- G30 1 : G30 is not executed in each machining processes.
0 : G30 is executed.
- NCO 1 : Conversion of a machining program into NC program is valid.
0 : This cannot be used.
- NPL This must be set to 1 always.

9761	#7 AFR	#6 SEM	#5 SRV	#4 AWD	#3 TCP	#2 BSZ	#1 PWN	#0 UWN
------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------

- UWN 1 : User window in an initial screen is available.
0 : This window is not available.
- PWN 1 : [PRESET] in an initial screen is not available.
0 : [PRESET] can be used.
- BSZ 1 : A window for setting the blank size is displayed in the program list window. The blank size is not determined automatically. It is set after a program is created or edited.
0 : The above function is disabled. The blank size is automatically determined when a new program is created. It is not automatically determined again when a program consisting of multiple processes is created or edited.
- TCP 1 : Approaching point data is treated as tool-change point data.
(This function is not enabled simply by setting this parameter.
To enable this function, also customize a macro.)
0 : The above function is disabled.
- AWD 1 : An alarm window is displayed on the MANUAL GUIDE screen.
0 : The above function is disabled.
- SRV 1 : Soft-keys for a near-end tool post lathe are displayed.
0 : Soft-keys for a back tool post lathe are displayed.
- SEM 1 : Semifinishing only can be specified for bar machining (roughing). When this parameter is set to 1, bit 5 (RFN) of parameter No. 9772 is invalidated.
0 : The above function is disabled.

- AFR 1 : The feed per revolution is displayed for actual feedrate F in the status indicator window.
 0 : The above function is disabled.

9762	#7 LG1	#6 LG2	#5 LG3	#4 LG4	#3 NCA	#2 NGS	#1 TCA	#0 NFK
------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------

- NFK 1 : The function keys are disabled on the MANUAL GUIDE screen. To select a CNC screen such as POS or OFFSET, press both ends of the related soft-key.
 0 : The function keys are enabled on the MANUAL GUIDE screen.
- TCA 1 : In linear or circular guidance cutting, approach and guidance cutting motions are automatically stored as different blocks according to the nature of each motion and taught in the CNC. Up to 30 blocks can be created at a time.
 0 : The above function is disabled.
- NGS 1 : The soft-keys for selecting guidance cutting and single cutting are not displayed.
 0 : The above soft-keys are displayed.
- NCA 1 : NC statements are also displayed on the machining simulation screen during machining or drawing.
 0 : No NC statements are displayed in the above case.

NOTE

When this parameter is set to 1, the tool may temporarily stop along the axis at transition from one block to the next depending on the feedrate. In this case, set this parameter to 0.

- LG1 1 : Use the extension language 1.
 0 : This language is not use.
- LG2 1 : Use the extension language 1.
 0 : This language is not use.
- LG3 1 : Use the extension language 1.
 0 : This language is not use.
- LG4 1 : Use the extension language 1.
 0 : This language is not use.
 If some parameters set to 1 at the same time, the lower parameter is in effect.

9763	#7 DRL	#6 CNT	#5 TGF	#4 TGR	#3 GRV	#2 TRD	#1 BAF	#0 BAR
------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------


Each bit type parameter shown below can be used to disable the soft-key for selecting the corresponding machining type.

- BAR 1 : The soft-key for selecting bar machining (roughing) is disabled.
 0 : The above soft-key is enabled.
- BAF 1 : The soft-key for selecting bar machining (finishing) is disabled.
 0 : The above soft-key is enabled.

TRD 1 : The soft-key for selecting threading is disabled.
 0 : The above soft-key is enabled.
 GRV 1 : The soft-key for selecting normal grooving is disabled.
 0 : The above soft-key is enabled.
 TGR 1 : The soft-key for selecting trapezoidal grooving (roughing) is disabled.
 0 : The above soft-key is enabled.
 TGF 1 : The soft-key for selecting trapezoidal grooving (finishing) is disabled.
 0 : The above soft-key is enabled.
 CNT 1 : The soft-key for selecting center drilling is disabled.
 0 : The above soft-key is enabled.
 DRL 1 : The soft-key for selecting drilling is disabled.
 0 : The above soft-key is enabled.

9764	#7 SNC	#6 ANG	#5 G1W	#4 INC	#3 ZOM	#2 TAP	#1 BOR	#0 REM
------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------

REM 1 : The soft-key for selecting reaming is disabled.
 0 : The above soft-key is enabled.
 BOR 1 : The soft-key for selecting boring is disabled.
 0 : The above soft-key is enabled.
 TAP 1 : The soft-key for selecting tapping is disabled.
 0 : The above soft-key is enabled.
 ZOM 1 : The soft-key for scaling animation is displayed on page 1.
 0 : The soft-key for scaling animation is displayed on page 2.
 INC 1 : Incremental values can be input as figure data in single machining, bar machining, threading, and grooving.
 0 : The above function is disabled.
 G1W 1 : In grooving, a groove is cut in the same Z direction (from Z+ to Z-).
 0 : In grooving, the center of a groove is first cut and the tool is moved right and left to cut the groove.
 ANG 1 : The angle of a line is input, assuming the clockwise direction as the negative direction.
 0 : The angle of a line is input, assuming the clockwise direction as the positive direction.
 SNC 1 : In semifinishing for bar machining, tool-nose geometric compensation is applied. It may take time until the tool starts cutting after it moves to the cutting start point depending on the specified number of figures.
 0 : In semifinishing for bar machining, tool-nose geometric compensation is not applied.



9765	#7	#6	#5	#4	#3	#2	#1	#0
						BSH	CBR	

- CBR 1 : C-axis boring is enabled.
 0 : The above function is disabled.
- BSH 1 : The negative shift direction is used in C-axis boring.
 0 : The positive shift direction is used in C-axis boring.

9766	#7	#6	#5	#4	#3	#2	#1	#0
						BSH	CBR	

Soft-keys (custom soft-keys) can be displayed in the tool data window to call and execute the corresponding macro program by pressing each soft-key.

- TU1 1 : Custom soft-key 1 is enabled in the tool data window.
 0 : Custom soft-key 1 is not enabled in the tool data window.
- TU2 1 : Custom soft-key 2 is enabled in the tool data window.
 0 : Custom soft-key 2 is not enabled in the tool data window.
- TU3 1 : Custom soft-key 3 is enabled in the tool data window.
 0 : Custom soft-key 3 is not enabled in the tool data window.

9767	#7	#6	#5	#4	#3	#2	#1	#0
		NT0	SFG	MTA	NCR		SGT	SFC

- SFC 1 : For arcs created in bar machining, tool radius compensation is applied using both tool-tip radius and finishing amount.
 0 : The compensation stated above uses only the tool-tip radius. The finishing amount is used as a shift amount for compensation.
- SGT 1 : Cutting edge compensation is enabled.
 0 : Cutting edge compensation is disabled.
- NCR 1 : G41 or G42 is not used in the finishing process of bar machining.
 0 : G41 and G42 is used.
- MTA 1 : Multiple threading is carried out by specifying an angle (Q).
 0 : Multiple threading is carried out by shifting the start point of each thread.
- SFG 1 : Bar machining including very small steps is enabled.
 0 : Bar machining including very small steps is disabled.
- NT0 1 : For an offset cancel command, T**00(** is the tool selection number) is used.
 0 : T0 is used.

9768	#7	#6	#5	#4	#3	#2	#1	#0
							NBC	SBC

- SBC 1 : Titles of the contour data input window are displayed in black.
 0 : Displayed in white.
- NBC 1 : Titles of the each windows are displayed in black.
 0 : Displayed in white.

#7	#6	#5	#4	#3	#2	#1	#0
9770						NBC	SBC

NM0-NM7 Distribution for the NC format program area and MANUAL GUIDE format program area.

Length of tape storage		160m	320m	640m	1280m
NM0- NM7=0	Number of processes	99	254	559	983
	Length of tape memory for NC format program	49m	99m	198m	499m
NM0=1 (others=0)	Number of processes	89	234	519	983
	Length of tape memory for NC format program	57m	115m	229m	499m
NM1=1 (others=0)	Number of processes	79	214	479	983
	Length of tape memory for NC format program	65m	130m	261m	523m
NM2=1 (others=0)	Number of processes	69	194	434	924
	Length of tape memory for NC format program	73m	146m	293m	586m
NM3=1 (others=0)	Number of processes	51	109	269	594
	Length of tape memory for NC format program	89m	210m	420m	840m
NM7=1 (others=0)	Number of processes	-	-	-	114
	Length of tape memory for NC format program				1204

#7	#6	#5	#4	#3	#2	#1	#0
9771							

All of these bits must be set to 0

#7	#6	#5	#4	#3	#2	#1	#0
9772		RFN		RLF	EDM	M5O	CM5

- CM5 1 : When C-axis cutting processes are continuously executed, M05 is output at the beginning of each following process.
 0 : M05 is not output in the above case.
- M5O 1 : M05 is outputted when the spindle rotation changed and when the spindle gear is changed.
 0 : M05 is not outputted at the above case.
- EDM 1 : M30 is output at the program end.
 0 : M02 is output at the program end.
- RLF 1 : Between the tool change position and the approach point, the tool moves simultaneously along 2 axes.
 0 : The tool moves along 1 axis at a time at the above case.
- RFN 1 : Semi finish machining is not carried out.
 0 : Semi finish machining is carried out always.

This parameter is available in bar machining and normal grooving.

9773	#7 TRT	#6 MDL	#5	#4 TCD	#3	#2	#1 GRO	#0
------	-----------	-----------	----	-----------	----	----	-----------	----

- GRO 1 : Data for graphic drawing is not outputted at NC format program conversion.
 0 : Data for graphic drawing is outputted at the above case.
- TCD 1 : Sub program is called instead of T-code output.
 0 : T-code is outputted.
 < Related parameter : No.9778#7bit(CLT) >
- MDL 1 : At NC format program conversion, a continuous state G code (01 group) and F code are not outputted if they are the same as those in the previous block.
 0 : The above G code and F code are outputted always.
- TRT 1 : When the tool is first move to the tool change position after machining is started, it moves along the Z-axis then along the X-axis.
 0 : When the tool is first moved to the tool change position after machining is started, it moves first along the X-axis then along the Z-axis.

9774	#7	#6	#5 T0O	#4 M1O	#3 28O	#2 MLT	#1 MLS	#0
------	----	----	-----------	-----------	-----------	-----------	-----------	----

- MLS 1 : The specified M code (parameter No. 9876) is output to stop the milling axis or change the direction of its rotation.
 0 : When the direction of rotation of the milling axis changes, the M code for stopping the axis is not output.
- MLT 1 : To rotate the milling axis in the forward or reverse direction, the specified M code (parameter No. 9877 or 9878) is output.
 0 : M03 or M04 is output in the above case.
- 28O 1 : At the end of the program, T0 and G28 are not outputted.
 0 : T0 and G28 are outputted automatically at the above case.
- M1O 1 : M01 is output after the tool returns to the tool-change position at the end of each process.
 When using soft-key [PROCESS] on the animation screen, always set M1O to 1.
 0 : M01 is not outputted at the above case.
- T0O 1 : T0 is outputted immediately before a return to the tool change position (G30).
 0 : T0 is not outputted at the above case.

9775	#7	#6	#5	#4	#3	#2	#1	#0
------	----	----	----	----	----	----	----	----

All of these bits must be set to 0

9776	#7	#6	#5	#4	#3	#2	#1	#0
						MTS	STM	

STM 1 : To switch from the turning mode to the milling mode, NC program O9994 is called instead of outputting an M code.

0 : An M code is output in the above case.

<Related parameter : 9880 (STMMCD)>

MTS 1 : To switch from the milling mode to the turning mode, NC program O9995 is called instead of outputting an M code.

0 : An M code is output in the above case.

<Related parameter : 9881 (MTSMCD)>

9777	#7	#6	#5	#4	#3	#2	#1	#0
	ACC							

ACC 1 : The waste cutting cancel function for a formed material is enabled.

0 : The above function is disabled.

When this parameter (ACC) is set to 1, also set bit 2 (BSZ) of parameter No. 9761 to 1. Set the other bits of this parameter to 0.

9778	#7	#6	#5	#4	#3	#2	#1	#0
	CLT			SMS	SSM			

SSM 1 : A subprogram for switching from the turning mode to the milling mode is created in the P code area using the macro compiler.

0 : The NC program (O9994) is used as the above subprogram.

SMS 1 : A subprogram for switching from the milling mode to the turning mode is created in the P code area using the macro compiler.

0 : The NC program (O9995) is used as the above subprogram.

CLT 1 : The sub program to be called by a T code is stored in the ROM area by the macro compiler.

0 : The above sub program is stored in a tape storage area.

<Related parameter : No.9773#4(TCD)>

NOTE

When this parameter is set to 1, the tool may temporarily stop along the axis at transition from one block to the next depending on the feedrate. In this case, set this parameter to 0.

	#7	#6	#5	#4	#3	#2	#1	#0
9779		G32					CRC	CRF

- CRF 1 : When forward rotation is specified by the C-axis end face tool rotation command, the M code for reverse rotation is output. When reverse rotation is specified, the M code for forward rotation is output. For C-axis tapping, the M code specified for parameter No. 9861 (CRVMCD) is output immediately before the tapping command.
 0 : The above function is disabled.
- CRC 1 : When forward rotation is specified by the C-axis side face tool rotation command, the M code for reverse rotation is output. When reverse rotation is specified, the M code for forward rotation is output. For C-axis tapping, the M code specified for parameter No. 9861 (CRVMCD) is output immediately before the tapping command.
 0 : The above function is disabled.
- G32 1 : Tapping for turning is done by G32.
 0 : Tapping for turning is done by G84.
 Example)

G32=0 :
X0. M8 ;
Z6. ;
G99 G84 Z-30. R0. F0.5 P225 ;
G80 ;

G32=1 :
X0. M8 ;
Z6. ;
G32 Z-30. R0. F0.5 M5 ;
Z6. M4 ;
G99 ;

	#7	#6	#5	#4	#3	#2	#1	#0
	SPE	RSC	ETC	WOP	UMC	NEX		NTL

- NTL 1 : The tool data window is not displayed.
 0 : The tool data window is displayed.
- NEX 1 : Soft-key for executing playback [EXEC] is not displayed.
 0 : The above soft-key is displayed.
- UMC 1 : Each auxiliary function specified by calling a user program is enabled on the MANUAL GUIDE initial screen, guidance and single cutting screens, and cycle screen.
 0 : Each auxiliary function specified by calling a user program is enabled only on the MANUAL GUIDE initial screen and guidance and single cutting screens.
- WOP 1 : A user window can be displayed using an external key. Eight types of windows can be displayed. A user window can be displayed at a time; multiple user windows cannot be displayed simultaneously.
 0 : No user window can be displayed using any external key.

- ETC 1 : Teach-in with an external key is enabled.
 0 : Teach-in with any external key is disabled.
 When each teach-in button (TEACH AUX, TEACH RAPID, or TEACH CUT) on the operator's panel is pressed, set the corresponding PMC signal listed below to 1:
 R988#0<CUTT> : Teaching [CUT]
 #1<RPDT> : Teaching [RAPID]
 #2<AUXT> : Teaching [AUX]
- RSC 1 : The RESET key is used to locate the beginning of teach-in data displayed in the figure data window in guidance or single cutting.
 0 : The RESET key is not used to locate the beginning of teach-in data displayed in the figure data window in guidance or single cutting.
- SPE 1 : The direction of spindle rotation displayed in the status indicator window is changed by the PMC signals.
 R987 = 1 : M03 (CW)
 = 2 : M04 (CCW)
 0 : The direction of spindle rotation displayed in the status indicator window is changed by the specified spindle rotation value.

9846	#7 RTN	#6 CME	#5 MTM	#4 TTM	#3 ENM	#2 SNM	#1 POS	#0 JOG
------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------

- JOG 1 : The jog feedrate input function is enabled.
 0 : The above function is disabled.
- POS 1 : The current position data displayed in the status indicator window can be switched between absolute, relative, and machine coordinates. The function of presetting a relative coordinate is also enabled.
 0 : The above function is disabled.
- SNM 1 : The M code for switching from the milling mode to the turning mode is not output at the start of single cutting.
 0 : The above M code is output.
- ENM 1 : At the end of each process in cycle cutting, the M code specified in process data is output.

NOTE

When this parameter is set to 1, the SPDL GEAR input item in process data cannot be used.

- 0 : The above M code is not output.
- TTM In tapping by turning, an M code (for indicating forward/reverse rotation in tapping) is:
 1 : Issued before tapping (the M code specified for parameter No. 9292 or 9293 is issued).
 0 : Not issued before tapping (the rigid tapping stop M code is issued).

NOTE

When bit 6 (G32) of parameter No. 9779 is set to 1, the setting of this parameter is invalid in tapping by turning.

- MTM In tapping by milling, an M code (for indicating forward/reverse rotation in tapping) is:
- 0 : Not issued before tapping (the milling rigid tapping stop M code is issued).
 - 1 : Issued before tapping (the M code specified for parameter No. 9088 or 9089 is issued). In this case, always set bit 0 (CRF) and bit 1 (CRC) of parameter No. 9779 to 0.
- CME 1 : The valid range of M codes to be specified for parameters Nos. 9876 to 9878 is between 0 and 255.
- 0 : The valid range of the above M codes is between 0 to 99.
<Related parameters P9876 to 9878>
- RTN 1 : The tool returns to the tool-change position unconditionally regardless of whether tool change is required at transition from one process to the next.
- 0 : The above function is disabled.

NOTE

When bit 5 (G30) of parameter No. 9760 is set to 0, this function is disabled even when this parameter is set to 1.

9847	#7 SPR	#6 EFS	#5 SGL	#4 ATS	#3 SGR	#2 NCD	#1	#0 WRN
------	-----------	-----------	-----------	-----------	-----------	-----------	----	-----------

- WRN 1 : The warning message is output if residual part is remained in bar machining. (Enable is animated drawing.)
- 0 : The above function is disabled.
- NCD 1 : NC statements are displayed on the machining simulation screen.
- 0 : The above function is disabled.
<Related parameter P9762<NCA>>
- SGR 1 : The animation screen is displayed when soft-key [SELPR] is pressed.
- 0 : The tool path screen is displayed when soft-key [SELPR] is pressed.
<Related parameter P9847<SPR>>
- ATS 1 : Automatic scaling is not performed in machining simulation.
- 0 : The above function is disabled.

NOTE

When the MANUAL GUIDE selection DI signal is turned off, then on again and the machining simulation screen is displayed again with this parameter set to 1, the value set by the NC is used as the graphic scale.

- EFS 1 : A contour input figure can be scaled up.
- 0 : The above function is disabled.

- SPR** To prevent operation with a program erroneously selected by an operator error, only the program selected using soft-key [SELPR] can be used for machining operation.
 0 : The above function is disabled.
 1 : Only the program selected by pressing soft-key [SELPR] can be used for machining operation.
 <Related parameters P9847 bit 3 (SGR)>
- SGL** 1 : (1) In case of deleting a taught block in guidance or trace cutting, the confirmation message for deleting one block data is not displayed.
 (2) When feed/rev or feed/min is commanded with PMC signals R950.2 or R950.3, F-command is not output.
 (3) In guidance or single cutting, input entry SSM and RPM are displayed as the spindle speed entry.
 0 : (1) In case of deleting a taught block in guidance or trace cutting, the confirmation message for deleting one block data is displayed.
 (2) When feed/rev or feed/min is commanded with PMC signals R950.2 or R950.3, F-command is output.
 (3) In guidance or single cutting, spindle speed SSM/PRM is selected by pushing the soft key [/MIN] or [/RPM].
 0 : The above function is disabled.
 1 : Only the program selected by pressing soft-key [SELPR] can be used for machining operation.

#7	#6	#5	#4	#3	#2	#1	#0
9848	TRP				NDV		

- WRN** 1 : Thread repair function is available.
 0 : Thread repair function is not available.
- NDV** 1 : Avoiding P/S3015 alarm or wrong tool path in the arc command in bar machining.
 0 : The above function is disabled.

9749	MCPEND
------	---------------

MCPEND M-code at end of process

A.5 NUMERICAL PARAMETERS FOR MANUAL GUIDE COMMON USE

9780**OTSFpx**

OTSFpx Distance (diameter) from the cutting start point to the approaching point along the X-axis.
Valid data range : 0 to 99,999,999
Units : 0.001mm
0.0001inch

9781**OTSFpz**

OTSFpz Distance from the work-piece end face (Z=0) to the approaching point along the Z-axis.
Valid data range : 0 to 99,999,999
Units : 0.001mm
0.0001inch

9782**INCLRx**

INCLRx Distance (diameter) from the cutting start point to the approaching point for inner cutting along the X-axis.
Valid data range : 0 to 99,999,999
Units : 0.001mm
0.0001inch

9783**INCLRz**

INCLRz Distance from the work-piece end face (Z=0) to the approaching point for inner cutting along the Z-axis.
Valid data range : 0 to 99,999,999
Units : 0.001mm
0.0001inch

NOTE

The approaching point is calculated as follows.

1 Bar machining, Threading, Grooving

1) [OUTER] / [OUTER REVERSE]

$$X = [\text{Cutting start point X}] + [\text{OTSFPX}]$$

$$Z = [Z=0] + [\text{OTSFPZ}]$$

2) [INNER] / [INNER REVERSE]

$$X = [\text{Cutting start point X}] - [\text{INSFPX}]$$

$$Z = [Z=0] + [\text{INSFPZ}]$$

3) [FACE] / [FACE REVERSE]

$$X = [\text{Cutting start point X}] + [\text{OTSFPX}]$$

$$Z = [Z=0] + [\text{OTSFPZ}]$$

2 Drilling

$$X = [\text{HLSFPX : Param.No.9787}]$$

$$Z = [\text{HLSFPZ : Param.No.9788}]$$

9784

SFCLRX

SFCLRXC clearance to the cutting start point along the X-axis (diameter).

Valid data range : 0 to 99,999,999

Units : 0.001mm

0.0001inch

9785

SFCLRX

SFCLRXC clearance to the cutting start point along the Z-axis.

Valid data range : 0 to 99,999,999

Units : 0.001mm

0.0001inch

NOTE

The cutting start point is calculated as follows.

1. Bar machining
 - 1) [OUTER]

$$X = [\text{Maximum outside coordinate of a figure}] + [\text{SFLCLR}X]$$

$$Z = [\text{Z coordinate of figure start point}] + [\text{SFCLR}Z]$$
 - 2) [INNER]

$$X = [\text{Minimum inside coordinate of a figure}] - [\text{SFLCLR}X]$$

$$Z = [\text{Z coordinate of figure start point}] + [\text{SFCLR}Z]$$
 - 3) [FACE]

$$X = [\text{X coordinate of figure start point}] + [\text{SFCLR}X]$$

$$Z = [\text{Maximum Z coordinate of a figure}] + [\text{SFLCLR}Z]$$
 - 4) [OUTER REVERS]

$$X = [\text{Maximum outside coordinate of a figure}] + [\text{SFLCLR}X]$$

$$Z = [\text{Z coordinate of figure start point}] - [\text{SFCLR}Z]$$
 - 5) [INNER REVERS]

$$X = [\text{Minimum inside coordinate of a figure}] - [\text{SFLCLR}X]$$

$$Z = [\text{Z coordinate of figure start point}] - [\text{SFCLR}Z]$$
 - 6) [FACE REVERS]

$$X = [\text{X coordinate of figure start point}] - [\text{SFCLR}X]$$

$$Z = [\text{Minimum Z coordinate of a figure}] - [\text{SFLCLR}Z]$$
2. Threading, Grooving
 - 1) [OUTER]

$$X = [\text{Start point X-coordinate of a figure}] + [\text{SFLCLR}X]$$

$$Z = [\text{Start point Z-coordinate of a figure}] + [\text{SFCLR}Z]$$
 - 2) [INNER]

$$X = [\text{Start point X-coordinate of a figure}] - [\text{SFLCLR}X]$$

$$Z = [\text{Start point Z-coordinate of a figure}] + [\text{SFCLR}Z]$$
 - 3) [FACE]

$$X = [\text{Start point X-coordinate of a figure}] + [\text{SFCLR}X]$$

$$Z = [\text{Start point Z-coordinate of a figure}] + [\text{SFLCLR}Z]$$
3. Drilling(Center drilling, Drilling, Reaming, Tapping)

$$X = 0$$

$$Z = [\text{Z coordinate of figure start point}] + [\text{SFCLR}Z]$$
4. Drilling(Boring)

$$X = [\text{Hole Diameter}]$$

$$Z = [\text{Z coordinate of figure start point}] + [\text{SFCLR}Z]$$
5. C-axis drilling

$$X = [\text{Minimum inside coordinate of a figure}] - [\text{SFLCLR}X]$$

$$Z = [\text{Z coordinate of the end face of a blank}] - [\text{SFLCLR}X]$$
6. C-axis grooving
 - 1) [FACE]

$$X = [\text{Start point X-coordinate of a figure}]$$

$$Z = [\text{Start point Z-coordinate of a figure}] + [\text{SFCLR}Z]$$
 - 2) [SIDE]

$$X = [\text{Start point X-coordinate of a figure}] - [\text{SFLCLR}X]$$

$$Z = [\text{Start point Z-coordinate of a figure}]$$

9786	ZEROPT
------	--------

This data must be set to 0 always.

9787	HLSFPX
------	--------

HLSFPX X-coordinate (diameter) of the approaching point for drilling.

Valid data range : 0 to 99,999,999

Units : 0.001mm

0.0001inch

9788	HLSFPZ
------	--------

HLSFPZ Z-coordinate of the approaching point for drilling.

Valid data range : 0 to 99,999,999

Units : 0.001mm

0.0001inch

9791	CAXIS1
------	--------

CAXIS1 0: The C-axis cutting menu is not displayed.

2: C-axis cutting A is enabled (the C-axis cutting A option is required).

A.6 PARAMETER FOR BAR MACHINING

9795**CUTCHG**

CUTCHG Rate of change in the depth of cut in bar machining. If the parameter is set to 0, the depth of cut remains unchanged.

Valid data range : 0 to 200

Units : 1%

Example)

When the depth of cut is 5mm, CUTCHG is 70%, and CUTMIN is 1.5mm, the depth of cuts are as follows.

First cut 5mm

2nd 3.5mm

3rd 2.45mm

4th 1.715mm

5th 1.5mm

6th 1.5mm

9796**CUTMIN**

CUTMIN Minimum limit of depth of cut (radius) in bar machining.

Valid data range : 0 to 99,999,999

Units : 0.001mm

0.0001inch

9797**RELFX**

RELFX Default value of X component (diameter) of a clearance from the cutting surface in in-feed machining of Outer and Inner bar machining.

Valid data range : 0 to 99,999,999

Units : 0.001mm

0.0001inch

9798**RELFZ**

RELFZ Default value of Z component (radius) of a clearance from the cutting surface in in-feed machining of Face bar machining.

Valid data range : 0 to 99,999,999


Units : 0.001mm

0.0001inch

9801

TLBACK

- TLBACK** Angle at which the back of the tool is raised above the work-piece in cutting onto an intermediate part.
 Valid data range : 0 to 180
 Units : 1 degree



9802

PCOVR1

- PCOVR1** Feed amount override when the tool cut angle is larger than 90 degrees and smaller than or equal to 135 degrees
 Valid data range : 0 to 20
 Units : 10%

9803

PCOVR2

- PCOVR2** Feed amount override when the tool cut angle is larger than 135 degrees and smaller than to 180 degrees
 Valid data range : 0 to 20
 Units : 10%

9804

PCOVR3

- PCOVR3** Feed amount override when the tool cut angle is larger than 180 degrees and smaller than or equal to 225 degrees
 Valid data range : 0 to 20
 Units : 10%


9805

PCOVR4

- PCOVR4** Feed amount override when the tool cut angle is larger than 225 degrees and smaller than to 280 degrees
 Valid data range : 0 to 20
 Units : 10%

NOTE

When the tool cut angle is 90, 180, or 270 degrees, override is disabled. When a value of 0 is set, override is also disabled.



9805

FSTOVR

This data must be set to 0 always.

9809

CUTANG

CUTANG Default value of cutting edge angle for bar machining.
Valid data range : 0 to 1800
Units : 0.1 degree

9810

TIPANG

TIPANG Default value of tool tip angle for bar machining.
Valid data range : 0 to 1800
Units : 0.1 degree


9811

CLRLNGX

CLRLNGX

When the defined contour has a concave along the Z-axis as shown in the following example, the tool may move toward point P_c through an uncut section at rapid traverse. Distance DI in the example can be set for this parameter to move the tool from point P_a to point P_c at cutting feed to prevent the above situation.

Example) Reverse end face bar machining (roughing)




9812

CLRLNGZ

CLRLNGZ

The above parameter sets distance DI along the X-axis. This parameter sets distance DI along the Z-axis as shown in the following example.

Example) Outer bar machining (roughing)




A.7 PARAMETER FOR GROOVING

9820	CLGRVX
------	--------

CLGRVX Clearance (diameter) of the X-axis in outer or inner grooving.
 Valid data range : 0 to 99,999,999
 Units : 0.001mm
 0.0001inch

9821	CLGRVZ
------	--------

CLGRVZ Clearance (radius) of the Z-axis in end face grooving.
 Valid data range : 0 to 99,999,999
 Units : 0.001mm
 0.0001inch



9822	GRVCHG
------	--------

GRVCHG Rate of change in the depth of cut in grooving. If the parameter is set to 0, the depth of cut remains unchanged.
 Valid data range : 0 to 200
 Units : 1%
 Example)

When the depth of cut is 5mm, CUTCHG is 70%, and CUTMIN is 1.5mm, the depth of cuts are as follows.

First cut	5mm
2nd	3.5mm
3rd	2.45mm
4th	1.715mm
5th	1.5mm
6th	1.5mm

9823	GRVMIN
------	--------

GRVMIN Minimum limit value (radius) for the depth of cut in grooving.
 Valid data range : 0 to 99,999,999
 Units : 0.001mm
 0.0001inch

9824	GRVBCK
------	--------

GRVBCK Pecking clearance for grooving (radius).
Valid data range : 0 to 99,999,999
Units : 0.001mm
0.0001inch

9825	OVLGRV
------	--------

OVLGRV Overlaps between each cutting in grooving (proportion to the tool width).
Valid data range : 0 to 100
Units : 1%


A.8 PARAMETER FOR THREADING

9830	CLSCRX
------	---------------

CLSCRX Default value of the clearance (diameter) of the X-axis for threading.
Valid data range : 0 to 99,999,999
Units : 0.001mm
0.0001inch

9831	CLSCRZ
------	---------------

CLSCRZ Default value of the acceleration distance (radius) of the Z axis for threading.
Valid data range : 0 to 99,999,999
Units : 0.001mm
0.0001inch



9832	SCWCF
------	--------------

SCWCF Coefficient for the height of a general thread.
Valid data range : 0 to 32,767
Units : 1/10000
The system automatically sets the height of the thread for process data from the following formula.
$$\text{Height of a thread} = \text{thread pitch} \times \text{SCWCF} / 10000$$

Standard set value 6495 for thread angle 60degrees
6403 for thread angle 55degrees

9833	TRDMIN
------	---------------

TRDMIN Minimum depth (radius) of cut for threading.
Valid data range : 0 to 99,999,999
Units : 0.001mm
0.0001inch

9834	TRDFNX
------	---------------

TRDFNX Default value of the finishing allowance along the X-axis for threading (diameter)
 Valid data range : 0 to 99,999,999
 Units : 0.001mm
 0.0001inch

9835	TRDAGL
------	---------------

TRDAGL Default value of the threading tool angle to be set automatically. If 0 is set, 60degrees is automatically set.
 Valid data range : 0 to 255
 Units : 1degrees

9836	CMFONM
------	---------------

CMFONM M code for enabling chamfering in threading.
 Valid data range : 0 to 999

9837	CMFOFM
------	---------------

CMFOFM M code for disabling chamfering in threading.
 Valid data range : 0 to 999

9838	MTUNCF
------	---------------

MTUNCF Coefficient for the height of a metric or unified thread.
 Valid data range : 0 to 32,767 Units : 1/10000
 The system automatically sets the height of the thread for process data from the following formula.

$$\text{Height of a thread} = \text{thread pitch} \times \text{MTUNCF} / 10000$$

 Standard set value 6495 for thread angle 60degrees
 6403 for thread angle 55degrees

9839	PTPFCF
------	---------------

PTPFCF Coefficient for the height of a PT or PF thread.
 Valid data range : 0 to 32,767
 Units : 1/10000
 The system automatically sets the height of the thread for process data from the following formula.


$$\text{Height of a thread} = \text{thread pitch} \times \text{PTPFCF} / 10000$$

 Standard set value 6495 for thread angle 60degrees
 6403 for thread angle 55degrees

9843

ESCRNG


ESCRNG When the tool is within the distance from the thread phase synchronization position that is specified by this parameter and soft-key [CAN OR] or [EXEC] is pressed, a warning message is displayed.
 Valid data range : 0 to 99999999
 Units : 0.001mm
 0.0001inch



9844

SPLANG

SPLANG Qz is measured and set for this parameter. If P0 is equal to P1, set this parameter to 0.



9845

#7	#6	#5	#4	#3	#2	#1	#0
SPE	RSC	ETC	WOP	UMC	NEX		NTL

- NTL** 1 : The tool data window is not displayed.
 0 : The tool data window is displayed.
- NEX** 1 : Soft-key for executing playback [EXEC] is not displayed.
 0 : The above soft-key is displayed.
- UMC** 1 : Each auxiliary function specified by calling a user program is enabled on the MANUAL GUIDE initial screen, guidance and single cutting screens, and cycle screen.
 0 : Each auxiliary function specified by calling a user program is enabled only on the MANUAL GUIDE initial screen and guidance and single cutting screens.
- WOP** 1 : A user window can be displayed using an external key. Eight types of windows can be displayed. A user window can be displayed at a time; multiple user windows cannot be displayed simultaneously.
 0 : No user window can be displayed using any external key.

- ETC 1 : Teach-in with any external key is enabled.
0 : Teach-in with any external key is disabled.
When each teach-in button (TEACH AUX, TEACH RAPID, or TEACH CUT) on the operator's panel is pressed, set the corresponding PMC signal listed below to 1:
R988#0<CUTT> : Teaching [CUT]
#1<RPDT> : Teaching [RAPID]
#2<AUXT> : Teaching [AUX]
- RSC 1 : The RESET key is used to locate the beginning of teach-in data displayed in the figure data window in guidance or single cutting.
0 : The RESET key is not used to locate the beginning of teach-in data displayed in the figure data window in guidance or single cutting.
- SPE 1 : The direction of spindle rotation displayed in the status indicator window is changed by the PMC signals.
R987 = 1 : M03 (CW)
= 2 : M04 (CCW)
0 : The direction of spindle rotation displayed in the status indicator window is changed by the specified spindle rotation value.

A.9 PARAMETERS FOR DRILLING

9088	MILTMN
------	--------

MILTMN M code specified before forward tapping by milling
Valid data range : 0 to 999
When this parameter is set to 0, nothing is output.

9089	MILTMR
------	--------

MILTMR M code specified before reverse tapping by milling
Valid data range : 0 to 999
When this parameter is set to 0, nothing is output.

9292	S1TTMN
------	--------

S1TTMN M code specified before forward tapping by turning
Valid data range : 0 to 999
When this parameter is set to 0, nothing is output.

9293	S1TTMR
------	--------

S1TTMR M code specified before reverse tapping by turning
Valid data range : 0 to 999
When this parameter is set to 0, nothing is output.

9294	S1STPM
------	--------

S1STPM M code specified to spindle stop
Valid data range : 0 to 999
When this parameter is set to 0, M5 is output.

9295	S1NMLM
------	--------

S1NMLM M code specified forward spindle rotation
Valid data range : 0 to 999
When this parameter is set to 0, M3 is output.

9296	S1RVSM
------	--------

S1RVSM M code specified reverse spindle rotation
Valid data range : 0 to 999
When this parameter is set to 0, M4 is output.

9850	DRLDEC
-------------	---------------

DRLDEC Default value of the reduced depth of cut in peck or high-speed peck drilling (radius) to be set automatically.
 Valid data range : 0 to 99,999,999
 Units : 0.001mm
 0.0001inch

9851	DRLRET
-------------	---------------

DRLRET Default value of the return clearance for peck or high-speed peck drilling (radius) to be set automatically.
 Valid data range : 0 to 99,999,999
 Units : 0.001mm
 0.0001inch

9852	DRLMIN
-------------	---------------


DRLMIN Default value of the minimum depth of cut for peck or high-speed peck drilling (radius) to be set automatically.
 Valid data range : 0 to 99,999,999
 Units : 0.001mm
 0.0001inch

9853	DRILCF
-------------	---------------

DRILCF Coefficient for the depth of cut in peck or high-speed peck drilling (radius) to be set automatically.
 Valid data range : 0 to 3000
 Units : 1%
 The system automatically sets the cutting depth from the following formula.
 Drilling depth of cut = drilling diameter x DRILCF /100

9855	GRDLCL
-------------	---------------

GRDLCL Clearance (radius) from each start point in C-axis drilling and grooving
 Valid data range : 0 to 99,999,999
 Units : 0.001mm
 0.0001inch




9856**TAPCCL**

TAPCCL Clearance (radius) from each start point in C-axis tapping
Valid data range : 0 to 99,999,999
Units : 0.001mm
0.0001inch

9858**BRSHFT**

BRSHFT Default value of the amount of shift for returning in boring (radius)
Valid data range : 0 to 99,999,999
Units : 0.001mm
0.0001inch

**9858****RMBROV**

RMBROV Feedrate override for returning in reaming or boring
 $\text{Return F} = \text{F} \times \text{RMBROV} / 10$
The tool always returns at return F in reaming.
In boring by turning, the tool normally returns at the rapid traverse rate. If the hole diameter is small and the clearance is insufficient (the amount of shift for returning < BRCLER), the tool returns at return F.
Valid data range : 0 to 20
Units : 10%

9861**CRVMCD**

CRVMCD M code for rotating the milling axis in the reverse direction in C-axis tapping
<Related parameters : No.9779#0bit(CRF),No.9779#1bit(CRC)>
Valid data range : 0 to 999

A.10 PARAMETERS FOR OTHER MANUAL GUIDE FUNCTIONS

9870	GERMC1
-------------	---------------

GERMC1 M-code outputted when a low-speed gear is selected.
Valid data range : 0 to 255

9871	GERMC2
-------------	---------------

GERMC2 M-code outputted when an intermediate speed gear 2 is selected.
Valid data range : 0 to 255

9872	GERMC3
-------------	---------------

GERMC3 M-code outputted when an intermediate speed gear 2 is selected.
Valid data range : 0 to 255

9873	GERMC4
-------------	---------------

GERMC4 M-code outputted when a high-speed gear is selected.
Valid data range : 0 to 255

9876	MLSTPM
-------------	---------------

MLSTPM M code specified milling tool axis stop
<Related parameters : No.9774#1bit(MLS), No.9846#6bit(CME)>
Valid data range : 0 to 99
When this parameter is set to 0, M5 is output.

9877	MLNMLM
-------------	---------------

MLNMLM M code specified forward milling axis rotation
<Related parameters : No.9774#2bit(MLT) , No.9846#6bit(CME)>
Valid data range : 0 to 99
When this parameter is set to 0 or a value outside the valid data range is set, this M code is not output.

9878	MLRVSM
-------------	---------------

MLRVSM M code specified reverse milling axis rotation
<Related parameters : No.9774#2bit(MLT) , No.9846#6bit(CME)>
Valid data range : 0 to 99
When this parameter is set to 0 or a value outside the valid data range is set, this M code is not output.

9880	STMMCD
-------------	---------------

STMMCD M-code for switching the turning mode to the milling mode
Valid data range : 0 to 99

9881**MTSMCD**

MTSMCD M-code for switching the milling mode to the turning mode
Valid data range : 0 to 255

9883**SQNOIC**

SQNOIC Sequence number (N) to be outputted for each block during NC format program converting.

- 0 : No sequence number is outputted.
- 1 to 8999 : This value is added to the sequence number for the first block of each process.
- 8999 to -1 : The absolute value of this data is added to the sequence number for all blocks.

NOTE

If nonzero data is set, process names (comment statement in English only) are outputted at the beginning of each process of the converted NC format program.

9884**GRPMGN**

GRPMGN Scale factor of the blank length and blank diameter in the graphic parameters for the length and the maximum outside diameter of a work material used in a machining.

Valid setting range : 0 to 20

Units : 10 percent

Blank length and blank diameter in the graphic parameters = maximum outside diameter and length of a work material used in a machining * (GRPMGN)/10

NOTE

When this parameter is set to 0, automatic setting is not performed.

9889**MFNCTM**

MFNCTM Average time required to execute a M code function.

Valid data range : 0 to 99,999,999

Units : 10msec

NOTE

Parameter from No.9889 to 9891 are used to calculate the machining time in machining simulation.

9890	MFNCTM
------	--------

MFNCTM Average time required to execute a S code function.
Valid data range : 0 to 99,999,999
Units : 10msec

9891	MFNCTM
------	--------

MFNCTM Average time required to execute a T code function.
Valid data range : 0 to 99,999,999
Units : 10msec

A.11 SETTING PARAMETERS IN THE NC

3405	#7	#6	#5	#4	#3	#2	#1	#0
			CCR					

- CCR To specify a corner radius during chamfering.
 1 : Address C and R are used. Address C cannot be used for C-axis.
 0 : Address I and K are used. In direct programming of a drawing dimension, ",C" and ",R" are used.
 This bit must be set to 0 always.

5002	#7	#6	#5	#4	#3	#2	#1	#0
			LGC	LGT		LWT	LGN	LD1

- LD1 1 : The offset number of tool offset is specified by one digit after the T code.
 0 : The offset number of tool offset is specified by two digits after the T code.
 This bit must be set to 0 always.
- LGN 1 : The upper two digits in the T code indicate a tool geometry compensation number.
 0 : The lower two digits in the T code indicate a tool geometry compensation number.
 This bit must be set to 0 always.
- LWT 1 : Tool wear compensation is applied by shifting the coordinate system.
 0 : Tool wear compensation is applied by moving the tool.
 This bit must be set to 1 always.
- LGT 1 : The tool geometry is compensated according to tool movement.
 0 : The tool geometry is compensated according to the shift of the work coordinate system.
 This bit must be set to 0 always.
- LGC 1 : Tool geometry compensation is canceled by specifying 0 for the offset number.
 0 : Tool geometry compensation is not canceled by specifying 0 for the offset number.
 This bit must be set to 1 always.

5110	C-axis clamp M code
------	---------------------

The value obtained by adding 1 to the M code set for this parameter is used as the C-axis unclamp M code.
 Valid data range : 0 to 99

5111	Dwell time when C-axis unclamping is specified
------	--

Valid data range : 0 to 32767
 Units : 1msec

5210

M code for specifying the rigid tapping mode

Set an M code for specifying the rigid tapping mode.
Valid data range : 0 to 255

5212

M code for specifying the rigid tapping mode

Set an M code for specifying the rigid tapping mode.
The M code for specifying the rigid tapping mode is normally set for parameter No. 5210. If you want to use an M code having a number 256 or more, set the M code for this parameter.
Valid data range : 0 to 65535

NOTE

As the M code for specifying the rigid tapping mode, the M code set for parameter No. 5212 is issued when the parameter is set to a value other than 0 or the M code set for parameter No. 5210 is issued when parameter No. 5212 is set to 0. If both parameters Nos. 5210 and 5212 are set to 0, M29 is issued, however.

6500	#7	#6	#5	#4	#3	#2	#1	#0
		NZM		CSF	DPA			

DPA 1 : The current position shown on the graphic screen is the programmed position.
0 : The actual position obtained after the tool radius compensation is applied.

This bit must be set to 0 always.

CSF Product figure drawing in cycle cutting is:

- 1 : Enabled.
0 : Disabled.

NZM 1 : The new style of scale magnification is enabled.
0 : The conventional scale magnification is enabled.
This bit must be set to 1 always.

NOTE

Set the other bits of this parameter to 0.

6501	#7	#6	#5	#4	#3	#2	#1	#0
			CSR					

CSR 1 : A cross cursor (x) is appeared on the scale magnifying screen.
0 : A square cursor is appeared.
This bit must be set to 0 always.

6502	#7	#6	#5	#4	#3	#2	#1	#0
								HSA

HSA 1 : High speed machining simulation is enabled.
 0 : Conventional type machining simulation is enabled.
This bit must be set to 1 always.

NOTE

Set the other bits of this parameter to 0.

5212	GRPAX

GRPAX Drawing coordinate system in the machining simulation.
This data must be set to 15 always.
Set 14 for the back tool post lathe.

B

ALARMS

If one or more of the set of the parameters or inputted programs are not correct when an attempt is made to execute that program, the following P/S alarms are raised.

When an alarm other than the following P/S alarms is raised, refer to the relevant NC operator's manual.

Alarm	Description	
3000	Cause	Some initial setting data commonly used for a machining program is missing. For example, this alarm occurs by the following mistake. - No cutting motion in a work-piece was taught-in in a guidance or single cutting process. - Incorrect figure data is inputted in cycle motions
	Action	Delete that program at once, and input it again with regular figure data or cutting motions.
	Reference	None
3001	Cause	The value of process data such as the machining area, tool number, or spindle speed is incorrect. Example) A minus value is entered for an item that must be positive.
	Action	On the process data window corresponding to this alarm, check the entered process data values. If there is an incorrect value, enter a correct value.
	Reference	II.4 Guidance Cutting Operations, II.5 Single Cutting Operations III Types of Cycle Motions
3002	Cause	Some figure data is missing.
	Action	On the figure data window for the process corresponding to this alarm, check the entered data. If some data is missing, enter correct data.
	Reference	III Types of Cycle Motions
3005	Cause	On the process data window, the value for the feedrate is missing or set to 0.
	Action	On the process data window corresponding to this alarm, enter a correct value for the feedrate.
	Reference	II.4 Guidance Cutting Operations, II.5 Single Cutting Operations III Types of Cycle Motions
3006	Cause	On the process data window, the value for the depth of cut is missing or set to 0.
	Action	On the process data window corresponding to this alarm, enter a correct value for the depth of cut.
	Reference	III Types of Cycle Motions

Alarm	Description	
3007	Cause	On the process data window, the value for the spindle speed is missing or set to 0.
	Action	On the process data window corresponding to this alarm, enter a correct value for the feedrate.
	Reference	II.4 Guidance Cutting Operations, II.5 Single Cutting Operations III Types of Cycle Motions
3011	Cause	The MANUAL GUIDE function does not operate normally. This alarm is raised when the NC internal memory is damaged and the MANUAL GUIDE function cannot operate normally.
	Action	Delete the program corresponding to this alarm. Even though this alarm cannot be canceled, delete the all program by turning on a power with pushing a DELETE key, and input the program again.
	Reference	None
3014	Cause	The program is not selected. This alarm is raised when a playback machining starting is performed without any program being selected.
	Action	Select a program on a program list window, and perform a playback machining starting.
	Reference	II.8 Playback Machining and Machining Simulation
3015 (Finishing) 3016 (Roughing)	Cause	The finishing allowance or radius of the tool tip radius specified for bar machining or grooving is large. Normal rough machining cannot be executed.
	Action	Reduce the finishing. Alternatively, use a tool with a smaller radius at the tool tip.
	Reference	III.1 Bar Machining (Roughing), III.2 Bar Machining (Finishing) III.5 Grooving (Trapezoidal)
3020	Cause	Cutting in bar machining is impossible because of the relationship between the tool angle, cutting edge angle, and clearance angle (parameter No.9801) for the tool used. This alarm is raised when the sum of the above three angles is less than or equal to 90degrees or is greater than or equal to 180degrees.
	Action	Check the above three data, and input correct values or select other tools.
	Reference	III.1 Bar Machining (Roughing), III.2 Bar Machining (Finishing)
3021	Cause	The part to be left in cutting tool back compensation cannot be determined at bar machining.
	Action	On the figure data window for the process corresponding to this alarm, check the machining figure. If the figure is incorrect, enter correct figure data. If the figure is correct, the tool cannot be used for this figure. So, change the tool for the process data or change the clearance angle (parameter No.9801).
	Reference	III.1 Bar Machining (Roughing), III.2 Bar Machining (Finishing)

Alarm	Description	
3022	Cause	The figure data is incorrect in bar machining. This alarm is raised when the relationship between start point coordinate and figures is incorrect.
	Action	On the figure data window for the process corresponding to this alarm, check the machining figure. If the figure is incorrect, enter correct figure data.
	Reference	III.1 Bar Machining (Roughing), III.2 Bar Machining (Finishing)
3025	Cause	A correct tool path cannot be calculated in bar machining. This alarm is raised when there is an error in the result of internal calculation (for example, when the value under a square root sign is negative because of an error in calculation).
	Action	On the figure data window for the process corresponding to this alarm, check the machining figure. If the figure is incorrect, enter correct figure data. If the figure is correct, the tool or finishing amount cannot be used for this figure. Reduce the finishing. Alternatively, use a tool with a smaller radius at the tool tip.
	Reference	III.1 Bar Machining (Roughing), III.2 Bar Machining (Finishing)
3026	Cause	The groove width is incorrect in grooving. This alarm is raised when the width of the tool used is larger than the groove width.
	Action	On the process data window for the grooving process corresponding to this alarm, check the groove width. If the width is incorrect, enter correct value. Otherwise, select a tool whose cutting edge width is smaller than the groove width.
	Reference	III.4 Grooving (Standard)
3028	Cause	Cutting in trapezoidal grooving is impossible because of the relationship of the groove bottom width and the tool width. This alarm is raised when the cutting edge width of the tool used is larger than the groove bottom width in trapezoidal grooving.
	Action	Check the figure, on the figure data window for the grooving process corresponding to this alarm. If the figure is incorrect, enter correct data. Otherwise, select a tool whose cutting edge width is smaller than the groove width.
	Reference	III.5 Grooving (Trapezoidal)
3029	Cause	The start point for threading coincides with the end point.
	Action	On the figure data window for the threading process corresponding to this alarm, enter correct data for the figure.
	Reference	III.3 Threading
3031	Cause	An invalid chamfering tool is set for C-axis grooving. This alarm is raised when the small diameter of the chamfering tool used is larger than the groove width.
	Action	Use a chamfering tool whose small diameter is smaller than the groove width.
	Reference	IV.4.3 C-axis end face grooving

C

DYNAMIC GRAPHIC DISPLAY FOR NC PROGRAMS

C.1 OVERVIEW

Motions in a playback machining program created using the MANUAL GUIDE can be checked using the machining simulation function (Chapter 8, "PLAYBACK MACHINING AND MACHINING SIMULATION," in Part II).

For an NC program consisting of G or M codes, this machining simulation function cannot be used under normal conditions.

An option function, "dynamic graphic display for NC programs," can be used to use the machining simulation function.

The machining simulation function of the MANUAL GUIDE automatically creates blank figure and tool figure data to be drawn. With dynamic graphic display for NC programs, the operator should input the data additionally. (For details, see Section C.4, "DYNAMIC GRAPHIC COMMANDS.")

⚠ WARNING

An NC program which operates normally with machining simulation of this function does not operate normally in actual machining if tool offset data to be used is invalid.

During machining simulation, the tool coordinates specified in the NC program are checked, but additional data required for actual machining such as the tool offset to be used and amount of shift of the workpiece coordinate system is not checked.

For this reason, before performing actual machining with an NC program checked with machining simulation, be sure to check that required all data is set correctly, according to the manual supplied by the machine tool builder or NC function manual.

If the machine is operated using invalid data, the tool may strike the workpiece or machine, possibly breaking the tool or machine or injuring you.

NOTE

Machining simulation for NC programs cannot perform animated drawing of solid model cutting. Machining simulation can be performed only for turning and cannot be performed for C-axis cutting.

C.2 OPERATION (MACHINING SIMULATION)

- 1) Disable the MANUAL GUIDE according to the instructions in the manual supplied by the machine tool builder. In ordinary cases, turn the MANUAL GUIDE selection switch on the machine operator's panel off.
- 2) Select an NC program for machining simulation according to the instructions in the NC function operator's manual. Also, select the memory operation mode.
- 3) Press function button GRAPH to display the machining simulation screen.
- 4) Press soft-key [G.PRM] to display the graphic parameter screen. On this screen, set required data. In ordinary cases, only the following data items are required. (For details of other data items, refer to the explanation of the graphic function in the NC function operator's manual.)

WORK LENGTH W:

Length of the blank to be machined
(Valid data range 0 to 99999999,
Increment system 0.001mm/0.0001inch)

WORK DIAMETER D :

Diameter of the blank to be machined (The valid data range and increment system are the same as for WORK LENGTH.)

GRAPHIC MODE M :

Drawing format. Be sure to set a value between 1 and 3.

1 = Blank (cross section) and tool path

2 = Animated drawing of cutting the blank (cross section) with the tool

3 = Animated drawing of cutting the blank (cross section) with the tool and tool path

In ordinary cases, set 1.

NOTE

Graphic parameters WORK LENGTH and WORK DIAMETER are used only for determining the drawing scaling factor and position and not used for drawing the blank figure.

To draw the blank figure, input dynamic commands described in Section C.4 additionally.

- 5) Press soft-key [GRAPH] to display the machining simulation screen. Press soft-key [(OPRT)] to display the following soft-keys. Use these soft-keys for required operation.

SPEED UP :

Increases the machining simulation speed. (Valid data range: 0 to 500) In ordinary cases, set 500 (maximum speed).

SPEED DOWN :

Reduces the machining simulation speed.

HEAD :

Returns to the top of the program and initializes the screen.

WORK PIECE :

Initializes blank figure drawing.

PROCESS :

Starts machining simulation. When M01 is found in a block in the NC program, a single block stop is caused in the block.

EXEC :

Starts continuous machining simulation.

SINGLE STEP:

Causes a single block stop while continuous machining simulation is being executed or starts single block machining simulation when the function is stopped.

NOTE

The soft-keys other than the above ([PROT] and [PROG ON/OFF]) cannot be used.

C.3 OPERATION (SCALING)

1) Press the rightmost soft-key ([+]) when the above soft-keys are displayed. Soft-key [ZOOM] is displayed.

2) Press soft-key [ZOOM] to display the drawing scaling screen. Use the following soft-keys and cursor keys to perform required operation:

NORMAL :

Returns to the standard scaling factor automatically determined according to WORK LENGTH and WORD DIAMETER.

SCAL ↑ :

Scales the drawing up.

SCAL ↓ :

Scales the drawing down.

CAN :

Cancels scaling for drawing.

EXEC :

Determines the specified scaling factor.

CURSOR KEY(← → ↑ ↓):

Moves the graphic cursor indicating the center of the screen after scaling.

3) Press the leftmost soft-key ([<]) and soft-key [(OPRT)] to display the soft-keys for machining simulation shown in Section C.2. Press [EXEC]. Machining simulation starts with the specified scaling factor for drawing.

C.4 DYNAMIC GRAPHIC COMMANDS

To draw the blank to be machined or tool in machining simulation for NC programs, input the following dedicated NC commands in the NC program.

(1) Blank figure

G10 P90054 X(Xs) Z(Zs) ;
 Start of registration of a blank figure. Xs and Zs indicate the drawing start point of the blank.
 G10 P90001 X(Xn) Z(Zn) ;
 Line for the blank figure. Xn and Zn indicate the end point of the line.
 :
 : (Specify the lines required for drawing the blank figure.)
 :
 G10 P90050 ;
 End of registration of the blank figure

NOTE

If no blank figure data is input, the blank figure specified immediately before drawing, including that specified with MANUAL GUIDE machining simulation, is drawn.

(2) Tool figure

For all tools used in the currently selected NC program, register tool figure data at the beginning of the NC program as shown below:

G10 P90051 X(Xt) Z(Zt) Q(Gn) ;
 Start of registration of the tool figure having graphic registration number Gn. Xt and Zt indicate the tool tip position. Gn indicates the graphic registration number of the tool (1 to 16).

G10 P90001 X(Xtn) Z(Ztn) ;
 Line for the tool tip figure for graphic registration number Gn. Xn and Zn indicate the end point of the line. (tool tip figure is closed area specified the maximum 4 points)
 :
 : (Specify the lines required for drawing the tool tip figure.)
 :

G10 P09000 X(Xss) Z(Zss) ;
 Start point of the tool shank figure for graphic registration number Gn(Xss/Zss)

G10 P90001 X(Xsn) Z(Zsn) ;
 Line for the tool shank figure for graphic registration number Xsn and Zsn indicate the end point of the line (up to six tool shanks).
 :
 : (Specify the lines required for the tool shank figure.)
 :

G10 P90050 ;

End of registration of the tool figure

Assign a graphic registration number (1 to 16) to each tool to be used and input the above registration commands.

(3) Tool selection

Immediately before a tool is used in the NC program, select the tool from multiple tool figures registered in advance as described above.

G10 P90060 Q(Gn) R(R) ;

Selects the tool figure having graphic registration number Gn (1 to 16) as a tool for drawing. R can be specified for mirroring the drawing.

R= 0 : X-axis off and Z-axis off
1 : X-axis on and Z-axis off
2 : X-axis off and Z-axis on
3 : X-axis on and Z-axis on

NOTE

When the drawing mode is set to 1, the tool selection command is also required. In this case, specify a dummy number between 1 and 16 for Q.

(4) Screen initialization

Specify the following command to draw a blank after completion of registration of the blank figure.

G10 P90099 ;

D

ADDITIONAL INFORMATION ON EACH CUTTING MOTION

The tool moves in each type of machining as follows in principle:

Tool-change point

↓ <1>

Approaching point (*1)

↓ <2>

Cutting start point (*2)

↓ <3>

Cutting motion

↓ <4>

Retraction

↓ <5>

Cutting start point (*3)

↓ <6>

Approaching point (*1)

↓ <7>

Tool-change point

(*1) An attempt to directly move the tool from the tool-change point to the cutting start point may fail because the tool strikes against an obstacle such as the workpiece. For this reason, the tool is moved safely via the approaching point to the cutting start point so that it does not strike against any obstacle.

(*2) The cutting start point is the position at which a cutting motion starts. The tool may not pass through the cutting start point depending on the type of machining.


(*3) The tool may not pass through the cutting start point depending on the type of machining.

The following sections describe machining requiring additional information.


D.1 BAR MACHINING

(1) Outer roughing

- Without semifinishing




- With semifinishing



The release amount is specified as an detail process data item.
Clearance X is specified for parameter No. 9784.


In machining in the forward direction, the input figure is defined from the end face of the workpiece to the chuck side.

(2) Outer finishing




(3) Outer reverse roughing and finishing

The input figure is defined from the end face of the chuck to that of the workpiece as shown in the figure below. For this reason, the cutting motion is the same as in outer roughing and finishing except for the machining direction.




(4) Inner roughing

- Without semifinishing




The release amount is specified as an detail process data item.

- With semifinishing



(5) Inner finishing




The release amount is specified as an detail process data item.

(*) When the approaching point is specified outside the cutting start point (+X side), the tool does not pass through the cutting start point.


(6) Inner roughing and finishing (reverse)

The input figure is defined from the end face of the chuck to that of the workpiece as shown in the figure below. For this reason, the cutting motion is the same as in inner roughing and finishing except for the machining direction.




(7) End face roughing

- Without semifinishing



Clearance X is specified for parameter No. 9784.


- With semifinishing



The release amount is specified as an detail process data item.
Clearance Z is specified for parameter No. 9785.

In end facing, the figure is defined from the outer surface of the work-piece (+X) to the center in the direction of the diameter as shown in the above figure.


(8) End face finishing




The release amount is specified as an detail process data item.

(9) End face roughing (reverse)

- Without semifinishing



- With semifinishing




The release amount is specified as an detail process data item.

Clearance Z is specified for parameter No. 9785.

In reverse end facing, the figure is defined from the center of the work-piece to the outer surface (+X) in the direction of the diameter as shown in the above figure.


(10) End face finishing (reverse)



The release amount is specified as an detail process data item.

D.2 NORMAL GROOVING


(1) Outer grooving



NOTE


Be sure to set a point further apart from the center of the blank than figure start point X (+X side) as the approaching point.

(2) Inner Grooving



NOTE


Be sure to set a point nearer to the center of the blank than figure start point X as the approaching point.

(3) End face cutting

Clearance Z is specified for parameter No. 9821.

D.3 TRAPEZOIDAL GROOVING

(1) Outer grooving (Roughing and finishing)




Clearance X is specified for parameter No. 9820.

NOTE


Be sure to set a point further apart from the center of the blank than figure start point X (+X side) as the approaching point.

(2) Inner grooving (Roughing and finishing)




NOTE

Be sure to set a point nearer to the center of the blank than figure start point X as the approaching point.


(3) End face grooving (Roughing and finishing)

D.4 THREADING

(1) Outer threading



(2) Inner threading



Clearance X is specified for parameter No. 9830.
Clearance Z is specified for parameter No. 9831.

INDEX

<Number>

9.5"/10.4" LCD-MOUNTED TYPE CNC CONTROL
UNIT 16

<A>

ADDITIONAL INFORMATION ON EACH CUTTING
MOTION 303
ALARM MESSAGE WINDOW 179
ALARMS 293
ALARMS DURING CONVERSION OF THE
MACHINING PROGRAM INTO NC PROGRAM 91
ALL-IN-ONE SCREEN 6
AUTOMATIC DIVISION OF TAUGHT-IN BLOCKS IN
GUIDANCE CUTTING 191

BAR MACHINING 304
BAR MACHINING (FINISHING) 115
BAR MACHINING (ROUGHING) 97
BIT TYPE PARAMETERS FOR MANUAL GUIDE
COMMON USE 259
BLANK FIGURE DATA DISPLAY IN THE PROGRAM
LIST WINDOW 178
Boring Tools 88

<C>

CALCULATING INPUT DATA 173
C-AXIS CUTTING A 202
C-AXIS END FACE CENTER DRILLING, C-AXIS END
FACE DRILLING, C-AXIS END FACE REAMING, C-
AXIS END FACE BORING, C-AXIS END FACE
TAPPING 203
C-AXIS END FACE GROOVING 223
C-AXIS SIDE FACE CENTER DRILLING, C-AXIS
DRILLING, C-AXIS REAMING, C-AXIS BORING, C-
AXIS TAPPING 217
C-AXIS SIDE FACE GROOVING 233
CENTER DRILLING / DRILLING / REAMING /
BORING / TAPPING 144
Center Drills 87
Changing a Figure 63
Changing Inputted Contour Figure Data 62
CHANGING PROGRAM NAME 69

CHECKING CUTTING MOTIONS ON A GRAPHIC
WINDOW 38
CHECKING CUTTING MOTIONS ON A GRAPHIC
WINDOW 52
CHECKING CUTTING MOTIONS ON A GRAPHIC
WINDOW 65
CONVERTING MACHINING PROGRAM INTO NC
PROGRAM 89
Copying a Process 73
Copying a Program 71
CYCLE CUTTING OPERATIONS 55

<D>

DELETING / COPYING A PROGRAM 71
Deleting a Contour Figure 63
Deleting a needless Contour Figure Data 62
Deleting a Process 73
Deleting a Program 71
DESCRIPTION OF COORDINATE 18
DESCRIPTION OF THE KEYBOARD 15
DETAIL OF CONTOUR CALCULATION 105
DETAIL OF FIGURE DATA 101, 119, 129, 135, 142
Detail of Figure Data 214, 220, 229, 236
DETAIL OF PROCESS DATA
..... 98, 116, 123, 133, 138, 146
Detail of Process Data 204, 218, 224, 233
Detail of Tool File Data 80
DETAIL OF -X AREA CUTTING 155
DETAILS OF CUTTING MOTIONS 244
DIRECT INPUT OF THE JOG FEEDRATE 182
Displaying of Entered Tool Motion Blocks 49
Drills 87
DYNAMIC GRAPHIC COMMANDS 301
DYNAMIC GRAPHIC DISPLAY FOR NC PROGRAMS 296
EDITING CONTOUR FIGURE DATA (BAR
MACHINING) 62

<E>

EDITING TAUGHT-IN BLOCKS 36
EDITING TAUGHT-IN OR ENTERED BLOCKS 50
EDITING THE CONTENTS OF MACHINING
PROCESS 70
EDITTING OF PLAYBACK MACHINING PROGRAMS 68

ENTERING CUTTING MOTIONS	45	NECKING FIGURE INPUTTING OF DIN509-E, DIN509-F, AND DIN76	120
EXAMPLE OF CONTOUR FIGURE INPUTTING	159	NORMAL GROOVING	309
<F>		NUMERICAL PARAMETERS FOR MANUAL GUIDE COMMON USE	270
Figure Data Window.....	26, 36, 45, 50	<O>	
FLOWCHART OF OPERATIONS	14	ONE-SHOT MACHINING SIMULATION OF A INPUTTING PROCESS.....	41, 54, 67
<G>		One-shot Playback Machining.....	39
General-Purpose Cutting Tools	84	OPERATION.....	175, 249
Graphic Window.....	38	OPERATION (MACHINING SIMULATION).....	298
GROOVING.....	132	OPERATION (SCALING)	300
Grooving Tools.....	86	Operation of Entering a Tool Path (Positioning/Line/Circle)	47
GUIDANCE CUTTING OPERATIONS.....	23	Operation of Guidance Cutting (Circle).....	32
GUIDANCE HANDWHEEL	4	Operation of Guidance Cutting (Line)	29
</>		Operation of Teach-in a Cutting Block	35
INCREMENTAL COORDINATE INPUT.....	185	Operation of Teach-in a Positioning Block.....	46
INPUTTING A BLANK FIGURE	241	Operation of Teach-in a Rapid Traverse Motion Block..	28
INPUTTING CONTOUR FIGURE DATA (BAR MACHINING).....	60	Operation of Teach-in a Simple Linear Cutting Motion Block.....	28, 46
INPUTTING FIGURE DATA (OTHER THAN BAR MACHINING).....	59	Operation of Teach-in Auxiliary Function Blocks....	27, 46
INPUTTING MACHINING PROGRAMS	94	Operation of Tool File Window.....	79
INPUTTING PROCESS DATA	25, 44, 57	OPERATIONS FOR CONVERSION	90
Inserting a New Contour Figure	62	Operations for Figure Data Editing.....	37, 51
Inserting a new Contour Figure Data.....	62	OUTPUTTING / INPUTTING MACHINING PROGRAMS	92
<K>		OUTPUTTING MACHINING PROGRAMS.....	93
KEYS FOR ARITHMETIC OPERATIONS	176	OVERVIEW OF THE PROCEDURE.....	11
<M>		<P>	
MACHINE COORDINATE SYSTEM	19	PARAMETER FOR BAR MACHINING	274
MACHINING SIMULATION.....	76	PARAMETER FOR GROOVING	278
Machining Simulation with Animated Drawing and Tool Path.....	77	PARAMETER FOR THREADING.....	280
Machining Simulation with Solid Model Animated Drawing	76	PARAMETERS	253
Machining Simulation with Tool Path Drawing	76	PARAMETERS FOR DRILLING	284
Main Process Data	25	PARAMETERS FOR DRILLING (1)	254
Main Process Data	44	PARAMETERS FOR MANUAL GUIDE PERIPHERAL FUNCTIONS.....	255
MEASURING WORKPIECE COORDINATE SHIFT AMOUNT.....	81	PARAMETERS FOR OTHER MANUAL GUIDE FUNCTIONS.....	287
Moving a Process	72	PLAYBACK MACHINING	39, 53, 66, 75
<N>		PLAYBACK MACHINING AND MACHINING SIMULATION.....	74
NC STATEMENT DISPLAY ON THE MACHINING SIMULATION SCREEN	183		

Process Data Window.....	98, 116, 123, 133, 146	TOOL DATA.....	79
Process Data Window for Finishing.....	139	Tool File Window.....	79
Process Data Window for Roughing.....	138	TOOL FORM FOR ANIMATED DRAWING.....	84
PROCESS EDITING.....	72	TRAPEZOIDAL GROOVING.....	311
PROGRAM COORDINATE SYSTEM	22	TRAPEZOIDAL GROOVING (ROUGHING AND FINISHING).....	137
Reamers	88		
RECALL OF FIGURE DATA FOR ROUGHING AND FINISHING	64		
RETHREADING	246		
REVERSE TAPPING.....	194		
Round Nose Cutting Tools	88		
<S>			
SAFE OPERATION FOR PROGRAM SELECTION .	193	UNIDIRECTIONAL GROOVE CUTTING	190
Sample of Process Data	57	USEFUL DISPLAY FUNCTIONS	177
SELECTING OF -X AREA CUTTING	154	USEFUL FUNCTIONS FOR MACHINING	
SELECTING THE CYCLE CUTTING.....	56	PROCESSES	184
SELECTING THE GUIDANCE CUTTING	24	USER PARAMETERS.....	258
SELECTING THE SINGLE CUTTING.....	43		
Selecting the Type of Machining.....	203, 217, 223, 233		
SETTING DATA.....	78	<V>	
SETTING PARAMETERS IN THE NC	290	VARIOUS TYPES OF CURRENT POSITION DISPLAY AND COORDINATE SYSTEM PRESET	180
SINGLE CUTTING OPERATIONS	42		
SOFT-KEY FOR ANIMATED DRAWING SCALING OPERATION.....	181	<W>	
SPECIFICATION OF SEMIFINISHING FOR BAR MACHINING.....	192	WASTE CUTTING CANCEL FUNCTION.....	240
STAND-ALONE TYPE SMALL MDI UNIT	16	Whole Processes Playback Machining	40
STAND-ALONE TYPE STANDARD MDI UNIT	17	WORKPIECE COORDINATE SYSTEM.....	20
Supplemental Process Data.....	58		
Supplemental Process Data in a Pop-up Window		<X>	
.....	99, 117, 128, 134, 150, 210, 227, 234	-X AREA CUTTING FUNCTION	153
Supplemental Process Data in a Pop-up Window for			
Finishing.....	141		
Supplemental Process Data in a Pop-up Window for			
Roughing	140		
SUPPORT OF BACK TOOL POST LATHES	188		
SYMBOLS USED	8		
<T>			
Taps	87		
TEACH-IN CUTTING MOTIONS	26		
THE MANUAL GUIDE CONCEPT.....	12		
THREADING.....	122, 313		
Threading Tools.....	85		

Revision Record

FANUC MANUAL GUIDE FOR LATHE OPERATOR'S MANUAL (B-63344EN)

Edition	Date	Contents	Edition	Date	Contents
02	Mar., 2002	Addition of following items : - Necking Figure Inputting Of Din509-E, Din509-F, and Din76 In III. Types Of Cycle Motions - V. Supplement - Appendix C Dynamic Graphic Display for NC Programs - Appendix D Additional Information on Each Cutting Motion			
01	Jul., 1998				

